

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the product, or data that is lost or destroyed.



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Fire warning

- Do not place any burning items or open flames near the product, since they may cause a fire.

Wireless unit

- Do not use this product near medical devices or inside medical facilities. Radio waves from this product may affect electro-medical devices.
- Do not use this product within 15 cm (6 in) of persons with a heart pacemaker implant or a defibrillator implant. Radio waves from this product may affect electro-medical devices, such as a heart pacemaker implant or defibrillator implant.

Location

- Install in the manner instructed in the manual. Falling may result in injury or damage.
- Confirm that the finished installation is safe and secure. Also, carry out safety inspections periodically. Failure to observe this may cause devices to fall and result in injury.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others. These precautions include, but are not limited to, the following:

If you notice any abnormality

- If any of the following problems occur, immediately disconnect the LAN cable from the product.
 - The LAN cable becomes frayed or damaged.
 - Unusual smells or smoke are emitted.
 - Some object, or water has been dropped into the product.
 - Cracks or other visible damage appear on the product.
- Then have the product inspected or repaired by qualified Yamaha service personnel.

Do not open

- This product contains no user-serviceable parts. Do not attempt to disassemble the internal parts or modify them in any way.

Water caution

- Do not expose the product to rain, use it near water or in damp or wet conditions, or place on it any containers (such as vases, bottles or glasses) containing liquids which might spill into any openings.

Location and connection

- When connecting this product with a PoE injector or a PoE network switch, use a LAN cable which supports PoE. If you connect a cable that does not comply with specifications, or connect a flat type or slim type cable, fire or malfunctions might occur.
- Do not damage the LAN cable. Failure to observe this precaution could result in fire, electric shock, or damage to the product.
 - Do not place heavy objects on the cable.
 - Do not process the cable in any way.
 - Do not use staples to fix the cable in place.
 - Do not apply excessive force to the cable.
 - Be sure to keep the cable away from anything hot.
- Do not place the product in an unstable position or a location with excessive vibration, where it might accidentally fall and cause injury.
- Keep this product out of reach of children. This product is not suitable for use in locations where children are likely to be present.
- Do not place the product in a location where it may come into contact with corrosive gases or salt air. Doing so may result in malfunction.
- Do not route a LAN cable where someone might trip over them, such as in a location where people pass. Tripping on a cable may cause a person or this product to fall down, resulting in personal injury or damage to the product.
- Before moving the product, remove the connected LAN cable.

Handling caution

- Do not rest your weight on the product or place heavy objects on it.

NOTICE

To avoid the possibility of malfunction/damage to the product, damage to data, or damage to other property, follow the notices below.

Handling and maintenance

- Use the product at a distance of at least 20 cm away from the human body. This product complies with international electromagnetic exposure limits set forth for a normal environment.
- Do not use the product in the vicinity of a TV, radio, or other electric products. Otherwise, the product, TV, or radio may generate noise.
- Do not use the product in the vicinity of a microwave oven. Otherwise, there is a risk of electromagnetic interference with wireless communication.
- Install the product in a location away from other electronic devices. Installing this product near other electronic devices may cause the quality of received radio waves to suffer and communication to become unstable.
- Do not install the product in a location where magnetic fields are strong. Otherwise, it might cause the product to malfunction.
- Do not expose the product to excessive dust or vibration, or extreme cold or heat, in order to prevent the possibility of disfiguration, unstable operation, or damage to the internal components.
- Do not install in locations where temperature changes are severe. Otherwise, condensation may form on the inside or the surface of the product, causing it to break.
- If there is reason to believe that condensation might have occurred, leave the product for several hours without turning on the power until the condensation has completely dried out, in order to prevent possible damage.
- Do not use a LAN cable that comes into contact with the product case or applies excessive force to the connector.
- Do not touch the interior of a port with your fingers or any metallic object.
- Do not place vinyl, plastic or rubber objects on the product, since this might cause alteration or discoloration.
- When cleaning the product, use a dry and soft cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths, since this might cause alteration or discoloration.

INFORMATION

About functions/data bundled with the product

- Warning: This is a class A product. Operation of this product in a residential environment could cause radio interference.
- This product is compatible with the 1.9 GHz DECT standard. If the product is used in an environment where CS digital broadcasting is being received or PHS is used, radio waves may interfere with each other, affecting broadcasting and communication.
- This product uses Dante Broadway. Refer to the Audinate website (English) for details on the open-source licenses for the particular software.
<https://www.audinate.com/software-licensing>
- Refer to the website below for the licensing terms of the open source software used in this product.
U.S.A. and Canada
<https://uc.yamaha.com/support/>
Other countries
<https://download.yamaha.com/>

About this manual

- This Manual uses the following signal words for the important information:

 WARNING	This content indicates “risk of serious injury or death.”
 CAUTION	This content indicates “risk of injury.”
NOTICE	Indicates content that you must observe in order to prevent the product from malfunctioning, being damaged, or operating incorrectly, and to avoid data loss.
IMPORTANT	Indicates content that you must know in order to operate and use the product correctly.
NOTE	Indicates information that is related to operation and use. Read this for your reference.

- The illustrations as shown in this manual are for instructional purposes only.
- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.
- Yamaha continuously makes improvements and updates to the software included in this product. You can download the latest software from the Yamaha website.
- Warning: Unauthorized copying of this document in part or in its entirety is prohibited.

About transfer/disposal

- If you transfer the product to a third party, pass this manual and accessories along with it.
- Before you transfer ownership or dispose of this product, initialize the product settings to default. If you transfer ownership or dispose of this product without initializing the settings, your personal data may be stolen by a third party.
- This product contains recyclable components. When disposing of this product, please contact the appropriate local authorities.

INTRODUCTION

Thank you for purchasing the Yamaha RM-WAP-16/RM-WAP-8 microphone access point. This unit is a PoE-powered access point. It is compatible with the 1.9 GHz DECT standard and Dante, and can be used in combination with a dedicated wireless microphone. Be sure to read this manual before using the unit.

Included items

- Mounting bracket : 1
- Owner's Manual (this document) : 1

Reference manuals

In order to use this unit, initial settings, such as pairing with a wireless microphone, are required. For details on the initial setting procedure, functions, and specifications, read the Reference Manual for the RM Series Wireless Microphone System. This publication is available on the Yamaha website.

U.S.A. and Canada


<https://uc.yamaha.com/support/>

Other countries

<https://download.yamaha.com/>

CONTROLS AND FUNCTIONS

Front panel



① **(Power) indicator**

② **! (Status) indicator**


Indicates the status of this unit using a color and flashing pattern. For details, refer to the Reference Manual.

③ **RESET button**

Use to reset the settings by long-pressing with a fine-tipped object, then releasing it.

Long press	Status indicator	Reset target
4 seconds to less than 8 seconds	Flashes blue twice per second (during long-pressing/resetting)	Network-related settings
8 seconds to less than 12 seconds	Flashes blue three times per second (during long-pressing/resetting)	All settings (Automatically restarts after reset)


Rear panel



① **UNLOCK switch**

Use to remove this unit from the mounting bracket. For details, refer to page 13.

Bottom panel



① Dante/PoE port

This is an RJ-45 port to which you can connect an LAN cable (CAT5e or higher) via an IEEE802.3af compliant a PoE injector or the PoE network switch to a Dante unit. For details on injectors, refer to the Reference Manual.

NOTICE : Do not connect this product to a public Wi-Fi and/or Internet service directly. Only connect this product to the Internet through a router with strong password protections. Consult your router manufacturer for information on optimum security practices.

: Do not connect any device here other than a Dante-compatible device or a device (including a computer) that supports gigabit Ethernet.

② Mounting cutouts

Use to hook onto the mounting bracket.

③ Cable slots

Use for routing the LAN cable if necessary.

④ Safety wire mounting holes

Use to attach a commercially available safety wire.

⑤ Heatsinks

Allow internal heat to escape.

NOTICE : Since the heatsinks collect heat, do not directly touch them with your hands. In addition, avoid direct contact with heat-sensitive objects.

⑥ Product label

Provides information about this unit and marks of conformity with various standards.

INSTALLING ON A WALL OR CEILING

This unit can be mounted on a wall or ceiling by using the mounting bracket.

Prepare the following.

- This unit
- Mounting bracket (included)
- Commercially available screws × 4
- Commercially available safety wire



CAUTION : Be sure to use screws and safety wires that are appropriate for the material of the wall or ceiling.

Using inappropriate hardware may cause the unit or mounting bracket to fall, resulting in injuries or malfunctions.


1. Attach the mounting bracket to the wall or ceiling with four commercially available screws.

The diameter of the screw holes is five mm.



CAUTION : When attaching to a wall, make sure that the side marked “UP” is at the top.

If it is at the bottom, the unit may fall, causing injuries or malfunctions.




2. Plug the LAN cable into the Dante/PoE port.

- NOTICE** : Use STP (Shielded Twisted Pair) cable to prevent electromagnetic interference.
: When disconnecting the LAN cable from the Dante/PoE port, wait at least five seconds before reconnecting the cable. Otherwise, damage or malfunctions may result.
- NOTE** : We recommend using single-pair Ethernet cables in order to stabilize power supply via PoE.
: If necessary, route the LAN cable through the cable slots.


3. Attach a commercially available safety wire.

4. Align the hooks on the mounting bracket with the mounting cutouts (holes) in this unit.




5. Slide this unit to engage the hooks.

This completes the installation. For safety, make sure that the unit does not come off the mounting bracket, even when a force is applied to the unit.



NOTE : To remove this unit from the mounting bracket, slide the unit in the opposite direction of installation while moving the UNLOCK switch on the rear panel (top edge in the illustration above) in the direction shown below.



NOTE : This unit can also be placed on a flat surface. Install it on an open area such as a desk or shelf. Do not install it inside a shelf or where airflow is blocked by obstructions and do not place it on heat-sensitive objects.

MAIN SPECIFICATIONS

General specifications

Dimensions		W 171.0 mm × D 172.5 mm × H 43.0 mm
Weight		650 g (including mounting bracket)
Power requirements		PoE (IEEE802.3af), 48 V DC
Maximum power consumption		48 V, 0.2 A
In operation	Temperature	0 °C – 40 °C
	Humidity	20% – 85% (no condensation)
Storage	Temperature	–20 °C – 60 °C
	Humidity	10% – 90% (no condensation)
Indicators		• Power • Status • Network port
Maximum device number with RM-CR	RM-WAP-16	1
	RM-WAP-8	2
Accessories		• Mounting bracket : 1 • Owner's Manual (this document) : 1

Network specifications

Dante/PoE port	• Dante audio/Dante control • External control • PoE • Cable requirements: CAT5e or higher, STP
----------------	--

Audio specifications

Sampling rate		48 kHz
Bit depth		24-bit
Latency		30 [ms] (DECT high quality mode, no sound processing)
Audio input/output (Dante)	RM-WAP-16	16 out out1–out16 : Mic input signals (maximum 16)
	RM-WAP-8	8 out out1–out8 : Mic input signals (maximum 8)


Wireless specifications

Supported standard	1.9 GHz DECT standard
Radio frequency	• USA/Canada: 1920.0 MHz – 1930.0 MHz • Europe/Northern Europe/UK/Australia/New Zealand: 1880.0 MHz – 1900.0 MHz • Japan: 1893.5 MHz – 1906.1 MHz
Maximum output power (EIRP)	• USA/Canada: 23.5 dBm • Europe/Northern Europe/UK/Australia/New Zealand/Japan: 26.5 dBm
Antenna (built-in)	Supports space diversity
Use	• Audio communication and control between access point and microphone • Control between access point and charger
Maximum coverage distance	50 m (depends on the usage environment)
Encryption method	AES (256-bit)

The contents of this manual apply to the latest specifications as of the publishing date. To obtain the latest manual, access the Yamaha website then download the manual file.


Dimensional diagram

This unit



Units: mm

Mounting bracket



Units: mm

Information for users on collection and disposal of old equipment:

This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products, please take them to applicable collection points, in accordance with your national legislation.

By disposing of these products correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

For business users in the European Union:

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

Information on Disposal in other Countries outside the European Union:

This symbol is only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

COMPLIANCE INFORMATION STATEMENT (Supplier's declaration of conformity procedure)

Responsible Party: Yamaha Unified Communications, Inc.
Address: 144 North Rd, Suite 3250 Sudbury, MA 01776
Telephone: 800-326-1088
Type of Equipment: Microphone Access Point
Model Name: RM-WAP-16, RM-WAP-8

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received including interference that may cause undesired operation.

FCC INFORMATION (U.S.A.)

1. IMPORTANT NOTICE:

DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements.

Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

- 2. IMPORTANT:** When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

- 3. NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

INHALTSVERZEICHNIS

VORSICHTSMAßNAHMEN	21
ACHTUNG	23
INFORMATION	24
EINLEITUNG.....	26
Lieferumfang	26
Referenzhandbücher	26
BEDIENUNGSELEMENTE UND DEREN FUNKTION.....	27
Frontblende	27
Rückseite	27
Unterseite.....	28
MONTAGE AN EINER WAND ODER DECKE	29
TECHNISCHE DATEN	32
Maßbild	34

Die Nummer des Modells, die Seriennummer, der Leistungsbedarf usw. sind auf dem Typenschild, das sich auf der Unterseite des Geräts befindet, oder in der Nähe davon angegeben. Sie sollten diese Seriennummer an der unten vorgesehenen Stelle eintragen und dieses Handbuch als dauerhaften Beleg für Ihren Kauf aufbewahren, um im Fall eines Diebstahls die Identifikation zu erleichtern.

Modell Nr.

Seriennr.

VORSICHTSMAßNAHMEN

EMPFOHLENE LEKTÜRE VOR DEM WEITERFAHREN

Vorliegendes Handbuch für spätere Nachschlagzwecke sorgfältig aufbewahren.

Yamaha haftet weder für Schäden, die auf unsachgemäße Benutzung oder Veränderungen des Geräts zurückzuführen sind, noch für den Verlust oder die Zerstörung von Daten.



WARNUNG

Beachten Sie stets die nachfolgend aufgeführten Vorsichtsmaßnahmen, um schwere Verletzungen oder tödliche Unfälle durch elektrischen Schlag, Kurzschluss, Brand oder andere Gefahren zu vermeiden. Folgende Vorsichtsmaßregeln stellen keine vollständige Aufzählung dar.

Brandschutz

- Halten Sie brennende Gegenstände und offene Flammen vom Gerät fern, um einen Brand zu vermeiden.

Kabellose Komponenten

- Verwenden Sie dieses Gerät nicht in der Nähe von medizinischen Geräten oder in medizinischen Einrichtungen. Funkwellen von diesem Gerät können medizinische Geräte stören.
- Personen mit Herzschrittmacher- oder Defibrillator-Implantat müssen mindestens 15 cm von diesem Gerät entfernt bleiben. Funkwellen von diesem Gerät können medizinische Geräte wie Herzschrittmacher- oder Defibrillator-Implantate stören.

Einsatzort

- Das Gerät wie in der Anleitung beschrieben aufstellen. Anderenfalls können Verletzungen oder Schäden verursachen.
- Bestätigen Sie, dass die abgeschlossene Aufstellung sicher ist. Führen Sie außerdem regelmäßige Sicherheitskontrollen durch. Andernfalls könnten Geräte abstürzen und Verletzungen verursachen.



VORSICHT

Befolgen Sie stets die unten aufgeführten Grundvorsichtsmaßnahmen, um mögliche Verletzungen der eigenen oder anderer Personen zu vermeiden. Folgende Vorsichtsmaßnahmen stellen keine vollständige Aufzählung dar.

Ungewöhnliche Vorkommnisse

- Tritt eines der folgenden Probleme auf, trennen Sie sofort das LAN-Kabel vom Gerät.
 - Das LAN-Kabel ist ausgefranst oder beschädigt.
 - Das Gerät erzeugt einen ungewöhnlichen Geruch oder Rauch.
 - Ein Gegenstand oder Wasser ist in das Gerät eingedrungen.
 - Das Gerät weist Risse oder andere sichtbare Schäden auf.Das Gerät anschließend von qualifiziertem Yamaha Kundendienstpersonal prüfen oder reparieren lassen.

Nicht öffnen

- Dieses Gerät enthält keine vom Benutzer zu wartenden Teile. Die inneren Bauteile weder zerlegen noch in irgendeiner Weise modifizieren.

Gefahr durch Wasser

- Schützen Sie das Gerät vor Regen, Wasser und Feuchtigkeit, und stellen Sie keine mit Flüssigkeiten befüllten Behälter (wie Vasen, Flaschen oder Gläser) darauf ab, deren Inhalt in die Öffnungen auslaufen könnte.

Einsatzort und Verbindungen

- Zum Verbinden dieses Geräts mit einem PoE-Injektor oder -Netzwerk-Switch ein PoE-fähiges LAN-Kabel einsetzen. Wird ein Kabel, das dieser Spezifikationen nicht entspricht, oder ein flaches bzw. dünnes Kabel eingesetzt, könnte ein Brand oder eine Störung erfolgen.
- Das LAN-Kabel nicht beschädigen. Andernfalls könnte ein Brand, elektrischer Schlag oder Beschädigung des Geräts erfolgen.
 - Keine schweren Gegenstände auf das Kabel setzen.
 - Das Kabel in keiner Weise umrüsten.
 - Das Kabel nicht anheften.
 - Das Kabel nicht strapazieren.
 - Das Kabel von Hitzequellen fernhalten.
- Stellen Sie das Gerät nicht in eine instabile Lage oder an einem Ort mit übermäßigen Vibrationen, an dem es versehentlich abstürzen und Verletzungen verursachen könnte.
- Halten Sie dieses Gerät außer Reichweite von Kindern. Dieses Gerät eignet sich nicht für den Einsatz an Orten, wo sich Kinder aufhalten könnten.
- Setzen Sie das Gerät nicht an einem Ort ein, wo es korrosiven Gasen oder salzhaltiger Luft ausgesetzt sein könnte. Dadurch kann es zu Fehlfunktionen kommen.
- Verlegen Sie keine LAN-Kabel in Durchgangsbereichen, wo Personen stolpern könnten. Beim Stolpern über ein Kabel könnte eine Person fallen und sich verletzen oder das Gerät stürzen und beschädigt werden.
- Ziehen Sie das LAN-Kabel ab, bevor Sie das Gerät versetzen.

Vorsichtsmaßnahmen während der Benutzung

- Sie sollten sich weder auf das Gerät abstützen noch schwere Gegenstände darauf abstellen.

ACHTUNG

Beachten Sie folgende Hinweise, um eine Störung bzw. Beschädigung des Geräts, den Verlust von Daten oder andere Sachschäden zu vermeiden.

Umgang und Wartung

- Personen sollten beim Einsatz des Geräts einem Mindestabstand von 20 cm zum Gerät wahren. Dieses Gerät hält die internationalen Grenzwerte für elektromagnetische Belastung ein, die für eine normale Umgebung festgelegt wurden.
- Setzen Sie dieses Gerät nicht in der Nähe eines Fernsehgeräts, Radios oder anderen elektrischen Geräts ein. Andernfalls könnte das Gerät, Fernsehgerät oder Radio Störungen verursachen.
- Setzen Sie dieses Gerät nicht in der Nähe eines Mikrowellenherds ein. Andernfalls könnte die drahtlose Kommunikation von elektromagnetischen Störungen beeinflusst werden.
- Stellen Sie das Gerät von anderen elektronischen Geräten entfernt auf. Wird dieses Gerät in der Nähe anderer elektronischer Geräte aufgestellt, kann der Empfang von Funkwellen beeinträchtigt und die Kommunikation gestört werden.
- Stellen Sie das Gerät von starken Magnetfeldern entfernt auf. Andernfalls könnte die Funktion des Geräts beeinträchtigt werden.
- Setzen Sie das Gerät weder übermäßigem Staub, Vibrationen noch extremer Kälte oder Hitze aus, um eine äußere Schädigung, Betriebsstörungen oder eine Beschädigung innerer Bauteile zu vermeiden.
- Das Gerät nicht an Orten mit starken Temperaturänderungen anbringen. Andernfalls kann sich Kondensation auf der Innenseite oder Oberfläche des Geräts bilden und Beschädigung verursachen.
- Wenn es Grund zur Annahme gibt, dass Kondensation aufgetreten sein könnte, lassen Sie das Gerät zum Schutz vor möglichen Schäden mehrere Stunden lang ausgeschaltet, bis die Kondensation vollständig ausgetrocknet ist.
- Verwenden Sie kein LAN-Kabel, welches das Gehäuse des Geräts berührt oder die Anschlussbuchse strapaziert.
- Fingern und metallische Gegenstände aus dem Inneren der Anschlussbuchsen fernhalten.
- Halten Sie Gegenstände aus Vinyl, Kunststoff oder Gummi fern, andernfalls könnte das Gerät verformt oder verfärbt werden.
- Reinigen Sie das Gerät mit einem trockenen, weichen Tuch. Verwenden Sie keine mit Verdünnern, Lösungsmitteln, Reinigern oder anderen Chemikalien befeuchteten Wischtücher, um Verformung oder Verfärbung zu vermeiden.

INFORMATION

Über mit dem Gerät gebündelte Funktionen/Daten

- Warnung: Dies ist ein Gerät der Klasse A. Der Betrieb dieses Geräts in Wohngebieten kann Funkstörungen verursachen.
- Dieses Gerät unterstützt den 1,9-GHz-DECT-Standard. Wird das Gerät in einer Umgebung eingesetzt, wo CS-Digitalrundfunk empfangen oder PHS verwendet wird, können sich die Funkwellen gegenseitig stören und der Rundfunk oder die Kommunikation beeinträchtigt werden.
- Dieses Gerät setzt Dante Broadway ein. Weitere Informationen zu den OpenSource-Lizenzen für die jeweilige Software finden sich auf der (englischsprachigen) Website von Audinate: <https://www.audinate.com/software-licensing>
- Die Lizenzbedingungen für die in diesem Produkt verwendete Open-Source-Software findet sich auf der folgenden Website.
Für USA und Kanada
<https://uc.yamaha.com/support/>
Für andere Länder
<https://download.yamaha.com/>

Über dieses Handbuch

- Folgende Signalwörter weisen auf wichtige Informationen in vorliegendem Handbuch hin.

 WARNUNG	Dieser Inhalt weist auf „unmittelbares Risiko schwerer Verletzungen oder Todesgefahr“ hin.
 VORSICHT	Der zugehörige Inhalt weist auf „ein Risiko schwerer Verletzungen“ hin.
ACHTUNG	Verweist auf Informationen, die zu beachten sind, um Gerätepannen, -schäden oder -störungen sowie Datenverluste zu verhindern.
WICHTIG	Verweist auf Informationen, die für eine ordnungsgemäße Bedienung und Benutzung des Geräts erforderlich sind.
HINWEIS	Verweist auf Informationen zur Bedienung und Benutzung. Lesen Sie diese nach Bedarf.

- Die Abbildungen in diesem Handbuch dienen lediglich zur Veranschaulichung.
- Die in dieser Anleitung erwähnten Firmen- und Produktnamen sind Warenzeichen bzw. eingetragene Warenzeichen der entsprechenden Firmen.
- Yamaha verbessert und aktualisiert die in diesem Gerät enthaltene Software kontinuierlich. Sie können die neueste Software von der Yamaha-Website herunterladen.
- Warnung: Das unbefugte Kopieren dieses Dokuments, ob ganz oder teilweise, ist untersagt.

Bei Übergabe/Entsorgung

- Falls Sie dieses Gerät an eine andere Person weitergeben, legen Sie vorliegendes Handbuch und das Zubehör bei.
- Bevor Sie dieses Gerät weitergeben oder entsorgen, initialisieren sie es, um die Vorgabeeinstellungen wiederherzustellen. Wird das Gerät ohne Initialisierung weitergegeben oder entsorgt, könnten Ihre personenbezogenen Daten in fremde Hände geraten.
- Dieses Gerät enthält recycelbare Komponenten. Wenden Sie sich für die Entsorgung dieses Geräts bitte an die zuständigen örtlichen Behörden.

EINLEITUNG

Vielen Dank für den Kauf eines Mikrofon-Access-Points RM-WAP-16/RM-WAP-8 von Yamaha. Dieser Access Point ist PoE-betrieben. Er unterstützt den 1,9-GHz-DECT-Standard sowie Dante und kann mit einem zugehörigen Drahtlosmikrofon eingesetzt werden. Lesen Sie das vorliegende Handbuch sorgfältig durch, bevor Sie das Gerät einsetzen.

Lieferumfang

- Montagehalterung : 1
- Vorliegende Bedienungsanleitung : 1

Referenzhandbücher

Vor dem Einsatz dieses Geräts sind Ersteinstellungen wie das Pairen mit einem drahtlosen Mikrofon erforderlich. Ausführliche Informationen zu den Ersteinstellungen, Funktionen und technischen Daten finden sich im Referenzhandbuch für das Drahtlosmikrofonsystem der RM-Serie. Das Dokument ist auf der Yamaha-Website verfügbar.

Für USA und Kanada

<https://uc.yamaha.com/support/>


Für andere Länder

<https://download.yamaha.com/>

BEDIENUNGSELEMENTE UND DEREN FUNKTION

Frontblende

Deutsch



① **Betriebsanzeige**

② **Statusanzeige**


Zeigt den Status dieses Geräts durch Farben und Blinkmuster an. Einzelheiten finden sich im Referenzhandbuch.

③ **Rückstellknopf RESET**

Mit einem feinspitzigen Gegenstand gedrückt halten und dann loslassen, um die Geräteeinstellungen zurückzustellen.

Gedrückt halten	Statusanzeige	Rückstellung
4 bis unter 8 Sekunden	Blinkt zweimal pro Sekunde blau (beim Gedrückthalten/Rückstellen)	Netzwerkeinstellungen
8 bis unter 12 Sekunden	Blinkt dreimal pro Sekunde blau (beim Gedrückthalten/Rückstellen)	Sämtliche Einstellungen (automatischer Neustart nach Rückstellung)


Rückseite



① **Entriegelungsschalter UNLOCK**

Zum Lösen dieses Geräts von der Montagehalterung. Einzelheiten finden sich auf Seite 31.

Unterseite



① Buchse Dante/PoE

An dieser RJ-45-Buchse können Sie ein LAN-Kabel (CAT5e oder höher) über einen IEEE802.3af-kompatiblen PoE-Injektor oder PoE-Netzwerk-Switch mit einem Dante-Gerät verbinden.

Einzelheiten finden sich im Referenzhandbuch.

ACHTUNG : Verbinden Sie dieses Gerät nicht direkt mit einem öffentlichen WLAN oder Internetdienst. Verbinden Sie dieses Gerät nur über einen Router mit starkem Kennwortschutz mit dem Internet. Wenden Sie sich an Ihren Routerhersteller, um Informationen zu bewährten Sicherheitsverfahren zu erhalten.

: Schließen Sie hier kein anderes als ein Dante-fähiges oder Gigabit-Ethernet-fähiges Gerät (einschließlich Computer) an.

② Montageöffnungen

Zum Einhängen in die Montagehalterung.

③ Kabelführungsaussparungen

Zum Verlegen des LAN-Kabels nach Bedarf.

④ Befestigungsöffnungen für Sicherheitsseil

Zum Anbringen eines handelsüblichen Sicherheitsseils.

⑤ Wärmeableiter

Zum Ableiten angestauter Hitze.

ACHTUNG : Die Wärmeableiter nicht direkt mit Ihren Händen berühren, da sie heiß werden. Halten Sie außerdem hitzeempfindliche Gegenstände davon fern.

⑥ Typschild

Informiert über das Gerät und Prüfzeichen für verschiedene Standards.

MONTAGE AN EINER WAND ODER DECKE

Dieses Gerät kann mit der Montagehalterung an einer Wand oder Decke montiert werden.

Bereiten Sie Folgendes vor:

- vorliegendes Gerät
- Montagehalterung (im Lieferumfang enthalten)
- handelsübliche Schrauben × 4
- handelsübliches Sicherheitsseil



VORSICHT : Schrauben und Sicherheitsseil müssen sich für den Wand- oder Deckenbaustoff eignen.

Durch den Einsatz von ungeeignetem Montagezubehör könnte das Gerät oder der Montagehalterung abstürzen und Verletzungen oder Störungen verursacht werden.


1. Befestigen Sie die Montagehalterung mit vier handelsüblichen Schrauben an der Wand oder Decke.

Der Durchmesser der Bohrungen beträgt fünf mm.



VORSICHT : Bei Wandmontage muss sich die mit „UP“ gekennzeichnete Seite oben befinden.

Anderenfalls könnte das Gerät abstürzen und Verletzungen oder Störungen verursacht werden.



2. Verbinden Sie das LAN-Kabel mit der Buchse Dante/PoE.

ACHTUNG : Verwenden Sie ein STP (Shielded Twisted Pair)-Kabel, um elektromagnetische Störungen zu verhindern.


: Wurde das LAN-Kabel von der Buchse Dante/PoE abgezogen, mindestens fünf Sekunden warten, bevor es wieder eingesteckt wird. Anderenfalls könnte Beschädigung oder Störung verursacht werden.

HINWEIS : Zum Stabilisieren der Stromversorgung über PoE wird der Einsatz von Single-Pair-Ethernet-Kabeln empfohlen.

: Verlegen Sie das LAN-Kabel bei Bedarf durch die Kabelführungsaussparungen.


3. Ein handelsüblichen Sicherheitsseil anbringen.

4. Richten Sie die Montageöffnungen im Gerät auf die Haken an der Montagehalterung aus.




5. Verschieben Sie das Gerät, sodass die Haken eingreifen.

Die Montage ist nun abgeschlossen. Vergewissern Sie sich, dass sich das Gerät auch unter Anwendung von Kraft nicht von der Halterung löst.



Deutsch

HINWEIS : Um das Gerät von der Montagehalterung zu lösen, schieben Sie das Gerät in die entgegengesetzte Richtung der Montage; schieben Sie dabei den Entriegelungsschalter UNLOCK an der Rückseite (Oberkante in der obigen Abbildung) in die unten gezeigte Richtung.



HINWEIS : Das Gerät kann ebenfalls auf einer ebenen Oberfläche aufgestellt werden. Stellen Sie es in einem offenen Bereich wie einem Schreibtisch oder einem Regal auf. Stellen Sie es weder an einer Stelle im Regal, wo der Luftstrom gehindert würde, noch auf wärmeempfindliche Gegenstände ab.

TECHNISCHE DATEN

Technische Daten – Allgemein

Abmessungen		B 171,0 mm × T 172,5 mm × H 43,0 mm
Gewicht		650 g (einschließlich Montagehalterung)
Leistungsanforderungen		PoE (IEEE802.3af), 48 VDC
Maximale Leistungsaufnahme		48 V, 0,2 A
Im Betrieb	Temperatur	0 °C – 40 °C
	Luftfeuchtigkeit	20% – 85% (nichtkondensierend)
Lagerung	Temperatur	–20 °C – 60 °C
	Luftfeuchtigkeit	10% – 90% (nichtkondensierend)
Anzeigen		• Betrieb • Status • Netzwerkbuchsen
Maximale Geräteanzahl mit RM-CR	RM-WAP-16	1
	RM-WAP-8	2
Zubehör		• Montagehalterung : 1 • Vorliegende Bedienungsanleitung : 1

Technische Daten – Netzwerk

Buchse Dante/PoE	• Dante-Audio/Dante-Steuerung • Externe Steuerung • PoE • Kabelanforderungen: CAT5e oder höher, STP
------------------	--

Technische Daten – Audio

Abtastrate		48 kHz
Bittiefe		24 Bits
Latenz		30 [ms] (DECT-Hochqualitätsmodus, ohne Klangbearbeitung)
Audio-E/A (Dante)	RM-WAP-16	16 Ausgänge out1–out16 : Mikrofoneingangssignale (max. 16)
	RM-WAP-8	8 Ausgänge out1–out8 : Mikrofoneingangssignale (max. 8)


Technische Daten – Drahtloskommunikation

Unterstützter Standard	1.9 GHz DECT
Funkfrequenz	• USA/Kanada: 1920,0 MHz – 1930,0 MHz • Europa/Nordeuropa/Großbritannien/Australien/Neuseeland: 1880,0 MHz – 1900,0 MHz • Japan: 1893,5 MHz – 1906,1 MHz
Maximale Ausgangsleistung (EIRP)	• USA/Kanada: 23,5 dBm • Europa/Nordeuropa/Großbritannien/Australien/Neuseeland/Japan: 26,5 dBm
Antenne (integriert)	Unterstützt Raumdiversität
Einsatz	• Audiokommunikation und -steuerung zwischen Access Point und Mikrofon • Steuerung zwischen Access Point und Ladegerät
Maximale Reichweite	50 m (je nach Einsatzumgebung)
Verschlüsselungsmethode	AES (256 Bits)

Der Inhalt dieser Bedienungsanleitung gilt für die neuesten technischen Daten zum Zeitpunkt der Veröffentlichung. Um die neueste Version der Anleitung zu erhalten, rufen Sie die Website von Yamaha auf und laden Sie dann die Datei mit der Bedienungsanleitung herunter.


Maßbild

Vorliegendes Gerät



Einheit: mm

Montagehalterung



Deutsch

Einheit: mm