FOLDED SIZE: 10 X 7 CM
材质：157g双铜 四色双面印刷 风琴折

正面

反面

ENG

SAFETY INFORMATION

Chemical Warning
Do not use around fuels or chemicals.
Temperature Warning
Do not expose to extreme temperatures or conditions.
Water Hazard
Keep away from water or liquids.
Electrical Hazard
Keep away from magnetic or electrical fields to avoid short circuits.

Precautions and Additional Safety Information

- While charging, the speaker LED charging indicator will light up red. Once charged, LED charge indicator will turn off.
- Do not use a charger that exceeds 5V / 1000mA in order to prevent permanent battery and component damage.
- For better performance and longer battery life, it is recommended that you charge the battery fully before using for the first time. Please keep in mind that repeated charge cycles will cause battery performance to deteriorate over time.
- While charging, please keep out of the reach of children.
- Store in a cool and dry place away from direct sunlight.

ENG

BLUETOOTH PAIRING

Turn on Bluetooth from your handset or device and set to "Pair New Device".
Click on the power button to power on the **aria2** speaker.
Once powered on, the speaker indicator light will begin to flash, and the speaker will go into the Bluetooth pairing state.
Click on **"BLU aria2"** from the available devices on your Bluetooth setting to pair.
You are now ready to enjoy!

Note: *If there is no operation while pairing, the speaker will shut down after 5 minutes.*

TF CARD MODE

Turn on the speaker and insert the TF Card.
Once inserted the speaker will recognize the TF Card and automatically switch to TF mode and will start playing the music saved on the TF.

Note: *The speaker supports up to a 32GB TF card and can only play MP3 file extensions.*

ENG

USB MODE

Turn on the speaker and insert the USB Flash Drive.
Once inserted, the speaker will recognize the USB Flash Drive and automatically switch to USB Mode and will start playing the music saved on the Flash Drive.

Note: *The speaker only supports MP3 file extensions.*

AUX MODE

Turn on the speaker and connect the auxiliary cable to the 3.5mm connector on the speaker. Connect the other end of the cable to either your handset, laptop, PC, or other device. Once connected the speaker will recognize the auxiliary connection and switch to Aux mode.

Note: *While in Aux mode, the speaker cannot switch between songs. The playback controls are executed through the external device.*

ENG

PHONE CALL MODE

When a phone call is coming in, press the "▷" Play Button to answer.
Repress the Play button to end the phone call.
During standby mode in Bluetooth, double click the Play Button to redial your last outgoing call.

MUSIC CONTROLS

- Press the "▷" button to start playback. Press to pause.
- Press and Hold the "▷" button to play the next song.
- Press and Hold the "◁" button to play the previous song.
- Press the "▷" button to increase the volume.
- Press the "◁" button to decrease the volume.

While playing music, LED light will flash slowly. When paused, the LED light will stay on.

RADIO CONTROLS

- Press and hold the "▷" button to Scan for available radio stations. You can also press to pause or resume Radio playback.
- Press and Hold the "▷" button to change to the next radio station.
- Press and Hold the "◁" button to the previous radio station.
- Press the "▷" button to increase the volume.
- Press the "◁" button to decrease the volume.

ENG



1. LED Light Indicator
2. Power On / Off
3. Play / Pause / Answer Call / End Call / Redial
4. Change Modes (Bluetooth / USB / TF / AUX / Radio)
5. Previous Song / Volume Down
6. Next Song / Volume Up
7. TF Card Slot (SD)
8. USB Connector (USB Flash Drive)
9. Auxiliary Connector (3.5mm)
10. Charge Port (Micro USB Input)

ENG

15.19:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

15.21:

The user manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICITIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to providereasonable

ENG

protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference toradio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

RF Exposure statement:

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment shouldbe installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

ENG

ESP

INFORMACION DE SEGURIDAD

Advertencia Química
No lo use cerca de combustibles o productos químicos.
Advertencia de Temperatura
No exponer a temperaturas o condiciones extremas.
Advertencia de Líquidos
Mantener alejado de agua o líquidos.
Advertencia de Electricidad
Mantener alejado de campos magnéticos o eléctricos para evitar cortos circuitos.

Precauciones e Información de Seguridad Adicional

- Mientras este cargando, el indicador de carga LED del parlante se iluminará en rojo. Una vez cargado, el indicador LED de carga se apagará.
- No utilice un cargador que exceda los 5V / 1000mA para evitar daño permanente de la batería y los componentes.
- Para un mejor rendimiento y una mayor duración de la batería, se recomienda cargar la batería por completo antes de usarla por primera vez. Tenga en cuenta que los ciclos de carga repetidos harán que el rendimiento de la batería se deteriore con el tiempo.
- Mientras este cargando, manténgalo fuera del alcance de los niños.
- Almacenar en un lugar fresco y seco y lejos del sol directo.

ESP

EMPAREJAMIENTO BLUETOOTH

Active Bluetooth desde su teléfono o dispositivo y configúrelo como "Emparejar dispositivo nuevo".
Hacer clic en el botón de encendido para encender el parlante **aria2**.
Una vez encendido, la luz indicadora del parlante comenzará a parpadear y el parlante pasará al estado de emparejamiento de Bluetooth.
Hacer clic en **"BLU aria2"** de los dispositivos disponibles en su configuración de Bluetooth para emparejar.
¡Ahora estás listo para disfrutar!

Nota: *Si no se realiza ninguna operación durante el emparejamiento, el parlante se apagará después de 5 minutos.*

MODO TARJETA TF

Encienda el parlante e inserte la tarjeta TF.
Una vez insertado, el parlante reconocerá la tarjeta TF y cambiará automáticamente al modo TF y comenzará a reproducir la música guardada en el TF.

Nota: *El parlante admite una tarjeta TF de hasta 32 GB y solo puede reproducir extensiones de archivos MP3.*

ESP

MODO USB

Encienda el parlante e inserte la memoria de Flash USB.
Una vez insertado, el parlante reconocerá el Flash USB y cambiará automáticamente al modo USB y comenzará a reproducir la música guardada en el Flash USB.

Aviso: El parlante solo puede reproducir extensiones de archivos MP3.

MODO AUXILIAR

Encienda el parlante y conecte el cable auxiliar al conector de 3.5 mm en el parlante. Conecte el otro extremo del cable a su teléfono, computadora portátil, PC u otro dispositivo. Una vez conectado, el parlante reconocerá la conexión auxiliar y cambiará al modo Aux.

Nota: *Mientras está en modo Aux, el parlante no puede cambiar entre canciones. Los controles de reproducción se ejecutan a través del dispositivo externo.*

ESP

MODO DE LLAMADAS TELEFÓNICAS

Cuando reciba una llamada telefónica, presione el "▷" botón de Reproducir para responder. Presione de nuevo el botón de Reproducir para terminar la llamada telefónica. En modo de espera mientras está en Bluetooth, hacer doble clic en el botón de Reproducir para volver a marcar su última llamada saliente.

CONTROLES DE MÚSICA

- Presione el botón " ▷" para iniciar la reproducción. Presione parc pausar.
- Mantenga presionado el botón "▷" para reproducir la siguiente canción
- Mantenga presionado el botón "◁" para reproducir la canción anterior
- Presione el botón "▷" para subir el volumen
- Presione el botón "◁" para bajar el volumen

Mientras la música este reproduciendo, la luz LED parpadeará lentamente. Cuando está en pausa, la luz LED permanece encendida.

CONTROLES DE RADIO

- Presione el botón " ▷" para buscar estaciones de radio disponibles. También puede presionar para pausar o reanudar la reproducción de radio.
- Mantenga presionado el botón "▷" para cambiar a la siguiente estación de radio.
- Mantenga presionado el botón "◁" para para cambiar a la estacion de radio anterior
- Presione el botón "▷" para subir el volumen
- Presione el botón "◁" para bajar el volumen

ESP



1. Indicador de Luz LED
2. Botón de Encender
3. Reproducir / Pausar / Responder llamada / Terminar llamada / Remarcar
4. Cambiar modos (Bluetooth / USB / TF / AUX / Radio)
5. Subir volumen / siguiente canción
6. Bajar volumen / Canción anterior
7. Ranura para tarjeta TF (SD)
8. Conector USB (Memoria Flash USB)
9. Puerto auxiliar (3.5 mm)
10. Puerto de carga (Entrada de Micro USB)