- **Gimbal Back to Factory Setting**
  Get the gimbal back to factory setting, access to "PTZ adjust", click "Restore factory setting"

Parameter
Type
Value
Gimbal Calibration
Gimbal Calibration
Restore factory setting
Gimbal Calibration
Gimbal Calibration
Gimbal Calibration

Question	Reason	Solutions
Unable to return home, drifting and flying away	GPS signal was turned off during the flight	Please don't turn off GPS suddenly during outdoor flight. Switch back to GPS mode in time
Cannot charge battery/Cannot fully charge battery	Using inferior charger or charging on the computer with unstable voltage output	Use a mobile USB charger that ensures constant stable voltage output(5V) and amperage output(2-3A)
	Using inferior charging cables	Please use the original factory charging cable to charge
Short battery life	Flying in windy weather	Flying in windy weather will accelerate power loss
	Flying in cold weather	In low temperatures, the chemical reaction of the lithium battery is slowed down and the energy cannot be fully released
	The battery is not fully charged	Fully charged with the correct USB charger before flying
The product has slight marks	We tested all Aircraft before shipping	In order to give you the best experience, we tested functions of all Aircraft before shipping. Therefore, it is inevitable that there will be slight traces. However, it can be guaranteed that all Aircraft are 100% brand new

Copyright ©2022 Ruko All Rights Reserved.

17 Accessories Support

Battery

Propeller

Landing Gear

Arm

Transmitter

All of the above accessories can be searched and purchased on Amazon, and you can enter the Ruko store to buy them yourself.

Be sure to use original accessories. The use of non-original accessories may cause danger to the safe use of the aircraft.

⚠WARNING:

- Please read the instructions carefully before use and keep the card for reference at any time.
- Only charge charged with the original USB cable.
- Only batteries of the same or equivalent type can be used.
- Do not mix new and old batteries.
- Dispose of batteries and warn local ballpriles correctly as required by the Environmental Protection Agency.
- Keep batteries away from high temperature environment.
- Prevent batteries being pierced or otherwise damaged periodically, if any damage is discovered, please do not use it until completely repaired.

⚠ WARNING:
CHOKING HAZARD -Small parts. Not for children under 3 years.

WARNING: CANCER AND REPRODUCTIVE HARM - WWW.P65WARNINGS.CA.GOV

WARNING: يسبب السرطان والتشوهات الخلقية - www.P65Warnings.ca.gov/arabic

NO. F11 GIM 2

Depend on product configuration

Please understand that the picture on the package may differ from actual product.

Special warning: Adult supervision required for children under the age of 14

•Use in open area and be mindful of your surroundings. Drone is not equipped with obstacle avoidance.

•Drone battery must be charged with the provided USB cable with a power source no greater than a standard 5V wall charger.

MADE IN CHINA

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The distance between user and device should be no less than 20cm.

CONTACT US FOR MORE TECH SUPPORT

Rukobrandstore@gmail.com
+1 (626) - 215 - 4337 (Available from 6pm to 3am PDT)

Printed in China.

 Copyright ©2022 Ruko All Rights Reserved.

Ruko

www.rukotoy.com