Bluetooth Headphones

H070

User Manual

CONTENTS

English Version 1
Deutsche Version 2
French version 3
Español Version 4

Thank you for purchasing our products. To ensure continuous the safety, guidelines, warranty and operating instructions.
Please review this manual thoroughly before operating your device.

Package Contents

- (1) Bluetooth headphones x 1
- (1) USB cable x 1
- (1) 3.5mm audio cable x 1
- (2) Carry case x 1
- (2) User manual x 1

At a Glance

LED Indicator Guide

- Power on: LED indicator flashes blue 3 times.
- Power off: LED indicator flashes red 3 times.
- Pairing mode: LED indicator flashes red and blue alternately.
- Pairing success: LED indicator flashes blue 3 times.
- Low battery: LED indicator flashes red every 5 seconds with a prompt tone "Please charge the headphones".
- Charging: Charging indicator stays red during charging and turns blue when the headphones are fully charged.

Using the Headphones

Volume

Adjust the volume of the headphones by pressing the Volume + button or Volume - button.

Microphone

Mute/Unmute the microphone by pressing the MIC button.

Noise cancelling

Turn on/off the noise cancelling function by pressing the Noise cancelling button.

Charging

Connect the headphones to the USB port of a computer or other USB charger using the provided USB cable (the Micro USB port on the left earpiece).

- Plug the other end into a USB wall charger or computer (DC 5V) that is switched on.

The headphones will start charging.

- Fully charged the headphones before using them for the first time.
- The LED indicator flashes red during charging and turns blue when the headphones are fully charged.

- The LED indicator flashes red every 5 seconds with a prompt tone "Hello" every 2 minutes when the headphones are in the battery.

Power on/off

Power on/off: Press and hold the MFB button for 3 seconds.

Pair

1) Turn on the Bluetooth of your phone or other Bluetooth devices.
2) Turn on the headphones, and the headphones enter pairing mode automatically (indicator flashes red and blue alternately).
3) Find the H070 on Bluetooth devices in your phone or other Bluetooth devices and click to connect.
4) Enter "0000" or "1234" if your phone or Bluetooth device asks you to enter a code to pair.

Notes:

- When the headphones are on but are not paired with your phone or other Bluetooth devices, the Bluetooth will automatically turn off (indicator flashes blue) after pairing mode again, turn on the headphones).
- The headphones will directly enter pairing mode the first time you turn them on, or reconnect to the last paired Bluetooth device automatically if it is available.
- When the headphones have been paired with a Bluetooth device, turn off the Bluetooth function of the device, the headphones will enter pairing mode automatically (indicator flashes red and blue alternately).

- To have the headphones enter the pairing mode when the headphones have been paired with a Bluetooth device, turn off the Bluetooth function of the device, and the headphones will enter pairing mode automatically (indicator flashes red and blue alternately).

Headphone functions

Function	What to do
Play/Pause	Press the MFB button
Next track	Press and hold the "+" button for 2 seconds.
Previous track	Press and hold the "-" button for 2 seconds.
Volume up	Press the "+" button
Volume down	Press the "-" button
Voice Assistant Activation/Deactivation	Press and hold the "+" and "-" button at the same time for 4 seconds

Call functions

Function	What to do
Answer/end a call	Press the MFB button
Decline an incoming call	Press the MFB button for 2 seconds
Redial the last number	Double-press the MFB button

ANC function

Slide the ANC button up/down to deactivate/activate the noise cancellation function. (A green indicator will turn on/off accordingly).

Note:

- When the battery is low (the indicator flashes red), the ANC function is not available.

Connect the audio cable

Use the 3.5 mm cable (provided) to connect a nonwireless device or to charge the headphones when the battery is too low to turn on.

1) Insert the cable into the audio port on the right earcup.
2) Insert the other end of the cable into the audio port on your device.

Note:

- The headphones do not use the internal battery (headphones are off) when connected to the audio cable.
- The headphones will not charge when you use the audio cable is been.

Reset the headphones/Clear all pairing information on the headphones

1) Turn off the headphones and place and hold the MFB button for 5 seconds until the indicator flashes red and blue alternately.
2) Press and hold the MFB button and "+" button at the same time for 5 seconds you will hear two "beep" sounds with the indicator flashes red and blue alternately.
3) Headphones enter pairing mode (indicator flashes red and blue alternately).

Care and Maintenance

Store your headphones

- Use earcups fold for easy, convenient storage. Place the headphones into the carry case.

Notes:

- Make sure to power off the headphones when not in use.
- Before storing the headphones for more than a few months, make sure the battery is fully charged.

Clean the headphones

Your headphones may require periodic cleaning.

- Wipe the headphones with a soft cloth.
- Wipe the outside surfaces with a soft, dry cloth.
- Don't allow moisture to get inside the earcups or the audio input port.

FAQs

Q: I paired the headphones with my phone before, but I failed to connect to the headphones.

A: Turn off the Bluetooth of your phone or other "MY DEVICES", choose "HOT1 and tap ⓘ >> "Forget This Device".

Q: Why can't I pair?

A: Reset the headphones.
A: Put the headphones and your phone again following the instructions in the "Pairing" section.

Q: Headphones sound poor, sound cuts out.

A: Some phones auto for the setup of the wireless headphones or an audio output device before the sound is transmitted. Please refer to the instructions for your phone to fix this issue.

- Move your phone closer to the headphones and remove any interference or obstructions.
- Turn off other Bluetooth devices.
- If you use a music player or other devices, please make sure it supports A2DP stereo music profile.

Q: Sound is not stable and consistent.

A: Move your phone closer to the headphones to your phone (not away from your phone more than 23 feet, no obstacles between, and no walls or structures between).

Q: Battery life is shorter than expected.

A: Fully charge the headphones before first use. Sound will improve when the battery is sufficiently charged and the headphones are off. Please turn off the ANC function to extend battery life.

Q: My headphones will not switch on.

A: Check the headphones have enough battery left. Charge the headphones for at least 30 minutes before use. If they still, charged and still nothing happens, or if you have tried everything on this sheet, please contact our customer support for further information.

Specifications

Bluetooth Standard: V4.2

Wireless Profile: A2DP, AVRCP, HSP, A2MCP, SVC

Bluetooth Range: Up to 23 feet (10 meters) (No obstacles between)

Charging Time: 3.5 hours

Talk/Play Time:

- About 30 hours with ANC off
  (Varies according to volume level and audio content)
- About 15 hours with ANC on
  (Varies according to volume level and audio content)

Charging Current: 500mA

Charging Current 5V 500mA

Battery Capacity: 300mAh,3.7V

Working Temperature: -10 ~ +40 °

Attention

SAFETY AND WARRANTY

Important Safety Instructions

- Read all headphones and accessory safety and care and operation instructions before using your headphones when you are engaging in any activity that may be dangerous or hazardous.
- Stop using a pacemaker or other electrical medical devices, you should consult your physician before using the product.
- Do not use headphones while operating a motor vehicle or bicycle or other activities that require your full attention. This product is not a toy – never allow children to play with this product. Always store the product out of reach of children. Small parts are a choking hazard. Use of this product may cause choking hazard.
- Do not use headphones while operating a power tool, or a lawn mower or any the products, as this may cause short circuits which could result in a fire or electric shock.
- Some of the components can be replaced or repaired by using OEM, authorized dealers or service centers may cause the product. If any parts of the product are damaged or worn out, please stop using and contact your local dealer or distributor. Always use original OEM parts.
- Avoid exposing your product to heat and humidity to protect against damage to the product and its parts.
- Keep all products, cords, and cables away from operating machinery.

- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, stop using the product and contact your dealer.
- Do NOT use the headphones in water.
- Do NOT submerge the headphones in water. Do NOT expose the headphones to water, rain, or other liquids.
- Do NOT place the headphones while showering or bathing, or when participating in water sports, e.g., swimming, waterskiing, surfing, etc.
- Do not use headphones if you have a medical condition or your physician or dentist has might affect your implantable medical device.
- Leaving the product in hot or cold places, such as in a closed car in the summer or winter conditions, will reduce the capacity and lifetime of the battery.
- Dispose of the product according to local elements and regulations.
- Protect your hearing and your environment when using headphones:
  - Using the headphones while operating a motor vehicle, motorcycle, waterscooter or bicycle may be dangerous, and in illegal in some jurisdictions.Just as you would with any other audio device, be careful not to listen at high volume levels for extended periods. Exposure to high volume levels can cause permanent hearing damage. Listening at high volume levels for extended periods can be addictive. While engaging in any such activity, reducing the headphones from your ears or lowering the volume to a safe level may prevent hearing loss or any accident accident or injury. Do not take notes or read documents while driving.

WARRANTY

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes errors and omissions will occur.

We are happy to offer a 1-year hassle-free warranty to all our products as well as lifetime technical support and assistance. Please contact us if you have any questions about our devices.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in an residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.