1.字体颜色: 黑色 Pantone Black 3 C

2.单页尺寸: 140x144mm，（七折页）展开尺寸: 980x144mm

3.材质: 128G双铜，双面印刷

折页首页

Pet Water Fountain

User Manual Smart Edition

Please Read the User Manual Carefully Before Using the Product

01

Safety Instruction

1. It is not recommended to use the device for young pets less than three months old
2. When the product is used by children, please use it under the escort of parents.
3.Do not immerse the main unit part in water, it will damage the control panel and other electronic components.
4. Please keep the device placed horizontally, do not knock over the device to avoid damage.
5. If this equipment is malfunctioning or has damaged parts, please do not try to repair the equipment by yourself, you should contact your dealer or customer service to solve the problem.
6. Be sure to unplug the product when not in use or before cleaning it.
7. If the machine's power plug becomes wet, turn off the power at the outlet and do not attempt to unplug it.

Notice

1.Please clean the product before first use, see page P10 for cleaning guide.
2.Pure water is recommended to extend filter life and maintain water quality.
3. The ambient temperature for normal operation of this device is 0℃ ~ 40℃, please do not place the equipment in the place where it is exposed to the sun or where the ambient temperature does not match.
4.Do not let your pet chew or swallow any accessories. If you are worried about the power cord, please buy wire conduit (hard plastic protector) and protect the power cord at the hardware store.
5.If the equipment has faults or damaged accessories, do not try to disassemble or modify the water fountain by yourself. Contact the seller or customer service immediately and solve it,to avoid causing safety incidents.
6. Be sure to check the amount of water remaining in the water fountain if you are traveling for an extended period of time or on a business trip.
7.Please carefully read and follow all important instructions listed on the machine and package.

02

Packing List

After opening the product package, please confirm whether the machine is in good condition. Please check the list to confirm whether the accessories are complete.

Water Tank

Accessories



❶ Host + water pump ❷ Power Adapter ❸ Power Cable

❹ Filter Cotton ❺ User Manual

*In order to provide better products, we will regularly improve our products. please refer to the actual product.

03

Product Image

Front View



Bottom View

04

Button Description

Power button:
1) Press and hold the button: for 6 seconds, and the device will turn on with "did" sounds.
2) Press and hold the button: for 6 seconds, and the device will turn off with "did" sounds.
3) Pair network: double-click the button: for 3 seconds, the device will auto-enter low power mode. In this mode, long press the power button for 1 second to wake up the device.
Note:connecting the power adapter or also wake up the device.

Cleaning & filter reset button:
1) Cleaning reset: double-click the button: and the device will emit "did" sounds. The cleaning reminder, and filter replacement reminder will be restored to default values.
2) Filter reset: double-click the button: and the device will emit "did" sounds. The filter replacement reminder is reset successfully, and will re-enter the filter replacement reminder countdown.
Note: 1) If the device displays cleaning and filter replacement reminders at the same time, double-click the reset button and the device will reset the cleaning reminder first, and the filter reset function will be disabled.
2) The cleaning reminder starts counting down from the time the device is reset, and the default reminder is 7 days later (the default reminder time can be adjusted in the APP, 7-30 days).
3) The filter replacement reminder starts from the time the device is reset, and the default reminder is 30 days later (the default reminder time can be adjusted in the APP, 15-90 days).

Restore factory settings:
Press and hold the button: for 6 seconds,the device will beep for 6 seconds, then the device will be restored to factory settings. The network information will be cleared, water mode, cleaning reminder, and filter replacement reminder will be restored to default values.

Indicator light color	Indicator light signal	Device status
White	Slow flash	Pairing completed, restart power on/off
	Slow flash	Grid Failure Device Offline Device Charging
	Still on	Device normal, network successful, charging complete
Orange	Quick flash	Cleaning reminder
	Slow flash	Filter cartridge reminder
	Still on	Insufficient water
Red	Quick flash	Pump abnormal
	Slow flash	Equipment mains water
	Single flash	Overvoltage protection
	Still on	Water level detection abnormality

Note: 1) When the device is flashy faster shortage reminder, cartridge replacement reminder, cleaning reminder), the App will push the abnormal reminder information to the App. 2) When the device is flashy faster shortage reminder, cartridge replacement reminder, cleaning reminder), the pump of the water dispensing equipment to the power supply, the water mode default continuous water equipment for the battery powered, automatically switched to intermittent water.

05

Installation Instructions

01 | Cleaning equipment

① Take out the main unit and accessories firstly, and clean the water tray and water tank with clean water. Do not let water contact the main unit during cleaning. You can wipe it with a rag or wet wipes.

02 | Add water to water tank

① Add purified water or tap water, the amount of water must be within the specified range. (2~4L).

Note: Do not add water exceeding the MAX line.

03 | Install the water tray

① Place the water tray assembly onto the water tank.

06

04 | Install filter

① Place the filter in the groove of the water tray, with the convex surface facing down and the flat surface facing up.

05 | Install stainless steel water tray&main unit

① Place the stainless steel water tray on the water tray , and then place the main unit on the water tray assembly.

06 | Plug in

① Place the assembled device on a level surface, and finally use a DC5V power adapter to power the device.

07

折页尾页

Cleaning and Maintenance

1. For your pet's health, it is recommended to clean the water fountain regularly.
2. When the water tank starts to get dirty and has stick water, you need to clean it.
3. It is recommended to clean the water tank, water pump and filter cotton once in 7 days.
4. The filter cotton needs to be replaced regularly and it is recommended not to exceed 30 days.

Water Pump Description

The specifications of W04 smart water dispenser pump as follow:
Water pump specifications as follow:
Rated voltage: 5V
Working noise:00bm from the water pump): ≤42dB
Material: engineering plastic
Ambient temperature: 1~40℃
Ultraviolet sterilizer lamp: only optional Below for the location of the UV germicidal lamp.
Note:
1) The germicidal lamp cycles every 5 minutes and stays on for 5 seconds each time
2) The cleaning method: it be same with conventional water pump, for details, you can check P10 of the instruction manual.

Specification

Water tank capacity: 4L
Power supply: DC 5V/7A power adapter
Power adapter input: AC100-240V ,50/60Hz
Power adapter output: DC5V/1A
G.W.: 1.1skg
Size: 18.9*18*23.5cm
80-001-0

07

Instructions

01 | Installation

① Follow the instructions to complete the water filling and assembly.

02 | Connecting to the power supply

① Connect the 5V1A power adapter to the device and plug it into the socket.The device turns on automatically.

03 | Equipment network configuration

① Please check the PetTech APP download operation guide below

Please Select Device
Add Device
Add Device
Device Name
Device Name
Device Name