Y10001811--V1说明书（日语）-V1(20230725)
技术要求：
1.成型尺寸：125*215mm，风琴折；
2.材质：80g书纸，
3.印刷：单色 双面印刷 色彩准确，无套印不准等现象；
4.裁切整齐无毛边；
5.其他要求：产品需满足REACH法规及最新RoHS指令要求。
产品需满足欧可林《包装材料来料检验通用标准》。
6.公差：±1mm
7.标注单位mm

English

Oclean
Product User Manual

Oclean X Ultra WR1 Smart Sonic Electric Toothbrush
User Manual

▲ Important Safety Tips

This product is recommended for use by persons over 12 years of age
The product can only be used with Oclean replacement heads. We will not be responsible for any consequences resulting from the use of other brands of replacement heads.
This product is not permitted shipping only and is not recommended for medical purpose.
The product is for adult use only. Do not place the toothbrush under direct sunlight for a prolonged period of time. It is recommended to keep the product in a cool place with a temperature below 40°C.
Please keep the body dry before charging, dry it with a soft cloth, and clean the charging base with a dry cloth regularly to prevent the base from building up.

Brush head:
It is recommended the brush head, please pull out or insert it vertically, and do not rotate left or right
It is recommended by dentists to change the brush head every two to three months.

Attention should be paid for those with the following conditions of oral sensitivities:
Those who have recently undergone periodontal surgery or are undergoing treatments.
Individuals with other symptoms in the mouth including those with unstable dentures or have persistent heavy bleeding from the gums.
Those with severe periodontal disease or gum recession.
This product is not recommended for use with the above group or consult a professional dentist before use.

This product is not suitable for people with disabilities, mental illness or lack of relevant experience and knowledge (including children 12-16 years old), unless used under the supervision of their guardians.

Touch Screen:
Supports up and down scene controls, please swipe on the left and right side of the screen.

Google Play Oclean & iOS APP Store

Button When brush is awake, press the button would enter the cleaning mode. During the cleaning operation, the brushing would pause when pressed, press the button within 30 seconds again, the brushing would resume.
On the mean interface, press and hold the power button for 2 seconds to lock or unlock the screen; press and hold the button for 2 seconds to restore it to the factory mode.

▲ User Guide

First time use:
To turn on the toothbrush, press the power button, the toothbrush will enter standby mode after turning on, and Bluetooth and WR will remain on while the screen is lit. After the screen turns off, Bluetooth and WR will turn off automatically after 30 seconds of inactivity.

App Installation:
Scan the QR code to download the "Oclean Care +" app, then search for and connect to the toothbrush within the app. Note: connecting to the toothbrush through "Bluetooth settings" in your phone's system settings will not work.

App Connection:
On the home page of the app, click the top device picture to enter the "Device Information" page, then turn on "Automatic switch between cleaning modes" under "Function Settings" to allow the toothbrush to switch between "Sunrise Brushing" and "Sunset Cleansing" modes automatically.

Brushing Plan Settings:
After successfully binding the toothbrush to the app, fill in your dental information to receive recommended brushing plans that fit you the most. Alternatively, customize your own exclusive brushing plan by clicking "Exclusive Mode" on the "Sweep" page of the app.

Viewing Brushing Records on the App:
The toothbrush will record your brushing data during brushing if the toothbrush is connected to WR and bound to the app. Toothbrush data taking less than 15 seconds will not be saved. The toothbrush can store a maximum of brushing data (up to 7 days), so please connect the toothbrush to WR and synchronize the data with the app within 7 days.

Brushing:
Without any settings, the toothbrush will run in the "sensitive clean mode" by default, where strong alert will be given when the toothbrush runs for 2 minutes and will automatically stop running after 5 minutes of operation.

Charging the toothbrush:
Dry the toothbrush bottom before charging, and then insert the USB Cable on the charging base into an adapter. After that, you can place the toothbrush on the charging base. The charging base will automatically start charging the toothbrush. When it is fully charged, remove the toothbrush from the charging base in time. After brushing, please recharge it when the toothbrush alerts you. Its low battery status.

Automatic Wake-up:
The toothbrush in WR mode toothbrush will automatically wake up the screen.
If the toothbrush is automatically woken up multiple times in a row without brushing teeth, the user use will require pressing a button to wake it up. When the battery is low, lifting the toothbrush will not automatically wake up the screen.

▲ Scientific Guidance Program

Brush Activity Clever: The Brush Activity Clever realizes daily and cross-cycle-based-loop management. It records the number of brushing section every day (usually are required to brush their teeth at least twice a day), brushing time (brushing for more than 2 minutes each time), and brushing areas (divided into 16 areas). The Brush Activity Clever is a tool to help users develop good habits.

Sensitive Mode: The sensitive mode is a special brushing mode that can be activated when the gums or tooth surfaces. Therefore, when the toothbrush detects excessive or rapid lateral brushing, it will sound an alarm.

Reminder to brush the outback surface: The outback surface of molars is prone to cavities, so you need to pay special attention to brushing the area. The toothbrush will issue a prompt when detecting the brushing process to remind you to brush the outback surface.

Zone reminder: Brushing needs to cover all areas to effectively prevent dental problems. Therefore, during the brushing process, there will be a sound reminder to change areas after completing brushing in one area.

Low Battery Alert:
When the battery percentage is below 10%, an alert will pop up on the display of your toothbrush from time to time to indicate that the battery is low and it is time to charge the toothbrush. When the battery is seriously low, your toothbrush will be off and the toothbrush's motor will vibrate to alert you to charge the battery.

Put the toothbrush bottom on the charger to ensure that the toothbrush is upright and stamped in the charging base. In normal charging, the toothbrush will show the charging cap and battery percentage and be fully charged for about 5.5 hours.

Important Charging Alert:
As the electric toothbrush is provided with the fast charging mechanism, it is recommended to connect and charge the toothbrush when required. Don't put the toothbrush on the charger when charging is not required or if it is fully charged because leaving the fully charged toothbrush or charging for a long time may lead to premature depletion of the built-in battery, thus affecting the usage experience.

▲ Recommended Tooth Brushing Method

▲ Specifications

Product Name	Oclean X Ultra WR1 Smart Sonic Electric Toothbrush
Model	V8100
Weight	97.7
Charger	WR2 Wireless Charging Base
Input	5V⎓1A
Battery Life*	45 days
Battery Capacity	200 mAh
Charging Time	5.5 hours
Standard	GB/T18268-2010
Bluetooth	Bluetooth 4.2 above
IP	IPX7

* Using default mode. It is calculated at 2 minutes/time, 2 times/day working condition.

1. Do NOT disassemble, strike, extrude or throw the device into a fire.
2. Do NOT use the toothbrush if its battery is bulging or has expended.
3. Do NOT use the device if it is damaged or has expended.
4. Do NOT use the device if its battery has been subjected to immersion in water.

▲ FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) the device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ANSD-V8100

▲ CE WARNING

1. - The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
2. - Children being supervised not to play with the appliance.
3. Signal words WARNING, CAUTION, DANGER in uppercase having a height as specified : Uppercase letter of the text explaining the signal words shall be at least as high as the signal words. Included is a displayed marking either raised above or have a depth below the surface of at least 0.25 mm, unless:
4. This appliance contains batteries that are non-replaceable

Shenzhen Yunding Information Technology Co.Ltd
Shenzhen Yunding Information Technology Co.Ltd Shenzhen Center(Phase 2), No.16, Dachong 1st Road, Dachong Community, Yuanlai Street, Nanshan District,Shenzhen City, Guangdong Province, China
Website: www.oclean.com

▲ Warning

- When removing the battery, the product must be powered off.
After removing the battery, it should be safely disposed of.
Please ensure the product is fully charged before first use or after prolonged storage.
Before disassembling the product, the battery must be removed from the product according to the following steps:
1.Find blow the charging board with a Heat gun, and then pry the charging board along the edge of the bottom cover with tweezers.
2.Use a Heat gun to heat the edge of the bottom cover, and then pry the bottom cover with tweezers.
3.Use a metal to pry the clip on both sides inward and forwardly push the motor shaft until it comes out of the movement.
4.Use scissors to cut off the charging cable at the bottom of the battery, break open the clip, and remove the battery.

—The battery must be removed before the appliance is scrapped.
—The appliance must be disconnected from the supply mains when removing the battery.
—The battery is to be disposed of safely.

EU REP:	EU Authorised Representative Representative Agricolo Tenda	European Address Tobing,Q & Kaunas, Lithuania Representative Agricolo Tenda	Email service@tobiiEu Phone +37069782870 Post Code LT44237

Made in China

Facebook Page

www.facebook.com/oceanglobal
Follow the
Oclean Official Facebook Page
Download App

Google Play | App Store

FDA Registration Number: 3014246581

IPX7

日语

Warranty Certificate of Oclean Sonic Electric Toothbrush

User Information

Name: _____ Contact number: _____ E-mail: _____ ZIP code: _____

Address: _____

Retailer Information

Retailer: _____ Contact number: _____ Address: _____

Sales Date: _____ ZIP code: _____ Invoice No.: _____

Product Information

Product Type: _____ Manufacturing Site: _____

Warranty Card of Oclean Smart Sonic Electric Toothbrush

Delivery Date	Fault Description/Reason Disposal	Equipment employed	Acceptance date	Serviceman

Name of parts	Toxic and harmful substance or element							Environment Protection
	Pb	Hg	Cd	CrVI	PBBs	PBDEs	4 Phthalates	
PCBA	○	○	○	○	○	○	○	10 years
Plastic parts	○	○	○	○	○	○	○	5 years
Metal hardware	○	○	○	○	○	○	○	5 years

Name of parts	Toxic and harmful substance or element							Environment Protection
	Pb	Hg	Cd	CrVI	PBBs	PBDEs	4 Phthalates	
Vibrating motor	○	○	○	○	○	○	○	10 years
Accessories	○	○	○	○	○	○	○	
Battery	○	○	○	---	---	---	---	5 years

Remarks:
○: This indicates that the content of toxic and hazardous substances in all homogeneous materials of this component is less than the limited quantity as specified in RoHS 2.0 Directive 2011/65/EU & (EU) 2015/863.
×: This indicates that the content of toxic and hazardous substances in at least one of the homogeneous materials of this component is more than the limited quantity as specified in RoHS 2.0 Directive 2011/65/EU & (EU) 2015/863.
—: Refer to Battery Directive 2006 / 66 / EC and Ammendment 2013 / 56 / EC
: Except for very fine materials, due to technical development reasons, most of the homogeneous materials of this component. We ensure the continued use this product with confidence during the environmental protection period.

Oclean X Ultra WR1スマート音波電動歯ブラシ
ユーザーマニュアル

▲ 重要な安全情報

この製品は18歳以上の人が使用を推奨します
この製品はOcleanのリプレイスヘッドのみ使用できます。互換ブランドのヘッドによるすべての結果については責任を負いません。
この製品は輸入専用の販売品です。医療目的で使用することは推奨されません。
この製品は屋内専用です。直射日光に長時間当たらないようにしてください。一般的な温度と湿度が高く保存に適した40度以下の場所に保管することを推奨します。
本製品に水滴が残ると、長期間使用すると、汚れが付着する可能性があります。充電する前に、水滴を拭き取り、充電ベースを定期的に清潔な乾いた布で拭いてください。

ブラシヘッド：
ブラシヘッドを交換する場合は、垂直方向へ抜いて挿入してください。左右に回転しないでください。
歯科医師は2～3か月ごとにブラシヘッドを交換することを推奨します。

口腔内感覚に敏感な方は、次のような状況に該当する方は、使用前に歯科医または専門家にご相談ください。
—最近歯周組織の手術を受けたか、治療を進めている方。
—口腔内の歯ぐきの出血が、持続的に重大な方。
—歯ぐきの重度の歯周病や歯ぐきの後退がある方。

この製品は障害者や、精神疾患、精神状態の問題があるか、関連する経験や知識がない方（12歳～16歳の子どもを含む）は、保護者の監督の下で使用してください。

Google Play Oclean & iOS APP Store

電源：
電源ボタンを長押しし、動作中に電源ボタンを短く押すと一時停止します。再度30秒以内に押すと、停止が解除されます。
インターフェイスでボタンを長押しすると、画面のロックまたはロック解除ができます。
ボタンを2秒間長押しすると、ロックされたインターフェイスを工場モードに復元します。

▲ ご使用のガイド

初めての使用：
ボタンを押して電源をオンにすると、ボタンがスタンバイモードに切り替わります。電源がオンになると、Bluetooth、WRがオンのままになります。画面が消灯すると、Bluetooth、WRは30秒間の非アクティブ後に自動的にオフになります。

アプリのインストール：「Oclean Care+」アプリをダウンロードするには次のコードをスキャンします。その後、アプリの中で歯ブラシを検索して接続します。注意：携帯電話の「システム設定Bluetooth設定」で接続しても機能しません。

アプリの接続：
アプリのホームページで、「Oclean Care+」アプリを開いてから、「デバイス情報」ページに移動するには、ページの上部にある「デバイス」をクリックします。「機能設定」セクションで「機能モードの自動切り替え」をオンにすると、歯ブラシは自動で「朝の歯ブラシ」モードと「夜の歯ブラシ」モードを切り替えます。

ブラシプランの設定：
アプリに歯ブラシをバインドしたあとは、歯の情報を入力して、お勧めのブラシプランを受け取ります。あるいは、アプリの「スイープ」ページで「独自モード」をクリックして、ご自分専用のブラシプランをカスタマイズします。

アプリで歯磨き記録を表示する：
歯ブラシがWRに接続され、アプリにバインドされている場合、ブラシは歯磨きデータを記録します。15秒未満の歯磨きデータは保存されません。歯ブラシは最大7日分の歯磨きデータを保存できます。7日以内にWRに接続して、ブラシの歯磨きデータを同期してください。

歯磨きをする：
何も設定しない場合、ブラシはデフォルトで「敏感クリーンモード」を使用します。ブラシが2分間動きすぎると警告ランプが点灯します。5分間動きすぎると自動的に停止します。

歯ブラシの充電：
充電する前に、ブラシの底面を乾かし、USBケーブルを充電ベースに挿入します。充電ベースに入れると、Oclean歯磨きブラシのチャージが始まります。ブラシが完全に充電されたら、ブラシを充電ベースから取り出してください。歯磨きが終わったら、歯ブラシが動作しなくなったら、充電してください。

自動ウェイクアップ：
WR モードの歯ブラシは自動的に画面をウェイクアップします。
ブラシが連続して歯を磨かずに自動的に数回ウェイクアップした場合、ユーザーがボタンを押してウェイクアップする必要があります。
バッテリーが低い場合、歯ブラシを持ち上げても画面は自動的に起動しません。

▲ 科学的ガイドラインプログラム

ブラシ・ハビリ機能：ブラシハビリは、毎日（2回以上ブラシを歯磨く習慣をさせるためです）、ブラシ使用回数（1回ごとに歯磨き2分以上）、時間（1回ごとに歯磨き2分以上）、領域（16の領域に分割）を記録します。ブラシハビリは、ユーザーが良い習慣を身につけるのを助けるツールです。

敏感モード：敏感モードは、ユーザーが歯、歯ぐきの表面をブラッシングしているときに、ブラシが過度に強くまたは速くブラッシングしていることを検出すると、アラームを鳴らします。

奥歯の裏面を磨くリマインダー：奥歯は虫歯になりやすいため、特に注意して奥歯の裏面を磨く必要があります。歯ブラシが奥歯の裏面を検出すると、歯ブラシは奥歯の裏面を磨くようにリマインドします。

ゾーンリマインダー：歯を効果的に予防するためには、すべてのエリアをカバーするブラッシングが必要です。そのため、歯磨きプロセス中、1つのエリアを磨き終わったあとは、ゾーンを変えるようにリマインドします。

▲ 製品の基本仕様

製品名:	Oclean X Ultra WR1スマート音波電動歯ブラシ
ブランド名:	Oclean
型番:	V8100
防水レベル:	IPX7
定格入力:	5V⎓1A
バッテリー仕様:	1ヶ月フル充電(*)/ 5.5時間 (200mAh)
充電時間:	約5.5時間
本体重量:	97.7g
製造業者:	Shenzhen Yunding Information Technology Co., Ltd.
	Made in China
WR2ワイヤレス充電器	
定格入力:	5V⎓1A
重量:	約35g

(*) 使用状態：1回2分間、2回/日の使用条件で計算。

製造元：フローチーモデル株式会社
販売元：ボイテック株式会社
お問い合わせ先：プラスチャイルド有限会社
TEL:0120-956-952(通話無料)
E-mail production@kosi.co.jp
営業時間：10:00～17:00(祝日及び土日を除く)

▲ 保証書

製品名		お客様のお名前	
お客様のご住所		ご購入販売店名称	
		保証期間	お買い上げ日から2年間
お買い上げ日	年　月　日	販売担当	㊞

お客様控え（切取シールを貼り直因）

製品名：
ご購入販売店名：
お客様のご住所：
お買い上げ日：
販売担当：
保証期間：

保証内容：
1. 本製品の保証期間は、お買い上げ日から2年間です。保証期間内に、通常の使用状態で故障が発生した場合、当社が無償で修理または交換を行います。
2. 保証期間内であっても、次の場合は有償修理となります。
(1) 誤使用や不適切な修理・改造による故障・損傷
(2) 本製品の購入日から2年を経過した場合
(3) 本製品の購入日を証明する書類（保証書・領収書・請求書・納品書・レシート等）の提示がない場合
(4) 本製品の購入日が、本製品の製造年月日から1年を経過している場合
(5) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態を超えていると当社が判断した場合
(6) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(7) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(8) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(9) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(10) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(11) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(12) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(13) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(14) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(15) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(16) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(17) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(18) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(19) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(20) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(21) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(22) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(23) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(24) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(25) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(26) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(27) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(28) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(29) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(30) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(31) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(32) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(33) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(34) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(35) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(36) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(37) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(38) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(39) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(40) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(41) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(42) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(43) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(44) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(45) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(46) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(47) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(48) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(49) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(50) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(51) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(52) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(53) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(54) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(55) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(56) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(57) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(58) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(59) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(60) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(61) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(62) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(63) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(64) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(65) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(66) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(67) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(68) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(69) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(70) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(71) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(72) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(73) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(74) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(75) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(76) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(77) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(78) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(79) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(80) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(81) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(82) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(83) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(84) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(85) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(86) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(87) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(88) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(89) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(90) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(91) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(92) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(93) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(94) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(95) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(96) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(97) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(98) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(99) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合
(100) 本製品の購入日が、本製品の製造年月日から1年を経過していない場合で、本製品の使用状態が、通常の使用状態であると当社が判断した場合

Instruction for E-label

- Instruction to find the e-label in the FQA:

1. Lift up the toothbrush, the screen will be automatically awake and lights up for 15.
2. Slip up and down to select any mode and hold for 15. The firmware version will be displayed on the button.
3. Slip up and down to switch to E-label screen and the E-label can be checked by user.

The certification logo will be displayed immediately in the screen of the device .
Before the device display the certification logo , the wireless transfer will not start.
After entering into the E-label screen ,the user do not have the entrance to enter and change the identification logo as the contents of the E-label is encrypted.

E-Label display as below figure:

CMIIT ID: 2023DP11889
R: 218-23812
CCAK23LP1380T1
FCC ID: 2ANSD-V8100
FDA Registration Number: 3014246581
Made in China
IPX7
Model V8100
FW V1.x.x.x
Made in China