PROMATE®
Innovation and Excellence

PROMATE.net

PROMATE®
Innovation and Excellence

Acoustic In-Ear TWS Earphone

Lush

User Guide

English

Introduction

Experience aesthetic design and acoustic audio quality with Lush TWS earphones. The composite speakers deliver crisp audio with balanced bass. Lightweight and compact, Lush is perfect for use indoors or on the move.

Packaging Contents

- Lush
- Charging case
- User guide
- USB Charging Cable
- Additional Ear Buds

Specifications

- **Bluetooth Version:** v5.3
- **Bluetooth Profiles:** HSP / HFP / A2DP /AVRCP/AAC
- **Chipset:** JL-AC6973D4
- **Earbuds Input:** 5V/40mA
- **Charging Case Input:** 5V, 260mA,
- **Impedance:** 32 Ω
- **Frequency Range:** 100Hz-10kHz
- **Charging Time:** 2 Hours
- **Playing Time:** 5 Hours
- **Earphone Battery Capacity:** 40mAh
- **Charging Case Battery Capacity:** 230mAh
- **Battery Type:** Li-polymer
- **Operating distance:** 10m

CE DECLARATION OF CONFORMITY

English

Features

- **Superior Connectivity:** Revel in the freedom only true wireless connection can provide and enjoy an ultimate hands-free experience
- **Charging Case:** The compact charging base enables you to store the earphones and charge them
- **Long-Lasting Connectivity:** With up to 19 hours of playback time, Lush will get you through your longest days
- **Intellitouch Control:** Manage audio playback with full-function touch controls.
- **Water Resistant:** The sweat and water-resistant design makes Lush a perfect companion on your active adventures

Compatibility

Lush can be paired to all Bluetooth-enabled devices.

Precautions

Please read all safety instructions and warnings thoroughly before using this product. Improper use of this product may result in damage to this or attached products.

1. Do not disassemble the product or attempt to fix it.
2. Do not attempt to replace any part of this product or battery inside.
3. Do not crush, puncture, dispose of in fire, short the contacts or expose the product to water or other liquids.
4. Do not store or use the product in a high-temperature environment, including intense sunlight or heat.
5. Avoid drops, bumps, abrasions and impacts.
6. If there is any reason to believe there is damage to the product, discontinue use immediately.
7. If you find that the product is too hot, is emitting an odour, is deformed, punctured or exhibits any suspicious or abnormal behaviour, discontinue use immediately and contact our customer service.

English

Appearance & Interface Description

1. Earphone LED Indicator
2. TouchPoint
3. Microphone
4. Charging Case Battery Indicator
5. Charging Input



Operation Instructions

1. **Automatic Power On/Off:**
   - Open the charging case and remove the earbuds to power on or press the touchpoint for 2 seconds to turn on the earphone.
   - Put the earbuds back in the charging case to power off or press the touchpoint for 5 seconds to turn off the earphone.
2. **Headphone Pairing:**
   - Teeny automatically enters into pairing mode once removed from the charging case.
   - Search the earbuds on the Bluetooth list of your phone to connect for the first time.
   - The earbuds will pair automatically to the last paired device when taken out of the charging case.

English

3. **Call Function:**
   - Press the touchpoint on the left/right earbud to answer calls.
   - Double press the touchpoint on the left/right earbud to answer or end calls.
   - Press and hold the touchpoint on the left/right earbud for 2 seconds to reject an incoming call.
4. **Music Controls:**
   - Press the touchpoint on the left ear while playing music to play/pause.
   - Double press the touchpoint on the right earbud to play the previous track.
   - Double press the touchpoint on the left earbud to play the next track.
5. **Charging Lush:**
   - Place the earbuds inside the charging case with contact points touching the charging contact perfectly.
   - Connect the USB cable to the charging case to begin charging.
   - The charging case indicator starts flashing green when charging and turns solid green when fully charged.
   - The charging case indicator turns solid red when charging the earphone and turns off once the earphones are fully charged.

Voice Assistant

- Long press the touchpoint for 3 seconds to activate the voice assistant function on your connected device.

English

Correct disposal of this Product
(Waste Electrical & Electronic Equipment (WEEE)
Your product is designed and manufactured with high quality materials and components which can be recycled and reused.This symbol means that electrical and electronic equipment, at their end of-life should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/recycling center.

CE

This product complies with European safety and electrical interference directives

RoHS

This product does not contain environmentally hazardous materials (lead, mercury, cadmium, hexavalent chromium and brominated flammable agents: PBB and PBDE).