210mm

maxpower

USER MANUAL

MPD155XB

PROFESSIONAL SPEAKER

PLEASE READ THIS USER MANUAL CAREFULLY BEFORE SYSTEM CONNECT

FCC ID: 2BBFBMPD155XB

MADE IN CHINA

IMPORTANT SAFETY MEASURES

Before using this machine, please read all the safety and operating instructions, meanwhile, please observe all the indications about safe operating. These safety and operating instructions should be kept in condition of consultation.

1. Protection of electric power supply line: Be aware that the electric power supply line is not tramped, pressed by heavy objects. Pay special attention to the plug of power supply line and outlet connection place. DO NOT put the machine near the fire, DO NOT put the machine near the water.
2. Ventilation: This set must be put in ventilated place. DO NOT put disk on it or cloth to cover it. The distance away from the wall should not be less than 10 centimeters. DO NOT put this set on the bed, sofa, carpet or other objects with similar surface in case of good ventilation.
3. Casing Dismantling: DO NOT dismantle the casing. If one touches the inner components, he will bear the responsibility for damage.
4. Unusual smell: When you discover unusual smell and smoke, cut power supplies immediately and pulls out the plus from the outlet on the wall. Contact the sell shop or nearest repairing center.

Attention: This set applies to AC 110V / 50Hz~60Hz power supply. Use standard power supply. Please be sure for te correct power supply before use it.

PRODUCT FEATURES

1. High output power.
2. With Karaoke function.
3. The treble is clear, natural and bass is powerful.
4. Compatible to DVD/VCD/CD/TAPE/MP3/MP4/AUX.

FRONT PANEL FUNCTION INSTRUCTION

PANEL FUNCTION

① ***MODE***: LINE(Audio input) button
REC: recording.
LED MODE: LED light adjustment.
USB: USB port disconnected
② ***PREV***: play key.
NEXT: play key.
SCAN/TWS: play key.
RPT: repeat key.
③ ***MASTER VOLUME***: control knob.
④ ***CARD***: slot.
M.BASS: control knob.
M.MID: control knob.
M TREBLE: control knob.
M.ECHO: control knob.
M.DELAY: control knob.
M.MUSIC: control.
⑤ ***EQUALIZER.***
⑥ ***POWER ON/OFF SWITCH.***
⑦ ***MICROPHONE1 & MICROPHONE 2***: input jack.
MIC VOLUME: -10db/+10db adjust key
AUDIO: input jack.
⑧ ***MIC VOLUME***: control knob

REMOTE CONTROL

WIRELESS USE INSTRUCTION

Change the mode into "OPEN", the wireless sign light twinkles, and speaker have sound "di". Set on mobile phone, connect to wireless data, search equipment and match properly. The proper connect wireless lights keep on, and music work on speaker normally.

BACK PANEL FUNCTION INSTRUCTION

1. AUDIO INPUT: DVD/TV or other AUX AV player audio signal input jack.
2. Switch for AUDIO INPUT, and switch for LED.
3. AC input: AC115V.

USE INSTRUCTION

1. Connect the signal cables according to the back panel connection instruction.
2. To sure the correct the voltage, insert electronic source cable, turn on the power switch button.
3. Adjust function keys to your satisfied best sound effect.

TWS CONNECTION

In wireless mode, press the TWS button and hold it down for three seconds, the primary speaker will sound an alarm and the screen will show "BTST". The secondary speaker switch to wireless mode will automatically connect to the primary speaker, and the screen will show "BT".

BACK PANEL CONNECTION DIAGRAM


Plug fully side to correct fuel, but still still
Unplug fuel out of the fuel socket
AC115V/60Hz
AC115V/60Hz
Fuse
Fuse
Fuse