包装信息	型号：E2 Gen2 成品尺寸：140*185MM 材质：80g书写纸，骑马钉 公差：不大于±1MM 工艺：四色印刷 版本号：V1.0-20240625	备注信息	封面背面留白

封底　　封面

Model No.: E2 Gen2

maono Global Best Selling Internet Microphone

Maono(maono)官方店
Download App to get more exclusive offers

Download App to get more exclusive offers

Technical Support
support@maono.com
www.maono.com

Made in China

Maono Technology Co., Ltd. (Shenzhen) All rights reserved.

maono
Global Best Selling Internet Microphone

Maono(maono), meaning 'vision' in Kiswahili, is the Global Best Selling Internet Microphone Brand that products are sold well in 153 countries worldwide. With the beautiful vision of becoming a leading global brand, Maono always offers products that deliver a pleasant sound experience. Maono is always working with audio professionals, influencers, and users, to make the world's best microphones and audio products.

User Manual
PODCASTING CONSOLE

maonocaster

Thanks for choosing Maonocaster E2 Gen2 podcast console.
Please read the User Manual carefully to have a better using experience.

CONTENTS

English 01-12
Deutsch 13-23
中文 24-34
日本語 35-46

Description

The Maonocaster E2 Gen2 is an upgraded version of our popular podcast and streaming audio console. Its 60-mm motorized faders provide smooth and precise control over audio levels, ensuring a seamless mix. The console boasts advanced functionality, including Bluetooth connectivity for wireless audio streaming and a dedicated Bluetooth DSP for enhanced audio performance. It also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). The console's versatile connectivity options include USB-C ports for computer connection and a 3.5mm TRRS interface for smartphone or tablet connection.

Product Features

- Dual AUX channels for easy mix-minus
- Internal and AUX buses to send your content
- Bluetooth connectivity for wireless audio
- Bluetooth MIDI and Bluetooth DSP for enhanced control and performance
- Motorized faders for smooth and precise control
- Advanced noise suppression algorithm for stress-ended voice
- Dedicated hardware buttons for muting microphones and sound effects
- USB-C for easy connection with computers and mobile phones
- Compatible with Windows and macOS
- Supports 48V phantom power for condenser microphones
- USB Phantom power support for XLR mic cable
- Supports 3.5mm headset mic and monitor jack

Applications

Podcasting, Audio Streaming, Online Meetings, Computer, Gaming, Live Broadcasting, Karaoke, Instruments recording and Voice-over recording and Mixing software.

Specification

Input Sensitivity	18dB	Mixing Type	4-Mono
Input Impedance	2.2KΩ	Mixing Mode	4-Stereo
THD	0.03%(1kHz)	Frequency Response	20Hz-20kHz
Headphone Power	40mW (32Ω, 1kHz, 1% THD)	Channel Sep.	70dB
Headphone Jack	3.5mm TRS	Phantom Power	48V
Channel Connection	Bluetooth, USB-C	Bluetooth Version	Bluetooth 5.0 (Support A2DP and AVRCP profile)

Accessory List

Maonocaster E2 Gen2 Console　　Mono Mic Audio Cable
USB-C(M) to USB-C(M) 1.1*1000　　User Manual

Layout

1. XLR Input 1 (Microphone Input)
Connect to an XLR microphone using a microphone cable.
2. XLR Input 2 (Microphone and Instrument Input) and High-Z Switch
Connect to an XLR microphone or instrument using a microphone cable.
Slide to turn on the High-Z mode when using an instrument (such as a guitar) or an acoustic or electric guitar.
3. 3.5mm Line Input
Connect to an audio source such as a mixer, smartphone, or tablet using a 3.5mm TRS cable.
4. Backlight Switch
Press to toggle the console's backlight between off, low, and high brightness.
5. Bluetooth Pairing Button
Press and hold to enter Bluetooth pairing mode.
6. 3.5mm Headphone Jack
Connect headphones or earbuds using a 3.5mm TRS or TRRS plug. Please note that the microphone input of headsets will not supported. The headset microphone function is not supported.

7. Headphone Volume Knob
Adjust the headphone volume.
8. Mic Volume Knob
Adjust the volume of the microphone.
9. Mute Button
Press to mute the microphone.
10. 3.5mm Headphone Jack
Connect headphones or earbuds using a 3.5mm TRS or TRRS plug. Please note that the microphone input of headsets will not supported. The headset microphone function is not supported.

11. USB-C Port (Sub Mix_1, Fader_1, and Mute_1)
Connect to a computer using a USB-C cable.
Plug into a USB-C port on your phone to use it as a microphone for live gaming, which may cause a slight delay.
Also supports Bluetooth MIDI.
12. Bluetooth Switch
Toggle the switch to activate the connect of wireless/wired note-taking recorder.
13. USB-C Phantom Power Switch
Please ensure that corresponding off/ switch for condenser microphones, as they typically require phantom power to operate. Connecting a microphone without phantom power may result in low or no audio output. Avoid damage to your microphone, it is crucial to keep the port on smartphone/pc/pad, DJ, Dj controller, etc. Phantom power is not supported.
Note:Maono XLR condenser microphones include: PD200, PD300, PM400, AD400.
Dynamic microphones do not require phantom power, including models such as: PD400, PD500, PD600, AD600.
14. Channel
Switch between the frequency response of the microphone and instrument inputs, allowing you to tune or record your instrument using the console's EQ.
15. Pad
Activate the pad to reduce input channel level to prevent distortion when using high-output devices.
16. Bluetooth Switch
Toggle the switch to activate the connect of wireless/wired note-taking recorder.
17. Bluetooth Button
The Maonocaster E2 Gen2 contains cases with eight-colored sound effect buttons. Users can record their own sound effects and assign them to these buttons. The console also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). Refer to the manual regarding recording and assigning sound effects to buttons. Note: Sound effects cannot be recorded from the microphone.
Note:Pad channel does not have processed control sound effects and needs to be recorded by the computer.
18. Recording and Playback
Press and hold to start recording the sound effects assigned to each button. Release to stop recording. Once you have recorded your sound effects and needs to be recorded by the computer, press the corresponding button to play the recording.
19. Channel and Pad Mixing
Regardless of whether there are sounds effect stored in the current bank or not, the previously recorded sound effects will be mixed with the channel input. The channel input can be adjusted using the console's faders, ensuring a balanced mix between the channel input and sound effects.
20. Bank Switch
Press and hold the bank switch button to enter the bank mode. Release the button to exit the bank mode. Use the sound effect buttons to select from the bank options and the 3D knob. Please consult detailed instructions in the manual.

21. 3D Knob
Rotate the knob to adjust the pitch of the sound effect. Press the knob to activate the pitch shift function. Rotate the knob to adjust the pitch of the sound effect. Press the knob to activate the pitch shift function.
22. 3.5mm Headset Jack
Connect headphones or earbuds using a 3.5mm TRRS plug.
23. Pitch Knob
Rotate the knob to adjust the pitch of the sound effect.
24. Speech Knob / Sub Mix Knob(Sub mix)
Rotate to control the strength of the speech effect. Turn it all the way to the left to turn off the vocals. Rotate to adjust the Sub Mix channel volume.
25. Volume
Rotate to adjust the frequency response of the microphone and instrument inputs, allowing you to tune or record your instrument using the console's EQ.
26. Fully Knob
Rotate to adjust the level of the sound effect.
27. Bluetooth Button
The Maonocaster E2 Gen2 contains cases with eight-colored sound effect buttons. Users can record their own sound effects and assign them to these buttons. The console also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). Refer to the manual regarding recording and assigning sound effects to buttons. Note: Sound effects cannot be recorded from the microphone.
28. Fader
Note:Pad channel does not have processed control sound effects and needs to be recorded by the computer.
29. Fully Knob
Rotate to adjust the level of the sound effect.
30. Bluetooth Button
The Maonocaster E2 Gen2 contains cases with eight-colored sound effect buttons. Users can record their own sound effects and assign them to these buttons. The console also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). Refer to the manual regarding recording and assigning sound effects to buttons. Note: Sound effects cannot be recorded from the microphone.
31. Pad Knob
Rotate to adjust the level of the sound effect.
32. Bluetooth Button
The Maonocaster E2 Gen2 contains cases with eight-colored sound effect buttons. Users can record their own sound effects and assign them to these buttons. The console also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). Refer to the manual regarding recording and assigning sound effects to buttons. Note: Sound effects cannot be recorded from the microphone.
33. Pad Knob
Rotate to adjust the level of the sound effect.
34. Bluetooth Button
The Maonocaster E2 Gen2 contains cases with eight-colored sound effect buttons. Users can record their own sound effects and assign them to these buttons. The console also supports Bluetooth MIDI, allowing for compatibility with various digital audio workstations (DAWs). Refer to the manual regarding recording and assigning sound effects to buttons. Note: Sound effects cannot be recorded from the microphone.
35. Pad Knob
Rotate to adjust the level of the sound effect.
36. Direct Monitoring Switch
Toggle the switch to activate the direct monitoring function. Note: Direct monitoring does not support the Bluetooth connection.
37. Headphone Level
Adjust the headphone volume.
38. Output Level
Adjust the overall output level of the console (TRRS headset).
39. Level Meter Display
Displays the overall output level. To enhance the sound quality, keep the level meter of the output level within the green range whenever possible. If the level meter turns red, it indicates potential clipping, which may result in distortion.

Setup Guide

1. PC Connection

1. Connect your microphones, headphones, and any other required devices as shown in the above diagram.
2. Use the provided USB-C to USB-A data cable or a 3.5mm TRRS to TRRS cable to connect the Maonocaster console to your computer.
3. Ensure the console's backlight is on. If it is not, press the backlight button to activate it.
4. Open your computer's sound settings and select the Maonocaster console as the default audio input and output device.
Note: Connecting your Maonocaster console to a laptop or desktop with a 3.5mm TRRS cable allows connecting your microphone to the console's XLR input.

2. Smartphone or tablet connection



1. Connect your microphones, headphones, and any other required devices as shown in the above diagram.
2. Use the provided USB-C to USB-C data cable or a 3.5mm TRRS to TRRS cable to connect the Maonocaster console to your smartphone or tablet.
3. Ensure the console's backlight is on. If it is not, press the backlight button to activate it.
4. Open your phone's settings and select the Maonocaster console as the default audio input and output device.
Note: Connecting your Maonocaster console to a laptop or desktop with a 3.5mm TRRS cable allows connecting your microphone to the console's XLR input.

3. Bluetooth Connection

This Maonocaster supports Bluetooth music playback. Please follow these steps to connect and play music:
1. Ensure your console is powered on and activate Bluetooth pairing mode.
2. Open your phone's Bluetooth settings and select "Maonocaster E2 Gen2" from the list of available devices.
"Maonocaster E2 Gen2" will now be connected.
3. Open your music app and start playing music.
4. Play your desired music on your phone.
5. Mute your Channel, use Fader1 controlling or controlling
Note:
The Bluetooth Switch is used for the console's pairing mode. Please refer to the manual for other functions.

4. Charging

1. Before using the device for the first time, please ensure it is fully charged.
2. To extend the battery life, it is recommended to charge the device once every month and fully charge it.
3. Please ensure the device is off during charging.
4. Charging time: 4-5 hours.
5. If you are using the device frequently, it is recommended to charge it at least once every months.
6. Avoid using the device while it is charging.
7. Do not charge the device for more than 24 hours.
8. Please unplug the device after it is fully charged.
9. Please ensure the ambient temperature is within the range of 0°C to 45°C for optimal charging efficiency.
10. Use only the provided charging cable and adapter to charge the device.
11. Regularly clean the charging ports to ensure a stable connection.
12. Avoid exposing the device to extreme temperatures, direct sunlight, or moisture during charging.

5. Troubleshooting

1. No sound from the microphone:
1.1 Please check if the microphone is muted.
1.2 Please check if the microphone is connected to the console.
2. No sound from accompaniment mode:
2.1 Please check if the accompaniment device is connected to the accompaniment interface of the console.
2.2 Please check if the accompaniment device is set as the default output device.
2.3 Please check the volume of the accompaniment device.
3. Bluetooth connection issue:
3.1 Please ensure your Bluetooth device is within a distance of 10 meters from the console.
3.2 Please ensure your Bluetooth device is set to "Maonocaster E2 Gen2" in the Bluetooth settings.
4. Microphone Noise:
4.1 Please ensure the microphone is not too close to the console.
4.2 Please check whether the microphone is connected properly to the interface on the console.
4.3 If the noise persists, please contact our customer service team for assistance.

1. Please check whether the "Control Panel" of the sound card operates. You can probably increase the volume of the microphone.
2. Please check whether the "Control Panel" of the sound card operates. You can probably increase the volume of accompaniment audio.
3. Please check whether the "Control Panel" of the sound card operates. You can probably increase the volume of the Bluetooth audio.
4. Please check whether the "Control Panel" of the sound card operates. You can probably increase the volume of the microphone.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

IC Warning

This device complies with Industry Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
Cet appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son fonctionnement est soumis aux deux conditions suivantes:
(1) cet appareil ne doit pas causer d'interférence et
(2) cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Beschreibung

Das Maonocaster E2 Gen2 ist eine verbesserte Version unseres beliebten Podcast- und Streaming-Audiokonsolen. Dank der 60-mm-Motorfadern bietet sie eine präzise und reibungslose Kontrolle über die Audiopegel, um einen nahtlosen Mischvorgang zu gewährleisten. Die Konsole verfügt über fortschrittliche Funktionen, einschließlich Bluetooth-Konnektivität für kabellose Audiostreaming und einen dedizierten Bluetooth-DSP für verbesserte Audioleistung. Sie unterstützt auch Bluetooth MIDI, was die Kompatibilität mit verschiedenen digitalen Audio-Workstations (DAWs) ermöglicht. Die vielseitigen Konnektivitätsoptionen der Konsole umfassen USB-C-Anschlüsse für den Anschluss an einen Computer und einen 3,5mm TRRS-Anschluss für Smartphone oder Tablet.

Produktfunktionen

- Dual AUX Mischvorrichtungen für einen Mix-Minus
- Interne und AUX-Busse zum Senden Ihrer Inhalte
- Bluetooth-Konnektivität für kabellose Audio
- Bluetooth MIDI und Bluetooth DSP für verbesserte Steuerung und Leistung
- Motorisierte Fader für reibungslose und präzise Steuerung
- Fortschrittlicher Algorithmus zur Rauschunterdrückung zur Verbesserung von Sprachaufnahmen
- Dedicated Hardware-Tasten zum Stummschalten von Mikrofonen und Soundeffekten
- USB-C für einfachen Anschluss an Computer und Mobiltelefone
- Kompatibel mit Windows und macOS
- Unterstützung von +48V Phantomspeisung für XLR-Kondensatormikrofone
- USB-Phantomspeisung unterstützt XLR-Mikrofonkabel
- Unterstützung für 3,5mm Headset-Mikrofon und Monitorbuchse

Anwendungen

Podcasting, Streaming, Online-Meetings, Computer, Spiele und Smartphones, Karaokeboxen und Sprachaufnahmen und Mixsoftware.

Spezifikation

Eingangsempfindlichkeit	18dB	Mischung	4-Mono 4-Stereo
Eingangsimpedanz	2.2kΩ	Mischmodus	
THD	0.03%(1kHz)	Frequenzgang	20Hz-20kHz
Kopfhörerleistung	40mW (32Ω, 1kHz, 1% THD)	Leitungsübersprechen	70dB
Kopfhörerbuchse	3.5mm TRS	Phantomspeisung	48V
Verbindungsmodus	Bluetooth, USB-C	Bluetooth-Version	Bluetooth 5.0 (Unterstützung für A2DP und AVRCP Profil)

Zubehörliste

Maonocaster E2 Gen2 Mischpult Konsole　　6.35mm TRS Mono Audiokabel
USB-C(M) zu USB-C(M) 1.1*1000　　Bedienungsanleitung

Layout



1. XLR Eingang 1 (Mikrofoneingang)
Anschluss an ein XLR-Mikrofon mit einem Mikrofonkabel.
2. XLR Eingang 2 (Mikrofon- und Instrumenteneingang) und High-Z Schalter
Anschluss an ein XLR-Mikrofon oder ein Instrument mit einem Mikrofonkabel.
Schalten Sie den High-Z-Modus ein, wenn Sie ein Instrument (z. B. eine Gitarre) oder eine akustische oder elektrische Gitarre verwenden.
3. 3.5mm Line Eingang
Anschluss an eine Tonquelle, z. B. ein Mischpult, ein Smartphone oder ein Tablet, mit einem 3.5mm TRS-Kabel.
4. Hintergrundbeleuchtungsschalter
Drücken Sie die Taste, um die Hintergrundbeleuchtung des Bedienfeldes zwischen aus, niedrig und hoch umzuschalten.
5. Bluetooth-Kopplungstaste
Halten Sie die Taste gedrückt, um den Bluetooth-Kopplungsmodus zu aktivieren.
6. 3.5mm Kopfhörerbuchse
Anschluss an Kopfhörer oder Ohrhörer mit einem 3.5mm TRS- oder TRRS-Stecker. Bei dem angeschlossenen Headset wird das Mikrofon nicht unterstützt. Die Headset-Mikrofonfunktion wird nicht unterstützt.

7. Kopfhörerlautstärkeregler
Einstellung der Kopfhörerlautstärke.
8. Mikrofonlautstärkeregler
Einstellung der Mikrofonlautstärke.
9. Mikrofon-Stummschaltung
Drücken Sie die Taste, um das Mikrofon stummzuschalten.
10. 3.5mm Kopfhörerbuchse
Anschluss an Kopfhörer oder Ohrhörer mit einem 3.5mm TRS- oder TRRS-Stecker. Bei dem angeschlossenen Headset wird das Mikrofon nicht unterstützt. Die Headset-Mikrofonfunktion wird nicht unterstützt.

11. USB-C Port (Sub Mix_1, Fader_1, und Mute_1)
Anschluss an einen Computer mit einem USB-C-Kabel.
Stecken Sie das USB-C-Kabel in einen USB-C-Anschluss Ihres Telefons, um es als Mikrofon für Live-Gaming zu verwenden, was eine leichte Verzögerung verursachen kann.
Unterstützt auch Bluetooth MIDI.
12. Bluetooth-Schalter
Schalten Sie den Schalter um, um die Verbindung zu drahtlosen/kabelgebundenen Notizenrekorder zu aktivieren.
13. USB-C Phantomspeisungsschalter
Bitte sicherstellen Sie die Ein/Aus-Schaltung für Kondensatormikrofone, da sie typischerweise Phantomspeisung zum Betrieb benötigen. Der Anschluss eines Mikrofons ohne Phantomspeisung kann zu geringer oder keiner Audioausgabe führen. Vermeiden Sie Schäden an Ihrem Mikrofon, es ist wichtig, den Anschluss an Smartphone/PC/Pad, DJ, Dj-Controller usw. aufrechtzuerhalten. Phantomspeisung wird nicht unterstützt.
Hinweis: Maono XLR-Kondensatormikrofone umfassen: PD200, PD300, PM400, AD400.
Dynamische Mikrofone benötigen keine Phantomspeisung, einschließlich Modellen wie: PD400, PD500, PD600, AD600.
14. Kanal
Wechseln Sie zwischen den Frequenzgängen des Mikrofons und des Instrumenteneingangs, um Ihr Instrument mit dem Mischpult zu stimmen oder aufzunehmen.
15. Pad
Aktivieren Sie das Pad, um den Eingangskanalpegel zu reduzieren, um Verzerrungen bei hohen Ausgangspegeln zu verhindern.
16. Bluetooth-Schalter
Schalten Sie den Schalter um, um die Verbindung zu drahtlosen/kabelgebundenen Notizenrekorder zu aktivieren.
17. Bluetooth-Taste
Die Maonocaster E2 Gen2 besitzen acht farbcodierte Soundeffekttasten. Benutzer können ihre eigenen Soundeffekte aufnehmen und diese den Tasten zuweisen. Das Mischpult unterstützt auch Bluetooth MIDI, was die Kompatibilität mit verschiedenen digitalen Audio-Workstations (DAWs) ermöglicht. Lesen Sie das Handbuch, um Soundeffekte aufzunehmen und den Tasten zuzuweisen. Hinweis: Soundeffekte können nicht vom Mikrofon aufgenommen werden.
Hinweis: Der Kanal des Pad-Kanals verfügt nicht über verarbeitete Soundeffekte und muss vom Computer aufgezeichnet werden.
18. Aufnahme und Wiedergabe
Halten Sie die Taste gedrückt, um die Soundeffekte, die jeder Taste zugewiesen sind, aufzunehmen. Lassen Sie die Taste los, um die Aufnahme zu beenden. Sobald Sie Ihre Soundeffekte aufgenommen haben, müssen sie vom Computer aufgezeichnet werden. Drücken Sie die entsprechende Taste, um die aufgezeichnete Aufnahme abzuspielen.
19. Kanal- und Pad-Mischung
Unabhängig davon, ob gespeicherte Effekte in der aktuellen/ausgewählten Tasten gespeichert sind oder nicht, können die zuvor aufgezeichneten Soundeffekte mit dem Kanaleingang gemischt werden. Der Kanaleingang kann mit den Fadern des Mischpults eingestellt werden, um eine ausgewogene Mischung zwischen dem Kanaleingang und den Soundeffekten zu gewährleisten.
20. Bankschalter
Halten Sie den Bankschalter für den Zugang zum Bankmodus gedrückt. Lassen Sie die Taste los, um den Bankmodus zu verlassen. Verwenden Sie die Soundeffekttasten und den 3D-Knopf, um aus den Bankoptionen zu wählen. Bitte konsultieren Sie die detaillierten Anweisungen im Handbuch.



21. 3D-Knopf
Drehen Sie den Knopf, um die Tonhöhe des Soundeffekts zu ändern. Drücken Sie den Knopf, um die Tonhöhenverschiebungsfunktion zu aktivieren. Drehen Sie den Knopf, um die Tonhöhe des Soundeffekts zu ändern. Drücken Sie den Knopf, um die Tonhöhenverschiebungsfunktion zu aktivieren.
22. 3.5mm Headset-Buchse
Anschluss an Kopfhörer oder Ohrhörer mit einem 3.5mm TRRS-Stecker.
23. Tonhöhenregler
Drehen Sie den Knopf, um die Tonhöhe des Soundeffekts zu ändern.
24. Sprach-Knopf / Sub Mix-Knopf (Sub mix)
Drehen Sie den Knopf, um die Stärke des Spracheffekts zu steuern. Drehen Sie den Knopf ganz nach links, um die Vocals auszuschalten. Drehen Sie den Knopf, um die Lautstärke des Sub Mix-Kanals einzustellen.
25. Volumen
Drehen Sie den Knopf, um die Frequenzgänge des Mikrofons und des Instrumenteneingangs anzupassen, sodass Sie Ihr Instrument mit dem Mischpult stimmen oder aufnehmen können.
26. Fully Knopf
Drehen Sie den Knopf, um den Pegel des Soundeffekts zu ändern.
27. Bluetooth-Taste
Die Maonocaster E2 Gen2 besitzen acht farbcodierte Soundeffekttasten. Benutzer können ihre eigenen Soundeffekte aufnehmen und diese den Tasten zuweisen. Das Mischpult unterstützt auch Bluetooth MIDI, was die Kompatibilität mit verschiedenen digitalen Audio-Workstations (DAWs) ermöglicht. Lesen Sie das Handbuch, um Soundeffekte aufzunehmen und den Tasten zuzuweisen. Hinweis: Soundeffekte können nicht vom Mikrofon aufgenommen werden.
28. Fader
Hinweis: Der Kanal des Pad-Kanals verfügt nicht über verarbeitete Soundeffekte und muss vom Computer aufgezeichnet werden.
29. Fully Knopf
Drehen Sie den Knopf, um den Pegel des Soundeffekts zu ändern.
30. Bluetooth-Taste
Die Maonocaster E2 Gen2 besitzen acht farbcodierte Soundeffekttasten. Benutzer können ihre eigenen Soundeffekte aufnehmen und diese den Tasten zuweisen. Das Mischpult unterstützt auch Bluetooth MIDI, was die Kompatibilität mit verschiedenen digitalen Audio-Workstations (DAWs) ermöglicht. Lesen Sie das Handbuch, um Soundeffekte aufzunehmen und den Tasten zuzuweisen. Hinweis: Soundeffekte können nicht vom Mikrofon aufgenommen werden.
31. Pad-Knopf
Drehen Sie den Knopf, um den Pegel des Soundeffekts zu ändern.
32. Bluetooth-Taste
Die Maonocaster E2 Gen2 besitzen acht farbcodierte Soundeffekttasten. Benutzer können ihre eigenen Soundeffekte aufnehmen und diese den Tasten zuweisen. Das Mischpult unterstützt auch Bluetooth MIDI, was die Kompatibilität mit verschiedenen digitalen Audio-Workstations (DAWs) ermöglicht. Lesen Sie das Handbuch, um Soundeffekte aufzunehmen und den Tasten zuzuweisen. Hinweis: Soundeffekte können nicht vom Mikrofon aufgenommen werden.
33. Pad-Knopf
Drehen Sie den Knopf, um den Pegel des Soundeffekts zu ändern.
34. Direktmonitorschalter
Schalten Sie den Schalter um, um die Direktmonitorfunktion zu aktivieren. Hinweis: Die Direktmonitorfunktion unterstützt keine Bluetooth-Verbindung.
35. Kopfhörerpegel
Einstellung der Kopfhörerlautstärke.
36. Ausgangspegel
Einstellung des Gesamtpegels der Konsole (TRRS-Headset).
37. Pegelanzeige
Zeigt den Gesamtausgangspegel der Konsole an. Um die Tonqualität zu verbessern, halten Sie die Pegelanzeige des Ausgangspegels im grünen Bereich, wenn immer möglich. Wenn die Pegelanzeige rot wird, deutet dies auf eine mögliche Verzerrung hin, die zu Verzerrungen führen kann.

Elektrizitätsanschlüsse

1. PC-Verbindung

1. Verbinden Sie Ihre Mikrofone, Kopfhörer und alle anderen erforderlichen Geräte wie im obigen Diagramm gezeigt.
2. Verwenden Sie das mitgelieferte USB-C-Datenkabel, um den Maonocaster mit Ihrem Computer zu verbinden. Verwenden Sie das mitgelieferte 3,5mm TRRS-Kabel, um den Maonocaster mit einem Smartphone oder Tablet zu verbinden.
3. Stellen Sie sicher, dass die Hintergrundbeleuchtung des Mischpults an ist. Ist dies nicht der Fall, drücken Sie die Hintergrundbeleuchtungstaste, um sie zu aktivieren.
4. Öffnen Sie Ihre Tonein- und Ausgabe-Einstellungen und wählen Sie das Maonocaster Mischpult als Standardeingabe- und -ausgabegerät aus.
Hinweis: Wenn Sie Ihr Audiokopplung Ihrer Desktop PC mit einem 3.5mm TRS Kabel an den AUX Anschluss des Mischpults anschließen, können Sie Ihr Mikrofon an den XLR Anschluss des Mischpults anschließen.

2. Smartphone oder Tablet-Verbindung

1. Verbinden Sie Ihre Mikrofone, Kopfhörer und alle anderen erforderlichen Geräte wie im obigen Diagramm gezeigt.
2. Verwenden Sie das mitgelieferte USB-C-Datenkabel oder das mitgelieferte 3,5mm TRRS-Kabel, um den Maonocaster mit Ihrem Smartphone oder Tablet zu verbinden.
3. Stellen Sie sicher, dass die Hintergrundbeleuchtung des Mischpults an ist. Ist dies nicht der Fall, drücken Sie die Hintergrundbeleuchtungstaste, um sie zu aktivieren.
4. Öffnen Sie Ihre Tonein- und Ausgabe-Einstellungen und wählen Sie das Maonocaster Mischpult als Standardeingabe- und -ausgabegerät aus.
Hinweis: Wenn Sie Ihr Audiokopplung Ihrer Desktop PC mit einem 3.5mm TRS Kabel an den AUX Anschluss des Mischpults anschließen, können Sie Ihr Mikrofon an den XLR Anschluss des Mischpults anschließen.

3. Bluetooth-Verbindung

Dieses Maonocaster unterstützt Bluetooth-Musikwiedergabe. Bitte folgen Sie diesen Schritten, um Musik zu verbinden und abzuspielen:
1. Stellen Sie sicher, dass Ihre Konsole eingeschaltet ist und aktivieren Sie den Bluetooth-Kopplungsmodus.
2. Öffnen Sie Ihre Bluetooth-Einstellungen und wählen Sie "Maonocaster E2 Gen2" aus der Liste der verfügbaren Geräte.
"Maonocaster E2 Gen2" ist jetzt verbunden.
3. Öffnen Sie Ihre Musikanwendung und beginnen Sie mit der Wiedergabe Ihrer Musik.
4. Spielen Sie Ihre bevorzugte Musik auf Ihrem Telefon ab.
5. Stummschalten Sie Ihren Kanal, verwenden Sie Fader1 zur Steuerung oder zur Steuerung.
Hinweis:
Der Bluetooth-Schalter wird verwendet für den Kopplungsmodus Ihrer Konsole. Bitte beziehen Sie sich für andere Funktionen auf das Handbuch.

4. Aufladen

1. Stellen Sie sicher, dass Sie Ihren Ton vor seiner Verwendung vollständig aufladen lassen.
2. Verwenden Sie ein USB-C-Kabel, um das USB-PD-Netzteil mit dem Gerät zu verbinden.
3. Um die Lebensdauer der Batterie zu verlängern, wird empfohlen, das Gerät einmal pro Monat aufzuladen und vollständig aufzuladen.
4. Schalten Sie das Gerät während des Ladevorgangs aus.
5. Ladezeit: 4-5 Stunden.
6. Wenn Sie das Gerät häufig verwenden, wird empfohlen, es mindestens einmal pro Monat aufzuladen.
7. Vermeiden Sie das Laden des Geräts für mehr als 24 Stunden.
8. Ziehen Sie das Ladekabel nach dem Aufladen ab.
9. Stellen Sie sicher, dass die Umgebungstemperatur innerhalb des Bereichs von 0°C bis 45°C liegt, um eine optimale Ladeleistung zu gewährleisten.
10. Verwenden Sie nur das mitgelieferte Ladekabel und Netzteil zum Aufladen des Geräts.
11. Reinigen Sie die Ladeanschlüsse regelmäßig, um eine stabile Verbindung zu gewährleisten.
12. Vermeiden Sie das Aussetzen des Geräts von extremen Temperaturen, direktem Sonnenlicht oder Feuchtigkeit während des Ladevorgangs.

5. Fehlerbehebung

1. Ton des Mikrofons nicht:
1.1 Überprüfen Sie, ob das Mikrofon stummgeschaltet ist.
1.2 Überprüfen Sie, ob das Mikrofon mit der Konsole verbunden ist.
2. Ton der Begleitung nicht:
2.1 Überprüfen Sie, ob das Begleitgerät mit der Begleitschnittstelle der Konsole verbunden ist.
2.2 Überprüfen Sie, ob das Begleitgerät als Standardausgabegerät festgelegt ist.
2.3 Überprüfen Sie die Lautstärke des Begleitgeräts.
3. Bluetooth-Verbindungsproblem:
3.1 Stellen Sie sicher, dass Ihr Bluetooth-Gerät sich innerhalb von 10 Metern von der Konsole befindet.
3.2 Stellen Sie sicher, dass Ihr Bluetooth-Gerät in den Bluetooth-Einstellungen auf "Maonocaster E2 Gen2" eingestellt ist.
4. Mikrofonrauschen:
4.1 Stellen Sie sicher, dass das Mikrofon nicht zu nahe an der Konsole ist.
4.2 Überprüfen Sie, ob das Mikrofon ordnungsgemäß mit der Schnittstelle der Konsole verbunden ist.
4.3 Wenden Sie sich bei anhaltenden Geräuschen an unsere Kundendienstabteilung.

1. Überprüfen Sie, ob das "Bedienfeld" des Soundkarte, z. B. ob es eingeschaltet ist.
2. Sie können die Lautstärke des Mikrofons erhöhen.
3. Überprüfen Sie, ob das "Bedienfeld" des Soundkarte, z. B. ob es eingeschaltet ist.
4. Sie können die Lautstärke der Begleitung erhöhen.
5. Überprüfen Sie, ob das "Bedienfeld" des Soundkarte, z. B. ob es eingeschaltet ist.
6. Sie können die Lautstärke des Bluetooth-Audio erhöhen.
7. Überprüfen Sie, ob das "Bedienfeld" des Soundkarte, z. B. ob es eingeschaltet ist.
8. Sie können die Lautstärke des Mikrofons erhöhen.

产品介绍

E2 Gen2 是我们热门的Maono产品系列的升级版本。通过60-mm电动推子，可实现平滑精确的音频电平控制，确保无缝混音。该控制台具有先进功能，包括蓝牙连接，用于实现无线音频流传输。它还配备专用蓝牙DSP，以提高音频性能。它支持蓝牙MIDI，使其能与各种数字音频工作站（DAW）兼容。控制台的多功能连接选项包括用于连接计算机的USB-C端口，以及用于连接智能手机或平板电脑的3.5mm TRRS接口。

产品功能

- 双AUX总线，实现简单的Mix-Minus
- 内部和AUX总线，用于发送内容
- 蓝牙连接，实现无线音频
- 蓝牙MIDI和蓝牙DSP，实现增强控制和性能
- 电动推子，实现平滑精确控制
- 高级降噪算法，优化语音录制
- 专用硬件按键，用于静音麦克风和音效
- USB-C接口，轻松连接电脑和手机
- 兼容Windows和macOS
- 支持+48V幻象电源，为电容麦克风供电
- USB幻象电源支持XLR麦克风线
- 支持3.5mm耳机麦克风输入和监听接口

应用

播客、流媒体、会议、电脑、游戏、直播、唱歌、录音和录制、以及使用编辑软件进行录音和混音。

参数

输入灵敏度	18dB	电源模式	4