1736.00 mm

124.00 mm

204.00 mm

照片打印机使用说明书

图片产品的进行调试及参考说明，并非最终版

01

产品介绍

电源键
指示灯
- 电源指示灯
- Wi-Fi 指示灯

散热孔
后出纸槽
重置网络
纸舱门
纸盒门
电源插口
Type-C USB接口

配件清单

电源适配器x1
纸盒x1
纸盒支架
纸盒盖

02

开机连接

1 连接电源
- 将电源线插入打印机背面的电源接口

2 开机
- 按电源键开启打印机，电源指示灯亮起，打印机Wi-Fi自动进入等待连接状态，电源指示灯会熄灭亮

3 连接打印机
- 请参考后续连接指南中相关内容

03

安装色带

1 打开色带仓门

2 插入新色带，转紧卡紧

3 关上色带仓门

04

补充相纸

1 沿着顶部撕掉标，打开纸盒盖

2 将相纸光面朝上放入纸盒
- 注意：纸盒中的纸张已经按类目分类，不要搬运相纸若印纸出现起皱，可以选择重复复制，方便取大纸张。
- 为了保证打印质量，请以每次可放入一张相片纸。

3 合上纸盒盖

05

安装纸盒

1 打开纸盒支架

2 向下旋转纸盒支架180°至底部

3 将纸盒倾斜对接上

06

更换色带

1 打开色带仓门

2 向上推动按手，旧色带自动弹出，取出旧色带

3 插入新色带，将其卡紧后关闭色带仓门

07

使用

工作位置

- 初次时，相机机底部活动板，调整倾斜打印机的方向，以方便打印操作，有效保存墨水

存放

- 打印机长期闲置，可将纸盒置于打印机顶部，节省空间，便于收纳

08

使用

按键操作说明

长按2秒	长按1秒"电源键"	开机
长按	短按"电源键"	关机
长按	快速连按3下	重置网络
长按	长按"电源键"至"重置网络键" 直至指示灯熄灭后	恢复出厂设置

- 重置：长按重置2秒，打印机将恢复至出厂设置状态，所有设置将被清除，但保留已连接的网络信息。
- 恢复出厂设置：长按电源键至重置键，长按2秒，打印机将恢复至出厂设置状态，所有设置将被清除，包括网络连接信息。
- 注意：这两个操作会影响打印机的正常使用，请谨慎操作。

电源指示灯

常开状态	关机
闪烁状态	开机
红色闪烁	打印机/墨水缺少
橙色闪烁	故障

Wi-Fi 指示灯

橙色长亮	未连接
蓝色长亮	连接成功
橙色闪烁	连接中

09

使用

打印机会根据设备与打印机的连接方式，优先选择：Wi-Fi直连 > 蓝牙 > 有线。

10

注意事项

- 打印机最佳的打印温度为25°C-30°C，相对湿度为40%-60%。如环境温度或湿度不适宜，可能影响打印效果。
- 请将墨水盒安装在指定位置，以保证打印质量。
- 请勿触摸喷墨孔位置，以免影响墨水，影响打印效果。
- 请勿使用非原装墨水盒或墨水，不兼容墨盒内，严格禁止重装打印机，以免损坏。
- 出现卡纸情况时，请按照说明书操作，切勿强行拉出纸张，以免损坏打印机。
- 请定期清洁打印机外部，以保持设备外观整洁。清洁时请使用柔软干布，切勿使用腐蚀性清洁剂。
- 打印过程中，请勿频繁开启纸盒盖，以免影响打印质量。
- 长期不使用时，请拔出电源线，并关闭打印机电源。
- 请勿将打印机放置在易受潮、高温或阳光直照的环境中。
- 本用户手册内容可能会根据产品更新而变更，恕不另行通知。
- 请保持本机清洁整洁，以确保最佳打印效果。
- 请勿将本机放置在易于接触儿童、宠物处的位置。
- 请勿将本机放置在不稳定的表面上。
- 不当使用可能导致设备损坏或人身伤害，因此造成的任何损失，概不负责。
- 请确保本机长期通电。

11

产品中有害物质的名称及含量

部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溶溴联苯 (PBB)	多溶二溴联苯 (PBDE)
机芯	○	○	○	○	○	○
电路板	○	○	○	○	○	○
外壳	○	○	○	○	○	○
电源适配器	○	○	○	○	○	○

- 表格依据SJ/T 11364的规定编制。
- ○：表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
- ×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

12

产品保修说明

感谢您选择我们的产品！我们致力于为您提供高质量的打印体验。为了确保您的权益得到保障，请仔细阅读以下保修说明：

一、保修期限

我们为打印产品提供有限产品质量保证。本产品自从（2023年2月1日）起，享有一年的有限产品质量保证。在这期间，如果您发现任何因生产缺陷导致的问题，我们将会为您提供免费的维修或更换服务。

二、保修内容

- 在保修期内，如果您的打印机出现任何因生产缺陷导致的问题，我们将会为您提供免费的维修或更换服务。
- 在保修期内，如果您的打印机出现任何因非正常使用、滥用、疏忽、意外事故、未经授权的修改或维修、自然磨损或老化、电压不稳定、环境因素（如高温、潮湿、腐蚀性物质）等原因造成的问题，我们将会根据具体情况进行评估，并决定是否提供有偿维修服务。
- 在保修期内，如果您的打印机因使用非原厂墨水盒、墨水或其他耗材而出现问题，我们将会根据具体情况进行评估，并决定是否提供有偿维修服务。
- 在保修期内，如果您的打印机因自然灾害、不可抗力因素（如火灾、洪水、地震、战争、恐怖袭击等）而出现问题，我们将会根据具体情况进行评估，并决定是否提供有偿维修服务。

三、产品性能指标表

类型	性能指标	类型	性能指标
主机	长宽：14.5cm 宽度：9.5cm 高度：7.5cm	电源适配器	输入：100-240V 输出：5V/2A

四、保修维修条件

1. 本保修期内维修，是指，检查，调试，更换，清洁，重组，测试，平正等必要保修服务产品组件，或更换，因保修期，因保修后，
2. 保修期内维修，
- 不收取任何费用。
- 不收取任何运输费用。
- 不收取任何其他费用。
3. 本产品因不可抗力因素造成的问题，请参考产品说明书中的相关内容，或联系我们的客服部门。
4. 本保修条款仅适用于在中国大陆地区销售、使用的产品。

照片打印机

产品名称：照片打印机
产品型号：IM002-11002
产品颜色：白色
产品材质：ABS工程塑料，电路板，喷墨组件
产品尺寸：124.00*204.00*75.00
产品重量：约1.5kg
生产厂家：深圳市经纬线科技有限公司
地址：深圳市龙岗区坪地街道

产品生产：2023.02.28前 xxxx
产品保修：1年（xx）
产品颜色：白色
产品尺寸：124.00*204.00*75.00
产品重量：约1.5kg

Photo Printer

Model: Photo Printer
Manufacturer: Jingweixian Communications
Product Dimensions: 124.00*204.00*75.00
Weight: 1.5kg
Product color: White
Manufacturer: Shenzhen Jingwei Communications Technology Co., Ltd.
Address: Pingdi Street, Longgang District, Shenzhen

Product size: 124.00*204.00*75.00
Product color: White
Weight: 1.5kg
Warranty period: 1Y(1Y)
Manufacturing date: 2023.02.28 xxxx

PHOTO PRINTER OPERATING MANUAL

Please read this manual carefully before using and keep it properly

01

Introduction

power button
Indicator Light
- Power light
- Wi-Fi indicator

Ribbon Cartridge
Paper Box
Louver
Paper Exit
Reset the network
DC Port
Type-C USB Port

Accessory List

Power Adapter x1
Paper Box x1
Paper Box Holder
Paper Box Cover

02

Power on and Connecting

1 Link the Power
- Plug the power adapter into the power port on the back of the printer

2 Power On
- Press the power button to turn on the printer. When the power indicator light is steady on, the printer is ready to connect to the Wi-Fi connection, and the power indicator is in white

3 Printer Connection
- Please consult instructions in the subsequent section for detailed connection guidelines.

03

Ribbon Assembling

1 Open the ribbon cartridge

2 Insert the new ribbon and clamp it tightly

3 Close the ribbon cartridge

04

Supply the photo paper

1 Open the paper box cover along the top gap

2 Place photo paper smooth side up in the box
- Put no more than 20 pieces of paper in the paper box.
- Please ensure the paper is placed in the paper box correctly.
- Pull the holder to place the paper more convenient.
- To ensure print quality, it's recommended to put only 1 piece of photo paper at one time.

3 Close the box cover

05

Paper box assembling

1 Open the box holder

2 Rotate the box holder down 180° to the bottom

3 Insert the box into the printer

06

Ribbon replacement

1 Open the ribbon cartridge

2 Push the trigger upward, old ribbon will pop up automatically, take out the old ribbon

3 Insert new ribbon, clamp it tightly and close the cartridge

07

Operating

Operating position

During the printing, the paper will move back and forth, please ensure that there is more than 20cm space behind the printer

Top Paper guard and out tray/paper holder

Storing

When the printer is idle, paper box can be placed on the top of the printer to save space and facilitate storage

08

Operating

Keys operating instruction

Hold down the power button for 1 second		Power on
Press the power button		Power off
Quick press 3 times		Reset the network
Press and hold the Power button and the Reset button simultaneously for 2 seconds		Restore to factory settings

- Factory Reset: Long press the reset button, the printer will restore to factory settings and reset the network.
- When the network is successfully reset, the Wi-Fi indicator light will be in a flash mode, indicating that the network has been successfully reset and is ready for new connections.
- Saving Power: Long press, a short time power button, supports with or without paper.
- When there is a fault, the power button is slow blinks.
- Paper Jam: Please remove the paper jam.
- The indicators are only for reset the printer in an standby, or in idle.

09

Power Indicator

Light off	Power off	
Light on	Power on	
Flash in white	printing/Firmware upgrading	
Flash in orange	error	

Wi-Fi Indicator

Constant orange	Disconnected
Constant in blue	connected
Flash in orange	connecting

Before printing, ensure that the device and printer are connected to the same network, and the Wi-Fi indicator is blight in blue.

10

Notes

- The best printing temperature of the printer is 10°C-35°C, and the relative humidity should be 40%-60%. If the conditions are not suitable, the print quality may be affected.
- Do not use unofficial ribbons and paper to ensure the quality of the print.
- Do not touch the smooth surface of the photo paper to avoid leaving fingerprints and affecting the print quality.
- When printing, make sure the smooth side of the paper is up, flat inside the paper box, and insert the paper box on the front of the printer.
- The paper exit can not be blocked, blocking the path of the photo paper will affect the printing effect.
- During the printing, the paper needs to be reciprocated in the printer four times to ensure the quality of the photo. Please avoid frequently pulling out the paper. Please wait patiently, do not forcibly pull out the paper, so as not to damage the printer.
- The printer uses thermal sublimation printing technology, the print head will be heated during the printing process. Please wait patiently for the print head to cool down after the printing is completed. Do not touch the print head to avoid burns.
- It is normal for different printers to have slightly different colors printed on different paper.
- When not used for a long time, it is recommended to remove the paper box, and close the door of box, close the box holder and box cover to prevent dust from entering and affecting the printing quality of the first photo.

11

- When unused photo paper is stored in the machine, it is necessary to avoid storage in high temperature and humid environment.
- Do not use the original adapter or other devices to avoid damage.
- Do not unplug the power adapter during the upgrade.
- Do use the original adapters, otherwise it will cause printing failure.
- Please avoid printing continuously for a long time.

12

Warnin

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF Exposure Statement
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Photo Printer

Model: Photo Printer
Manufacturer: Jingwei Communications
Product size: 124.00*204.00*75.00
Weight: 1.5kg
Product color: White
Warning period: 1Y(1Y)
Manufacturing date: 2023.02.28 xxxx

图纸提供单位

深圳市经纬线科技有限公司

项目名称

IM002-11002
照片打印机说明书

版本号

V1.1

材质工艺要求

材质要求：

105g金东太空梭

附加工艺：

折页，正反面印刷

颜色及 专色：

设计时间

2023.09.21

设计-部门：

冉龙威-品牌运营部

审核：

陈辉