NCS-001U

HORI

1977-4US

EN

Instruction Manual

Thank you for purchasing this product.
Please read this instruction manual carefully.
After reading the instruction sheet, please keep it with you for reference.

Caution

Warning
Do not expose to rain or water.

Please read carefully before using this product.
Do not use in a wet environment.
Do not put this product or any of its components in your mouth.
Do not use this product near water or in the rain.
Do not use any chemical agents like benzene or thinner.

Regarding radio wave interference regulation:
This product is a radio wave device. Please use it in an intended for use in a home environment.
If used in close proximity to a radio or television, interference may occur. Please read this manual carefully and use the product properly.

Regarding device certification:
This product is certified by the Radio law as a low power data communication wireless device.

Notice on communication:
Wireless communication uses the frequency band. Other wireless devices may use the same frequency band.
In order to prevent radio interference with other wireless devices, please pay attention to the following items:
1. Before using this product, please confirm that no other wireless devices are being used nearby.
2. If radio waves from other wireless devices are detected, please stop using this product or move to a place where other wireless devices are not detected.
3. Change the area where this product or our other wireless devices off.
Please do not use in prohibited areas such as hospitals or near other electronic devices.
Please do not use near other wireless devices, such as pacemakers, automatic doors, etc.
If a pacemaker or other medical electronic equipment is in the vicinity, please consult a doctor.

Regarding batteries:
Use only the specified batteries. Do not disassemble, modify, or heat the batteries.
The lithium-ion rechargeable battery pack contains a protection circuit.
When replacing the batteries, replace both batteries at the same time with new ones.
Do not mix batteries of different types, brands, or capacities.
If the battery pack leaks or emits a smell, stop using it and keep it away from fire.
If the battery pack has swelled or deformed, do not use it.
If the unit's screw is rusted with your body or clothing, may stain those water immediately.
Do not disassemble, modify, or heat the battery pack or charging cable.
Do not disassemble, hack, modify, charge, or add batteries to the cable. Damage or leakage of liquid may cause injury or burns.
Do not use batteries other than the specified batteries. Do not mix new and used batteries or different types of batteries.
Do not short circuit the battery terminals with metal objects. Do not carry or store with metal objects.
Avoid batteries entirely. When plan to use it once a 1 year minimum, remove it and charge it.
Do not expose batteries to water, fire, or high temperatures. Do not place in microwave ovens or pressure cookers.
If the battery leaks or emits a smell, remove it from the device and keep it away from fire.
If you feel an abnormal heat, stop using the product and contact your local Hori or your local authorized dealer.
Stop using the product if the battery pack overheats, discolors, or deforms.
If the battery pack leaks and you get liquid in your eyes, do not rub your eyes. Rinse with clean water and seek medical attention immediately.
Do not use the battery if it is damaged or has a strong odor.
Do not use the battery if it is damaged or has a strong odor.
Do not use batteries if they are damaged, leaking, or have a strong odor.
Do not use batteries if they are damaged, leaking, or have a strong odor.
Do not use batteries if they are damaged, leaking, or have