English x 1pcs

Front

ADV.

sleeper

WIRELESS

ENGLISH | USER GUIDE

CHARGING SLEEPER WIRELESS

Plug the microUSB cable into the charging port*.

*It takes 2.5h to fully charge.

Earphones will turn off automatically to save power after 10 minutes of idle.

PAIRING SLEEPER WIRELESS

Long press the power button until you hear a beep, hold the button until the LED flashes blue & red.

Power button

Voice prompt

"POWER ON"

Turn on BT function on your smartphone.

Find "ADV. Sleeper" inside BT device settings, and pair.

Voice prompt

"CONNECTED"

WEARING SLEEPER WIRELESS

Wear the device as illustrated.

Back

L R

CONTROLS

Control music playback, answer and calls, and activate voice assistant.

Previous track

Activate voice assistant (hold 1 second)

Power on / off (hold 1 sec)

Play/ Pause

Pairing

Forward

Volume +

TECH SPEC

Driver	6mm dynamic driver
Impedance	16Ω ±15%
Sensitivity	95dBm±3dB at 1kHz
Frequency	20Hz - 20,000Hz
Mic type	Omni
Distance	10m (33ft)
Music/Talk time	up to 7 hours
Charging time	2.5h
Input port	microUSB port
Input power	DC 5V 1A
Voltage	3.7V

1-YEAR LIMITED WARRANTY

ADV. Sleeper Wireless Earphones are warranted against defects in workmanship and materials for one year from the date they are first purchased by the original consumer. This warranty does not cover damage caused by improper use, abuse, misuse, or improper maintenance. Proof of purchase is required. Please keep your receipt in a safe place. Contact ADV. Sleeper Wireless Earphones Customer Service at support@adv-sleeper.com for assistance. Please do not return your product to the place of purchase.

WHAT IS PROTECTED BY THIS WARRANTY

Defects in workmanship and materials in ADV. Sleeper Wireless Earphones under normal use for a period of one year.

WHAT IS NOT COVERED BY THIS WARRANTY

Damage caused by improper use, abuse, misuse, or improper maintenance. Damage caused by the ADV. Sleeper Wireless Earphones being used with other products. Damage caused by accidents, acts of God, or other causes beyond the control of ADV. Sleeper Wireless Earphones. Damage from failure to follow instructions contained in the instruction manual. Damage resulting from unauthorized repairs or modifications. Damage caused by ADV. Sleeper operating outside of its intended purpose. Damage caused by other products, or by the use of other products with ADV. Sleeper Wireless Earphones. Damage caused by other hardware, software, or other products. Damage caused by improper storage or handling. Damage caused by improper or inadequate packaging. Damage caused by improper or inadequate maintenance. Damage caused by improper or inadequate cleaning. Damage caused by exposure to liquids. Damage caused by improper or inadequate repairs. Damage caused by improper or inadequate modifications. Damage caused by improper or inadequate installation. Damage caused by improper or inadequate connections. Damage caused by improper or inadequate adjustments. Damage caused by improper or inadequate use. Damage caused by improper or inadequate storage. Damage caused by improper or inadequate