

APPLICANT: HANTEL

FCC ID: ODGWWC1000

MPE CALCULATION FOR 0 dBi ANTENNA

Formula used in the MPE Calculations:

$$E^2/3770 = S, \text{ mW/cm}^2$$

$$P_{\text{watts}} * G_{\text{gain}} = 10^{(P_{\text{dBm}} - 30 + G_{\text{dBi}})/10}$$

$$E, \text{ V/m} = (P_{\text{watts}} * G_{\text{gain}} * 30)^{.5}/d, \text{ meters}$$

$$d = ((P_{\text{watts}} * G * 30) / (3770 * S))^{0.5} \text{ ----- (A)}$$

Since

$$S \text{ (mW/cm}^2\text{)} = 0.30 \quad \text{from 1.1310 Table 1}$$

$$P \text{ (dBm)} = 22.50 \quad \text{EUT output power}$$

$$G \text{ (dBi)} = 0.00 \quad \text{EUT antenna gain}$$

Substitute these parameters into the A above, we have

$$\text{MPE safe distance } d \text{ (cm)} = 6.87$$

NOTE: For mobile or fixed location transmitters, minimum separation distance is 20 cm, even if calculations indicate MPE distance is less