

The adhesive backed product label should be adhered to the underside of the cover moulding (BBM Cover A016) in the top left corner with a 2-3mm border around the edge



The adhesive backed barcode label should be adhered within the recessed detail on the underside of the base moulding (BBM Base A017) in the orientation shown

