

Figure 44: V3000-to-V3000 backhauled link connectivity using a DAC cable



- **Connecting a V5000 device backhauled by a V3000 device**

When setting up point-to-multipoint links with the V5000 device as a distribution node (DN), if the fibre PoP is not available near the V5000 device node, a V3000 to V3000 backhaul point-to-point link is setup. For connecting V3000 to V5000, the DAC cable is recommended (as shown in [Figure 45](#)).