

Date:	January 26, 2006	Assembly P/N	750024 Rev B
Assembly	Assembly, paddle antenna		
Name:			

## Bill of Materials for 750024 Rev B

AgileMesh P/N	Description
100072	C068-510330A, paddle antenna, RP-SMA female
100073	Adapter, RP-TNC female to RP-SMA male
100059	Thread-locker, permanent, Loc-tite 277

## Assembly Instructions:

- 1. Apply permanent thread-locker (P/N 100059) to the threads of the RP-TNC female to RP-SMA male adapter (P/N 100073) making sure that the thread-locker does not get inside the connector area. Make sure the threads are covered all around the adapter. See Figure 1 below.
- 2. Screw together the adapter (P/N 100073) to paddle antenna (P/N 100072). Clean off any excess thread-locker away with a Q-tip. See Figure 1 below.



Figure 1. 70024 Assembly