

真无线耳机使用说明书



产品示意图



包装清单

真无线耳机主机
真无线耳机充电盒
Micro Spin 充电线
使用说明书

产品规格:

无线版本：V5.3
电池规格：耳机3.7V
支持模式：HFP/HSP/A2DP/AVRCP
灵敏度：105dB ±3dB S/P at 10Hz
信号距离：10米（无任何较大障碍物的理想环境）
待机时间：约80小时
充电时间：给电池仓充电约1小时，充电仓给耳机充电的10小时
充电仓给耳机充电次数：约2次

功能操作说明

- 开机
将耳机从充电仓拿出自动开机或长按左耳机多功能键5秒开机。
- 关机
将耳机放入充电仓自动关机长按右耳机多功能键5秒关机。
- 开机关机
当配对成功后，第二次开机时蓝牙耳机优先进入连接状态。

杰西双耳已连接过的手机。

- 播放/暂停
在待机状态下，单击左右耳机多功能键均可直接播放音乐，播放时单击左右耳机多功能键均可暂停播放。
- 切换歌曲
播放音乐时长按左耳机多功能键2秒同时按“嘿”一声语音识别上一首，长按右耳机多功能键2秒同时按“嘿”一声语音识别切换到下一曲。
- 音量加减
长按左耳机多功能键加大音量，长按右耳机多功能键减小音量。
- 来电接听
手机来电时，单击左耳机多功能键均可接听电话。
- 来电拒接
手机通话时，单击左耳机多功能键均可挂断电话。
- 来电拒接
手机来电时，长按左耳机多功能键2秒均可挂断来电。
- 来电重拨
在通话或者播放音乐时，三击左耳机多功能键即可拨打通话记录中最后一个拨打过的电话。
- 启动语音助手
三击右耳机多功能键即可启动苹果Siri或谷歌语音助手进行语音控制手机操作。
- 低电量提示
当耳机电池电量不足时，间隔60秒播放一次电量不足提示音。南京耳机低电关机。

显示屏：南京耳机低电关机。

配对方式

普通配对方式

- 从充电仓取出或者长按充电仓，若耳机多功能键3秒开机，直至指示灯交替闪烁，进入对耳设备配对状态，进入对耳设备配对，配对成功后三指示灯交替闪烁，副屏指示灯光，同时播放对匹配成功的提示音。
- 启动手机或者其他设备的蓝牙功能，如果是安卓系统的手机或者设备请点手机“设置-无线设备”选项，如果是iOS系统的手机或者设备则会自动搜索设备，当搜索到该无线耳机的型号后，点击进入配对，当配对成功后，耳机会发出连接成功的提示音，左右耳机指示灯灭，进入连接状态，配对成功后右耳为右声道，在耳为左声道。
- 两只耳机也可单独与手机进行配对使用，操作方法同上步骤2操作步骤进行操作。

充电操作

- 将Micro USB充电线一头插入充电仓，一头插入充电器即可给充电仓充电。充电器需使用5V 1A的额定充电器能给充电仓充电。
- 给耳机充电：将耳机放入充电仓即可自动充电，充电时耳机显示灯会点亮，充满电后熄灭；

注意事项

- 请在安全的环境下充电。在充电组合充完电后，请将充电仓与充电线分开，以免在长的时间内充电线造成过热。
- 在显示播放时，请将音量调至合适的音量大小，以免长期在大音量状态下对听力造成损伤。
- 尽量避免在有干扰的地方使用本耳机，否则有可能对耳机产生影响。
- 尽量避免在有腐蚀性的环境中使用本耳机，以免对耳机的功能产生影响。

温馨提示：在使用本无线耳机听音乐或者通话时，请注意适当调节音量大小，以免过大的音量对您的听力造成影响。

PCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including

interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

LIVE TWS EARBUDS WITH POWER DISPLAY USER MANUAL



Product diagram



Packing list

TWS 耳机盒
真无线耳机充电盒
Micro Spin 充电线
使用说明书

Product specification

Product model: T5000
True wireless version: V5.3
Battery specification: earphones 3.7V ; Charging box 3.7V
Supported mode: HFP/HSP/A2DP/AVRCP
Transmission: 10M (in ideal environment without any large obstacles)
Standby time: about 80 hours
Charging time: charge the charging box for about 3 hours, and charge the headset for about 1 hour
Charging time for the headset: about 2 hours

Functional instructions

- Reset
Take the headset out of the charging box and press it automatically or long press the left and right multi-function buttons of the headset for 3 seconds.
- Shut down
Put the headphones into the charging box and turn it off automatically.
Long press the left and right earphone multi-function buttons for 3 seconds to turn it off.
- Phone link
When the pairing is successful, the Bluetooth headset will first enter the state of connection when the second time is started and automatically connect the connected phone.
- Play/pause
When the earphone is in standby or playing music, you can make the last call to your phone ended by three clicks of the left earphone multi-function button.
- Call volume
Three clicks on the right earphone multi-function button can increase volume or Google voice assistant the voice control of the phone operation.
- Low battery alert
When the earphone battery is insufficient, the interval of 60 seconds to play a low battery sound, until the earphone low power off.

Common pairing style

- Take it out from the charging box or press the left and right multi-function area for 3 seconds at the same time, turn it on until the indicator light flashes alternately, turn the pair-one search matching state, enter the pair-one scanning matching state, after the successful matching, the main ear indicator light will be always on, the auxiliary ear indicator light will be off, and the pair one matching success one time is played simultaneously.
- Double wireless capabilities on your phone or other devices, it'll be an analog phone or device, click the "Search for wireless devices" option on your phone, it'll be an iOS phone or device, it will search for devices automatically. After searching for the model of the wireless headset, click enter the search. After the search is successful, the headset will give a confirmation tone that the connection is successful. The left and right earpiece lights will turn off and enter the connection state by mode, the right ear will be the right earpiece and the left ear was the left earpiece.
- Try to avoid using the earphone where there is interference source, otherwise it may affect the earphone signal.
- Try to avoid using the earphone in a corrosive environment, so as not to affect the function of the earphone.

Tip: when you use this bluetooth headset to listen to music or talk, please pay attention to adjust the volume, so as not to affect your listening too much!

Precautions

- Please charge in a safe environment. When charging the charging box, the charging box should be separated from the charger as soon as possible, so as to avoid damage to the charging box caused by charging for a long time.
 - When the music is playing, please adjust the music to the appropriate volume to avoid long-term damage to the hearing under the condition of high volume.
 - Try to avoid using the earphone where there is interference source, otherwise it may affect the earphone signal.
 - Try to avoid using the earphone in a corrosive environment, so as not to affect the function of the earphone.
- ## Charging Operation
- Plug the Micro USB charging cable into the charging box and the Charger at one end. The Charger uses a standard 5V 1A charger to charge the box.
 - Charging the headphones: the headphones can be automatically charged into the charging box, charging the headphone indicator light will be lit, full of electricity after the arrangement.