S17说明书折页

成品尺寸: 55*80 mm

材质: 封面封底157g铜版纸, 折页

料号: 11401-01342



Overview of earbuds

Key diagram


Charger and battery: 1.Please use the original cable to charge the Bluetcoth

eerbuds,otherwise it may damage the earbuds.

2. The earbuds uses a non-detachable built-in rechargeable battery, in order to protect your earbuds,please do not

remove the battery. 3.Before charging,make sure the earbuds has been power

off.
4.Plug USB cable into the charging port of earbuds, the red light remains bright when charging.
5.Charging time of earbuds takes approximately up to 1.5-2hours, the red light will turn blue when fully charged, they time is about 16 hours.




Play / Pause | Tap once

Vol [+] Tap once Next Track Press and hold

Call Voice Assistant (SIRI) Press and hold

booming call/hang up | Tan once



. Smart on: Keep pressing the MF button 3S,red light will go for 1S, then go out.

Keep press the MF button until the alternative red and blue light quickly blirks,turn on your phone's Bluetooth,search for "Padmate \$17" in the available devices list,and click it to complete the pairing of the earbuils.

Padmate S17

(0)



长按多功能按键3秒、红灯亮1秒后关机。 RC:

长按耳机多功能按键直到指示灯红蓝灯交替快闪,打开手机 富牙,在可用设备中搜索"Padmate S17"并点击连接完成 配对

同时连接两台设备(多点连接)

- 1 首先 按照配对的说明与设备1配对连接。
- 2.配对成功后,关闭设备1的蓝牙功能。 3.按照配对说明与设备2配对连接(设备1的蓝牙 功能已关闭)。
- 4.与设备2连接成功后, 打开设备1的蒸牙功能, 耳机将于设备1自动连接,如果没有连接成功, 请在设备1中点击"Padmate S17"完成连接。
- 5.以上操作完成后、您可以使用耳机从两个配对 设备中的任何一个拨打和接听电话。

音频产品警告!

长期暴露于高音量的声音可能导致永久性听力损失,请尽可能 使用低音量,避免以过高的声压级长时间使用耳机,在使用本 产品前请仔细阅读安全指南。

你可以通过遵守这些安全指面减少折力损害风险: 1.在使用本产品之前请按这些步程操作

在使用本产品前,请将音量控制调到最低;
 截上耳机、如透用;
 慢慢地将音量调到舒适的水平。

2.在使用本产品的过程中

使音量保持在尺可能量低的水平 · 使自無條所任係可能數据的不等。 如果必要加高營權。但權地制予。 如果經過不透或其完單線期的,但立即停止使用本产品。 如果持续以高營量使用。因如其冷可能会無衡适应这种严峻,这 可能会在沒有任何明显不适的情况下对您的听力造成永久性損

一般安全信息

- ·如果您身上安装了起舞器或其它电子医疗装置,在使用本产品 初应咨询医生 **中级内含有印能对儿童造成危险的他小号件。务必将本产 品置于儿童无险级处的地方。吞食包装领或使中所装他小号 部可能引起更见, "效为自行转群本产品或各任何类型价势体额入产品,这样可能 造成电路故障进而导致火灾或触电

商。 如果长时间不对耳机进行充电,电池寿命会大大细矩,建议 等第三个月至少为耳机充一次电。 让扩与届在过热或过冷的地方将减少电池的能量和寿命。务 必使用说费于15℃至25156户至7下16时54章下,电抢过热 或过冷可搬会导致产品暂时不工作即便电池已经充满电。

Battery warning

中不得自行更换或维修元件。只有授权的经销商或服务中 方可打开本产品。

心方可打开本产品。 如果由于任何原因(包括正常磨损或破损)需要更换产品的任 何部件,请联系经销商或服务中心。

何部件,演歌系经销商观众第分中心。 建定广岛接触与阿木坎克拉尔战。 用作了。 在接触与阿木坎克拉尔战。 "通过分析有果实在指达特尔(加速的内域、4机上)关闭电子设备 或对频光起序。 是是一个最后的最高。 是是一个最后的最高。 "是是一个最后的最高。" "是是一个最后的最高。" "是是一个最后的最高。" "是是一个最后的最高。" "是是一个最后的最高。" "是是一个最后的最高。"

请记住: 务必安全驾驶,避免分散注意力并遵守当地法律!

内置电池保养: 如果产品配有电池, 请遵守以下指引

等線机的车辆时使用场声器可能会受到当地法律管例等線机 动车辆,靠托车、船舶或自行车时使用耳机可能会有在险斗 且在某些司法管辖区是不合法的,因为某些司法管辖区不允许 在驾驶时使用这种覆盖双耳的耳线。请答询您当地的有关部门。

您的产品由可充电电池供电。新电池只有经过两到三个完整

的充放电循环后才会获得完整的性能。 电池可充放电数百次,但最终将耗尽。请勿让充满电的电池连

电影可元政电数目次,但最终初起3。 情勿止无满电的电池压 接在充电器上,因为过充可缩短其寿命。 在不使用的情况下,充满电的电池将随着时间渐渐损失它的电

Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or bree complete charge and discharge cycles. The battery can be charged and discharged fundreds of times, but will eventually weer out. Do not besive a fully charged battery connected to a charged, since executarying

may shorten its lifetime.

If left unused, a fully charged battery will lose its charge over

ilme. The battery life will be shortened if you do not charge the headset for a long time.We recommend you to charge it at least

headset for a long time. We recommend you to charge it at leas once every three months.

Leaving the product in hot or cold places will reduce the capacity and lifetime of the bettery. Always try to keep the bettery between 15°C and 25°C(59°F and 77°F). A product with a lot or cold bettery may not work temporarily, even when the bettery is fully charged.

电池警告!

- "小心"--如果处置不当,本产品中使用的电池可能存在火灾或 化学烧伤风险。如果损坏,电池可能爆炸。 只可使用所配的指定用于本产品的认可充电器为您的电池充
- 电。 · 明功的容置应遵守当地注接。可能时间回收。请勿当作生活 垃圾容置或丟入火中风为它们可能爆炸。 · 修非用户手册或快速使用骗响中规定产品中的电池不得由用 广取下或更换。这样脑半常危险,可能导致产品损坏。
- 重要: 有关充电状态指示灯的说明,请查询用户手册。有些产品 在农由封于诗律用

·請勿使用輸出高于6V/2A約整式充电器。 ·新开电源保任阿剌加设备的时候。应避性然后被出插头,而不是 拉杜电谱线、不要使用已损坏的充电器。 ·不要试图拆到充电器。这样可能会有触电危险。

·清洁前请拔除产品或充电器插头。 ·清洁时请使用干燥或微湿的布擦拭产品。软线和充电器只能

*** 8 ***

used while charging Do not use a well charger with more than 5V and 2A output. When you disconnect the power cord or any enhancement, grease and pull the plug, not the cord. Never use a charger that is charged. Do not attempt to diseasemble the charger as it may expose you to chargeruse electric shock.

MAINTENANCE

Unplug the product or charger before cleaning.
 Clean the product by wiping with a dry or slightly damp clott. The cord and charger may only be dry-clusted.

FCC Warning

FEC Warning The drives comprehen with part 15 of the FEC Bales. Questions in adjact to the following hard conditions (1) the device may be recommended to the following hard conditions (1) the device may be recommended to the following hard conditions (1) the device may be recommended to the second to the sec

Simultaneously Pairing with Two Devices (Dual Pairing Mode) : AUDIO PRODUCT WARNING!

- The instructions in the "Pairing" section to pair the earbuds with Device 1.
- 2.Once paired, disable pairing function on Device 1. Next, follow the instructions in the "Pairing" section to pair with the Device 2 (Device 1 Pairing function off).
- 4.Once paired with Device 2,Turn on Pairing function on
- Device 1 and the earbuds will automatically reconnect, if it not reconnect success, please click "Padmate S17" in Device 1 to connect. 5. You can now make and receive calls from either of the

- PERMANENT HEARING LOSS MAY RESULT FROM long-term EXPOSURE TO SOUNDS AT HIGH VOLUMES, USE AS LOW A VOLUME AS POSSIBLE. Avoid prolonged use of headsets at excessive sound pressure
- levels.

 Please read the Safety Guidelines below prior to using this product

....

You can reduce the risk of hearing damage by following these safety guidelines:

- 1.Prior to using this product follow these steps
- Before using the product, turn the volume control to its lowest level; owest level:

 - Put the headset on, if applicable;

 - Slowly adjust the volume control to a comfortable level.
- 2.During the use of this product

- Keap the volume at the lowest level possible;
 If increased volume is necessary, adjust the volume control
 If increased volume is necessary, adjust the volume control
 If you specificated decontror or integring in your earn, immediately discontinue using the product.

 With continued use a triph volume, your earn may become accustomed to the sound level, which may result in permanent unique to your hearing without any accustedable disconfirert.

GENERAL SAFETY INFORMATION!

- This paskage contains small parts that may be hazardous to children. Always store the product out of resch from children. The bugs threehead for the may maint part they contain the bug children and the product yourself or insert any type of the product yourself or insert any type of bug children when you can act critical time that can be considered that, that they cause a critical time who can be considered to the product yourself or insert any open and they contain the product your department can be replaced or repited by users. Only admitscrate they can be component can be replaced or repited to your services. Only admitscrate your deliver or service contains. - Note of the contains the product of your or or other liquids. - And always they are product to run or other liquids. - And always they are product to run or other liquids.

- machinery.

 Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts.

 If the product overheads, has been dropped or damaged or has been dropped in a liquid, discontinue use.
- Remember: Always drive safely, avoid distractions and follow local laws!

- The use of a speaker while operating a motor vehicle may be regulated by local laws. Using a headset while operating a motor-which, monotroycle, weterraft or blocked may be dangerous, and is legal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check with your local sutherfiles.
- BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

- "Caution"—the battery used in this product may present a new close to the control down in miscredod. Batteres may be controlled to the miscredod space of the rectings you better with the product. The product of the product of

*** 15 ***

