


# User Manual













## 1 appearance







PMN: REMOTE CONTROL  
HVIN:RF45

## 2 Key function

Key value	Specification
PAIR	press and hold  button ,the remote enters pairing mode, backlight LED flashes, When the pair succeeds, the backlight stops flashing then normally on.
Hi	press and hold <b>Hi</b> button , lumbar actuator moves out, stop when released
Lo	press and hold <b>Lo</b> button , lumbar actuator moves in, stop when released

HEAD UP	Press and hold  button, head actuator moves out, stop when released
HEAD DOWN	Press and hold  button, head actuator moves in, stop when released
FOOT UP	Press and hold  button, foot actuator moves out, stop when released
FOOT DOWN	Press and hold  button, foot actuator moves in, stop when released
FLAT	Click  button, the bed goes flat
ZG	Click  button, the bed moves to zeroG position, press and hold zeroG button for 5s, until backlight flashes, the control set the current position as zeroG position
TV/PC	Click  button, the bed moves to TV/PC position, press and hold TV/PC button for 5s, until backlight flashes, the control set the current position as TV/PC position
UNDER BED LIGHT	Click  button, the under bed light switch its on/off state; After the under bed light opens, if do not manually close, it will automatically turn off after 5 minutes;
MEMORY	Click  button, the bed moves to MEMORY position, press and hold MEMORY button for 5s, until backlight flashes, the control set the current position as MEMORY position
FLASH LIGHT	Press and hold  button, open flash light, close when released
MESSAGE HEAD	Click  button, head massage motor switch its intensity among 1-2-3-0
MESSAGE FOOT	Click  button, foot massage motor switch its intensity among 1-2-3-0
TIMER	If the massage motors do not work, the button is invalid, if the

	 <p>message motors work, click button to switch the massage time, when massage time switch to 0, turn off the massage;</p>
INTENSITY+	 <p>if the massage motors work,click button to increase massage intensity among 1-2-3-0.</p>
INTENSITY-	 <p>if the massage motors work,click button to decrease massage intensity among 3-2-1-0.</p>
MESSAGE TYPE	 <p>Click button, to switch the massage mode of massage motors,massage mode switches among type0→ type1→ type2→ type3→type0; this button can only switch the massage mode, it can not open massage motors;</p>

### FCC Warning :

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### ISED RSS Warning:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

