





MODEL: TWS210

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE

Getting started

- . Remove the product from the box.
- . Remove any packaging from the product.
- . Please retain all packaging after you have checked and counted all the parts and the contents against the list.
- . Please fully charge the earphone and charging case before first using.

Package Contents

- . Bluetooth earphones
- . Charging case
- . USB charging cable
- . Instruction Manual
- . large and small earbud caps each one set

Safety Rules

1. To ensure safety, please follow the rules mentioned in this manual. Before using the Bluetooth earphone, we strongly recommend that you read this manual carefully.

2. Please pay attention to the sharp edge, uneven surface, metal parts, accessories and packaging.

3. Please do not open, dismantle or repair this product, this may lead to fire, electronic breakdown or even completely damage the product, these are not included in the warranty.

4. Do not wipe the product with oil and other volatile liquids.

5. Please do not use this product in the places where there is a potential personal safety risk and danger.

Connect to your phone quickly

1. The first time to manually connect the phone

If it's the first time to use the earbuds, you can connect your phone in just two easy steps.

(1) Open the charging case and take out the earbuds. The two earbuds first automatically pair each other. After 5 seconds, the two earbuds will automatically pair successfully.

(2) Click on the connection setting on the phone, search for the device, select

"2BOOM-TWS210"

to connect.

2. Automatically connect with mobile phone

You only need to manually connect to your phone on first time.

In next time, when you take out the earbuds from the charging case, they will automatically pair each other and connect to your phone after pairing successfully, without any manual operation.

3. Monaural Earphone Use

If it is the first time to use the monaural earbud, you can manually connect your phone in just

two easy steps.

(1) Open the charging case and take out the earbud. The earbud will automatically power on and wait for connection.

(2) Click on the connection setting on the phone, search for the device, search and select "**2BOOM-TWS210**" and click on Connect.

Battery Case and charging

A. Put the earbuds into the case, the earbuds will be charged directly until fully charged.

B. The Blue light is flashing when charging, once fully charged the blue light will be on always and stop charging.

Button Function definition

Answer calling	One touch during the call ringing.
Hung up	One touch during answer calling.
Reject calling	Long touch for 1 second during the call ringing.
Recall	Double touch any side.
Play/Pause	One touch any side.
Siri/Google	Touch three times.
Move Next	Long touch till hear "Di".

(Note: Battery life & charging time may vary based on usage & types of devices used.)

FCC ID: 2AIDL-TWS210

FCC STATEMRNT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

Warming: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notes:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, The device has been evaluated to meet general RF exposure requirement.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.

Migear International Group LLC, 21 W 38th Street, 14th Floor, NY, NY 10018 USA

TEL: 929-390-4504