TROUBLESHOOTING

No power Recharge your earbuds using the included battery charging case.

Music is not plaving over Bluetooth

Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the earbuds to reconnect your Bluetooth® device.

Bluetooth® device will not reconnect with the earbuds

Navigate to your Bluetooth® settings menu on your Bluetooth device, tap "UZ E044T" and select "Forget." Now follow the steps to pair your device again.

Specification: Bluetooth® Version: 5.3 Bluetooth® Range: Up to 30ft. Charging Case Capacity: 200mAh Charging Time: Approx. 1.5 Hours Playback Time: Approx. 3-4 Hours* Charging Input: USB Type C Freq. Response: 20Hz - 20KHz Standby Time: Approx. 4 8 Hours
*Depends on individual use

FCC Notice:
This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

2. This device must accept any interference received, including interference that may cause undesired operation. This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technical for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Technical Support:

Iecnnical Support:Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support: Merkury Innovations

contact Merkury Innovations technical support:
Merkury Innovations
45 Broadway 3rd Fl. New York, NY 10006
www.merkuryinnovations.com
E-mail: support@merkuryinnovations.com
© 2023 Merkury Innovations LLC
To explore our full selection of products,
visit us at: www.merkuryinnovations.com
The Bluetooth word mark and logo are registered trademarks owned by Bluetooth SIG, Inc.
The illustrated product and specifications may differ slightly from those supplied. All other
trademarks and trade names are those of their respective owners.
Made in China

trademarks and Made in China



SOUND:CORE

true wireless earbuds

User's Manual for UZ-E044T

Wirefree Earbuds | Charging Case | Charging Cable | User Manual

FCC ID : 24S7\/-TWS12

IMPORTANT Please read before using this product

PAIR & CONNECT WITH A NEW DEVICE

- SOUND:CORE will turn on automatically once it is removed from charging case.
 It will blink alternately red and blue indicating that it is in pairing mode.
- Open the Bluetooth® menu on your smartphone and search for new devices
- When you see "UZ E044T" listed, tap it to connect.
- Once connected with your device, there will be a BEEP

NOTE: If one of the earphones doesn't power on when removed from charging case, tap and hold the power button for 5-8 seconds to power on.

TOUCH CONTROL

- Tap the side of either earbud twice to play or pause your music.
- Hold and Press the left earbud for 3 seconds to return to the previous track. Hold and Press the right earbud for 3 seconds to skip to the next track.
- Tap either earbud once to answer a call. You can tap either earbud once during a call to
- When there is an incoming call, press and hold either earbud for 2 seconds to reject the call.
- Please note, holding for 3-5 seconds will power down the earbuds.

PLAY & CALLS

- Connect your device to these earbuds via Bluetooth® (see "Pair & Connect with a New Device.")
- Open your favorite music app and press play.
- All audio, including music, calls, games, videos, and notifications will be routed through the earbuds.

CHARGING

EARBUDS

- Checking the "R" and "L" indicators on the charging case, place the right and left earbuds into the corresponding slots so that the magnetic metal charging contacts line-up correctly
- The LED indicators on the earbuds will glow red and the charging indicators on the case will glow blue. Your earbuds are now charging.
- Once your earbuds are fully charged the LED indicators will turn solid blue. After approximately 30 seconds the LED indicators will turn off.

- CASE
 When the case is charging, the led light will illuminate red. When charge is complete, all the
- * Note: the case can charge the earbuds while charging itself.


RECONNECT TO YOUR DEVICE

- You only need to pair your Bluetooth® device with these earbuds once.
- With your device's Bluetooth® feature turned on and in range, power on the
- left & right earbuds.
- They will automatically connect to each other and to your smartphone.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device and select "UZ E044T" from the list of paired

POWER ON/OFF

NOTE: Earbuds Turn On/Off automatically when removed from or returned to case

- To power on manually, tap and hold for 3-5 seconds, the LED lights will begin to flash.
- To power off manually, tap and hold the power buttons for 3-5 seconds.









IMPORTANT: Please follow these directions in the proper order to ensure the earbuds pair and connect properly. NOTE: If one of the earphones doesn't power on wher removed from charging case, tap and hold the power button for 3-5 seconds to power on.

SOUND:CORE will turn on automatically once it is removed from charging case. It will blink alternately red and blue indicating that it is in pairing mode.

- 2. On your smartphone open the Bluetooth® menu, power on your Bluetooth® setting and search for new devices.
- 3. When you see UZ E044T listed, tap it to connect.
- 4. Once connected with your device, there will be a BEEP from the right earbud.

If your device asks for a passcode to connect, enter "0000".