EUT Photographs

1.1 EUT Host Unit – Front View



1.2 EUT Host Unit – Rear View



1.3 EUT Host Unit – Top View




1.4 EUT Host Unit – Bottom View



1.5 EUT Host Unit – Right Side View




1.6 EUT Host Unit – Left Side View



1.7 EUT Host Unit – Board View WWAN Antennas Location t de de de de di gigg de de du de de d 00400 10 20 30 40 50 60 70 84 WWAN Radio Location 00 10 20 30 40 50 60 ESD **RFID** Radio and Antenna Location os os

1.8 EUT WLAN/BT Module – Zoomed In View



1.9 Updated WLAN/BT Antennas View

