

RIM 902M radio, an application that uses one of these protocols must be installed on the computer and configured to communicate on COM4.

Cisco Wireless LAN

- Go to your preferred LAN application and run normally

CAUTION While the RIM 802 radio is operating, the antenna must be at least 2.0 cm from all persons in order to comply with the FCC RF exposure limit. Radio (wireless modem) operators must make sure their radio unit is in compliance with [these FCC regulations](#). See [Optional Equipment and Accessories](#) for important information about vehicle-mounted antennas.



79_0100_001

[© 2001 Itronix Corporation. All rights reserved.](#)

Power Management



5. Power Management Topics

GoBook Pro Help

Using the Battery

Monitoring Battery Power

There are two ways to monitor how much power the battery has left.

1. Click Start, Settings, Control Panel, Power Management (Power Options); then click the Power Meter tab.
2. Moving the cursor to the battery icon on the [taskbar](#), without selecting anything, is the simplest way to check on battery power status. The status will show as a pop-up when you mouse-over the icon.

NOTE If you do not see the battery icon on the taskbar, enable it in Start, Settings, Control Panel, Power Management. Choose the Advanced tab and select “Always show icon on the taskbar.”

Low Battery Alarms