

FCC REGULATORY COMPLIANCE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

FCC REGULATORY COMPLIANCE (CONT.)

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

BATTERY WARNING


Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Operating temperature:
Charging: 0°C ~ 45°C
Discharging: -10°C ~60°C

E-LABEL NAVIGATION

The e-label can be found in the information selection of your device's settings.


FCC ID: FCC ID: 2AJXA-TC4
Product: iTouch Active 4 Tracker
Model No: TC4S01



1. Swipe down on your watch's home screen.
2. Click 'About' to view the product and model number information.
3. Click on 'Regulatory' to view the device's FCC ID.

MAINTENANCE

To make sure your watch is up to date, please check for watch firmware updates. You can find this in the device settings menu in the app.



To make sure you are using the latest version of the iTOUCH Wearables App, locate the version number by clicking the ≡ burger menu on the app.

ACCESSORIES

Customize your smartwatch even further by selecting different watch faces and changing your bands!

To view and purchase accessories for your watch, visit our accessories page online at the URL below:

itouchwearables.com/collections/all-accessories

To change your band, slide the lever with your finger to release or attach the band.



iTOUCH ACTIVE 4

UNPACK CONTENTS

Locate your watch and charging cable inside the box.



CHARGING

- 1. Insert the cable into a computer USB port or a UL-certified wall charger.
- 2. Line up the magnetic pins on the charging cable with the contacts on the back of the watch until it snaps into place.
- 3. A charging screen will appear to confirm your watch is charging.

*Charging can take up to 2 hours.
Note: avoid using fast-chargers



DOWNLOAD APP

Scan the QR code with your smartphone camera to download our free mobile app.




CREATING AN ACCOUNT

- 1. Open the app and click on "Sign Up".
- 2. You will be prompted to input your name, email address, and create a password, as well as agree to the terms & conditions.
- 3. A verification code will be sent to your email, which you will need to confirm your account.



CREATING YOUR USER PROFILE



Input your profile data, including gender, birthday, height, and weight.

Your birthday is required for data protection and privacy laws. Minimum age requirement for online account creation varies and is based on your region.


Your gender, height, and weight are used to improve accuracy of our activity tracking features.

PAIR YOUR WATCH



- 1. Make sure your watch is charged and close to your smartphone.
- 2. The app will bring you directly to the pairing screen to connect your watch.
- 3. Select your watch from the list of devices once it is detected.
- 4. A Bluetooth Pairing Request popup will be displayed on your smartphone (select pair).
- 5. Your connection is now established and you're now ready to enjoy the features of your new watch!

BASIC FUNCTIONS



- 1. **LONG PRESS THE SIDE BUTTON** to turn your watch on or off.
- 2. **PRESS THE SIDE BUTTON** to wake your watch or return to the previous screen.
- 3. **SWIPE UP** to view your health stats.
- 4. **SWIPE DOWN** to access Settings, Power, Reset, About, and Regulatory Information.
- 5. **SWIPE LEFT** to view a list of complete features.
- 6. **SWIPE RIGHT** to return to the main watch face.

THANK YOU FOR CHOOSING iTOUCH WEARABLES

Have questions?
For the full user manual, help, and answers to many common questions, visit us online



El manual en Español
se puede encontrar escaneando el código QR
Le manuel en français
peut être trouvé en scannant le code QR



1 year warranty



customer support

support.ityouchwearables.com
support@ityouchwearables.com

Enjoy your watch!

iTOUCH
WEARABLES