

FUNCTIONS

PHONE CALL CONTROL		
	Answer/Send Call	Phone
	Endless Call	Phone for 3.0 sec.
	Switch call mode	
	Answer: Phone and Answer: Speaker (during a call)	Phone for 3.0 sec.
VOICE RECORDING MODE		
	Activate Voice Activation	Phone for 3.0 sec.






[@ayyorginal](#)