

Front

Back

j5create®

Wireless N300 Dual Band USB Adapter

JUE302

Do **NOT** plug the Wireless 11N USB Adapter into the computer until the driver is completely installed.

If you have internet access it is **highly recommended** that you download the **latest driver** from www.j5create.com under **Support & Services** –scroll down to the product's driver you are installing and download the latest driver for your operating system.

Windows Driver Installation

Please follow the steps below to install your new wireless network card:

1. Insert the device driver CD into the CDROM drive on your computer, double-click the **Setup.exe** icon and run the **Setup.exe** program.

2. Select **I accept the terms of the license agreement** and then click **Next**.

3. Select the setup type that best suits your needs, **Install driver and Ralink WLAN Utility** is recommended.

4. Click **Next**, the **Select Configuration Tool** window will appear, you can manage this wireless adapter by either the **Ralink Configuration Tool** or the **Microsoft Zero Configuration Tool**.

5. Click **Next**, the ready to install window will appear.


6. Click **Install**, and wait while the installation is in process.


7. Finally, click **Finish** to complete the driver installation.



1


2

Connect to a Wireless Access Point



- After installation has finished, it will automatically try to connect to any unencrypted wireless access point. If you want to connect to a specific wireless access point, or the access point you want to connect to uses encryption, you have to configure the wireless network card and input the correct password to connect to the wireless access point. To do this, double-click the  icon.
- The following window will appear:







- Click the  icon to scan available wireless access points. Scan results will display in the **Network** zone. If you can't find the access point you want to connect to, click the  refresh button, until your wireless access point is displayed.



- Double-click the wireless access point's SSID you want to use. If the access point is encrypted, you should follow the prompts to select the appropriate encryption type and enter your password.

- After you have connected to the wireless access point successfully, you can get detailed information on the connected access point such as status, IP address, speed, etc. Click the  icon, then the  icon, here you will see the signal quality and signal strength information.

3

4


5


6



7


8

Connect to a Wireless Access Point



- After installation has finished, it will automatically try to connect to any unencrypted wireless access point. If you want to connect to a specific wireless access point, or the access point you want to connect to uses encryption, you have to configure the wireless network card and input the correct password to connect to the wireless access point. To do this, double-click the  icon.
- The following window will appear:







- Click the  icon to scan available wireless access points. Scan results will display in the **Network** zone. If you can't find the access point you want to connect to, click the  refresh button, until your wireless access point is displayed.



- Double-click the wireless access point's SSID you want to use. If the access point is encrypted, you should follow the prompts to select the appropriate encryption type and enter your password.

- After you have connected to the wireless access point successfully, you can get detailed information on the connected access point such as status, IP address, speed, etc. Click the  icon, then the  icon, here you will see the signal quality and signal strength information.

3

4


5


6



7


8

Connect to a Wireless Access Point



- After installation has finished, it will automatically try to connect to any unencrypted wireless access point. If you want to connect to a specific wireless access point, or the access point you want to connect to uses encryption, you have to configure the wireless network card and input the correct password to connect to the wireless access point. To do this, double-click the  icon.
- The following window will appear:







- Click the  icon to scan available wireless access points. Scan results will display in the **Network** zone. If you can't find the access point you want to connect to, click the  refresh button, until your wireless access point is displayed.



- Double-click the wireless access point's SSID you want to use. If the access point is encrypted, you should follow the prompts to select the appropriate encryption type and enter your password.

- After you have connected to the wireless access point successfully, you can get detailed information on the connected access point such as status, IP address, speed, etc. Click the  icon, then the  icon, here you will see the signal quality and signal strength information.

3

4


5


6



7


8

Connect to a Wireless Access Point



- After installation has finished, it will automatically try to connect to any unencrypted wireless access point. If you want to connect to a specific wireless access point, or the access point you want to connect to uses encryption, you have to configure the wireless network card and input the correct password to connect to the wireless access point. To do this, double-click the  icon.
- The following window will appear:







- Click the  icon to scan available wireless access points. Scan results will display in the **Network** zone. If you can't find the access point you want to connect to, click the  refresh button, until your wireless access point is displayed.



- Double-click the wireless access point's SSID you want to use. If the access point is encrypted, you should follow the prompts to select the appropriate encryption type and enter your password.

- After you have connected to the wireless access point successfully, you can get detailed information on the connected access point such as status, IP address, speed, etc. Click the  icon, then the  icon, here you will see the signal quality and signal strength information.

3

4


5

6

7

8

Connect to a Wireless Access Point

- After installation has finished, it will automatically try to connect to any unencrypted wireless access point. If you want to connect to a specific wireless access point, or the access point you want to connect to uses encryption, you have to configure the wireless network card and input the correct password to connect to the wireless access point. To do this, double-click the  icon.
- The following window will appear:

j5create

Model Name	JUE301+302	Color	Black only	Scale	100%	Designer	Alexia	Ver	V1-D
Part Name	FCC Sticker	Dimension	展開尺寸：180X95mm 成型尺寸： 60X95mm	Unit	mm	Date	2014/12/26		
Material	80P模造紙	Notes	1. 雙面黑白印刷 2. 彈簧折						

FCC Warning Statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Exposure Warning:

This device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.

The product is restricted for indoor use only.