

User Manual Item: #20004 - LED Candle **Smart Color & Tunable White**

WELCOME TO LEXI

USER GUIDE OPERATION

- 1. In order to add new devices to your Lexi when the light has not been paired) Mobile App, first follow the instructions for connecting your Lexi Portable Hub to your wireless network.
- 2. Power on your light(s), you'll see the light(s) flashing with cool white color 3. Select "ADD NEW DEVICE" on the LEXI Mobile App and follow the instruction to complete adding the light(s). During this process you'll see the light transition to warm white flashing as it goes through the 5. Take out the LED Candle from the association process until it stops flashing and remains on warm white color.
- 4. Your light has been added to the LEXI Mobile App successfully and ready to use. switch is located at On position. 5. Remember to pair the LED Candles one 7. During charging the LED Candle cannot by one to the LEXI Mobile App so that they can be individually controlled afterwards.
- 6. To learn more about detail function and special effect, Please go to www.lexidevices.com

CHARGING THE LED CANDLE

- 1. Turn on the switch under the LED Candle. (You may see the light is flashing with white color, this is the normal state
- 2. Plug-in the LED Candle(s) to the 3.5mm connector on the Charging Base.
- the 3.5mm connector to the socket at the played with by children. side of Charging Base. During charging the LED Candle will be light-up with red. 4. Charge for approximately for 6-8 hours. The LED Candle will turn green when fully
- charaed.
- Charaina Base, and turn off the candle light to save power. 6. During charging, make sure the On/Off
- be controlled by the LEXI Mobile App.

WARNINGS AND CAUTIONS:

- LED Candle with fire.
- Keep away from liquids and humidity.
- The product is for indoor use only. Do not use in wet locations, directly exposed to water or outdoors.
- 3. Connect the DC 5V 1A adapter, plug-in This product is not a toy designed to be
 - Do not place on hot surfaces.
 - Do not be exposed to extreme temperatures, direct sunlight and moisture.
 - For safety reasons and under the terms of out, deleted or rendered illegible on the the warranty, none of the enclosed devices should be opened.
 - Only use the adapter supplied: using a different adapter can damage the product.

WARRANTY:

- This is an artificial candle. Do not light the LEXI provided one-year warranty is valid if the product is used in accordance with the instructions and for its intended purpose. Claims will only be accepted on submission of the original proof of purchase (invoice, sales slip or receipt) stating the purchase date, the name of the dealer and a description of the product with product ID labeled at the products.

The LEXI's warranty lapses if:

- a. Anything has been changed, crossed purchase docket or product description. b. The failure is caused by damage, faulty connections or abuse.
- c. A defect is caused by extreme circumstances not inherent to the product, for example, lighting, flooding, fire, incorrect use or negligence. d. The product has been opened or disassembled.
- e. using a different adapter other than we provided

TROUBLESHOOTING

- Ensure your device is within 45 feet of the BLE Frequency: 2402-2480MHz Lexi Portable Hub without obstacles
- Check the On/Off switch is located at On position (even at charging)
- Make sure the light is charged.
- Confirm your smart phone is paired with LEXI Portable Hub
- times in quick succession using the LEXI Mobile App. Afterwards, you'll see a cool white flashing. (A warm white will be flashing at the 5th power cycle which is a warning signal for you. If you don't want to un-pair it, stop the power cycle. The light will go back to the last state). Then, re-pair cleaned with a soft dry cloth. Do not use this light in the User Guide section.

WIRELESS SPECIFICATION:

Wireless communication protocol: IEEE 802.15.4

Channel: 0-39 channels

ENVIRONMENTAL SPECIFICATION:

Temperature (operation): -5...40°C - To un-pair the lights turn the light on/off 6 Temperature (storage): -25...60°C Relative humidity: 5-90% non-condensing

CLEANING AND MAINTENANCE:

Do not clean when the product is on and connected to mains power. To avoid scratching, the product should only be cleaning agents.

PLEASE KEEP THIS PACKAGING FOR FUTURE REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

DISPOSAL OF YOUR OLD PRODUCT:

Your product is designed and manufactured with high quality materials and component, contains non-removable following two conditions: Lithium-Ion battery, which can be recycled and reused. When this crossedout wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.

Please find out for yourself about the local expressly approved by the party separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

FCC WARNING AND CAUTION:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the
- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications to this unit not responsible for compliance could void the user's authority to operate the equipment. following measures: FCC ID: 2ATOT20004
- Shielded Cables must be used with this unit to ensure complaince with the Class B **FCC** limits

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed radio/TV technician for help. to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced

