



XIBERIA
G01

Instruction manual

Wearing a headset

G01

Headset specifications

- Model: G01
- Headset battery capacity: 180mAh battery 3.7V/300mAh
- Working time: about 8 hours (70% volume)
- Charging time: about 4 hours
- Standby time: about 200 hours
- Input charging standard: USB TYPE-C/5V2A
- Frequency response: 20Hz-20KHz
- Impedance: 16Ω
- Sensitivity: 104±3dB/1kHz
- RF sensitivity: 302.5MHz/300MHz (optional)
- Effective distance 100m—linear transmission distance is about 1000m

Headset adjustment

Adjustment of the wearing position



- Headphones
- Volume adjustment
- Switch button
- Microphone swing
- USB plug hole
- 3.5mm headphone cable
- Microphone mute button
- Directional microphone
- Volume control
- USB charging cable
- 3.5mm headphone cable

Overview



Headset charging

We recommend charging the battery before use for the first time.

When the charging cable is connected, the red light on the ear cup will return to the charging state.

Connect LED light	charging
Red	Charging
Red+Blue	Full charged

Headset pairing

The headset and USB wireless adapter are paired and ready to use at the factory. If the headset transmitting power is insufficient, you can try following the steps below (it is recommended to contact technical support personnel before going to Step 6 if it is necessary).

- Turn off the headset.
- Unplug the USB wireless transmitter and reconnect it.
- Go to power button according to the button mode.
- Setting that the blue LED is on is indicating that the connection is successful.

Headset connection mode

The headset can be used as a wired headset with the included 3.5 mm audio cable. To use the headset as a wired headset, the headset has been successfully connected.

Headset has a power button that can be used in the following ways:

- Insert the 3.5 mm headphone cable into the device

On/Off

Power on: The headset is in the off state. Press and hold the power button 1 seconds to hear the power-on tone, and the blue status light flashes.

Power off: Press and hold the power button 3 seconds to hear the power-off tone, and the blue status light flashes.

Headset pairing

The headset and USB wireless adapter are paired and ready to use at the factory. If the headset transmitting power is insufficient, you can try following the steps below (it is recommended to contact technical support personnel before going to Step 6 if it is necessary).

- Turn off the headset.
- Unplug the USB wireless transmitter and reconnect it.
- Go to power button according to the button mode.
- Setting that the blue LED is on is indicating that the connection is successful.

Headset connection mode

The headset can be used as a wired headset with the included 3.5 mm audio cable. To use the headset as a wired headset, the headset has been successfully connected.

Headset has a power button that can be used in the following ways:

- Insert the 3.5 mm headphone cable into the device

Headset connection and configuration

To use the headset with the PlayStation™4 (PS4) or PS5™, do the following:

- Open your PS4 game console.
- Connect the USB wireless adapter to the USB port on the PS4/PS5. The wireless adapter status light will flash to indicate that it is waiting for a connection.
- Hold the power button on the headset for 3 seconds to turn it on. Follow the wireless adapter status indicator and the wireless headset LED are always on, the headset is connected.

1. Right-click the speaker icon on the taskbar and select "Play Device".

2. Click on the "Recording" tab, then "Right-click on "XIBERIA G01 device" and select "Play Device".

After detaching the "G01 Wireless Headset" device, configure the PS4/PS5 device as follows:

- Go to the Settings menu and select it.
- Highlight the Device menu option and select it.
- Select menu "Audio Input/Output" and select it.
- Set the "Output Device" to the XIBERIA G01 Wireless Headset.
- Select "Output Device" to the XIBERIA G01 Wireless Headset.
- Select "Output Device" and select "Yield".

3. Right-click on "XIBERIA G01 Device" and select "Set as Default Device".

4. G01 wireless headphones can be used.

Headset connection and configuration

To use the headset with the PlayStation™4 (PS4) or PS5™, do the following:

- Open your PS4 game console.
- Connect the USB wireless adapter to the USB port on the PS4/PS5. The wireless adapter status light will flash to indicate that it is waiting for a connection.
- Hold the power button on the headset for 3 seconds to turn it on. Follow the wireless adapter status indicator and the wireless headset LED are always on, the headset is connected.

1. Right-click the speaker icon on the taskbar and select "Play Device".

2. Click on the "Recording" tab, then "Right-click on "XIBERIA G01 device" and select "Play Device".

After detaching the "G01 Wireless Headset" device, configure the PS4/PS5 device as follows:

- Go to the Settings menu and select it.
- Highlight the Device menu option and select it.
- Select menu "Audio Input/Output" and select it.
- Set the "Output Device" to the XIBERIA G01 Wireless Headset.
- Select "Output Device" to the XIBERIA G01 Wireless Headset.
- Select "Output Device" and select "Yield".

3. Right-click on "XIBERIA G01 Device" and select "Set as Default Device".

4. G01 wireless headphones can be used.

www.xiberia.net

FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.