FIGURE 7
LED LAMP (G117P38MO6C)
COVER REMOVE



FIGURE 8 LED LAMP (G117P38MO6C) MAINBOARD FRONT




FIGURE 9 LED LAMP (G117P38MO6C) MAINBOARD BACK




FIGURE 10 LED LAMP (G117P38MO6C) LED FRONT




FIGURE 11 LED LAMP (G117P38MO6C) LED BACK




FIGURE 12 LED LAMP (G117P38MO6C) CONTROL BOARD FRONT




FIGURE 13 LED LAMP (G117P38MO6C) CONTROL BOARD BACK



Antenna

FIGURE 14 LED LAMP (G117P38MO6C) CHIP & CRYSTAL ON BOARD



-END-