FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: a) Reorient or relocate the receiving antenna b) Increase the separation between the equipment and receiver c) Connect the equipment into an outlet different from that to which the receiver is connected d) Consult the dealer or an experienced radio/Ty technician for help.

Note 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

One (1) Year Limited Warranty

PCT Brands, LLC warrants this product to be free from defects in materials and workmanship. This warranty covers the original purchaser only, and is not transferable to anyone who subsequently buys, leases, or otherwise obtains from you. Your One Year Limited Warranty begins on the date of purchase. Your original purchase invoice or sales receipt, showing date of purchase, is your proof of warranty period. The duration of this warranty does not extend beyond the initial period of coverage should any repairs or replacements be made or performed.

This warranty does not extend to any product not purchased from PCT Brands, LLC, or an authorized PCT Brands, LLC reseller. This warranty does not extend to product that has been damaged or rendered defective as a result of use for which the product is not intended, is contrary to instructions provided in the user manual, as a result of the use of parts not manufactured or sold by PCT Brands, LLC, or due to any misuse, abuse, negligence, modification, or improper packing when returning product to PCT Brands, LLC. EXCEPT FOR THE WARRANTY SET FORTH HEREIN, PCT BRANDS, LLC DISCLAIMS ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY APPLICABLE LAW ARE LIMITED TO THE TERM OF THIS WARRANTY. IN NO EVENT SHALL PCT BRANDS, LLC BE LIABLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF BUSINESS, PROFITS, DATA OR USE, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT. YOU AGREE THAT REPAIR, AND (UPON AVAILABILITY) REPLACEMENT, AS APPLICABLE, UNDER THE WARRANTY SERVICES DESCRIBED HÈREIN IS YOUR SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO ANY BREACH OF THE PCT BRANDS, LLC LIMITED WARRANTY SET FORTH HEREIN. THIS WARBANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

How Do I Obtain Warranty Service?

For warranty service, please email warranty-Hyrixprysm@pctbrands.com or call (248) 236-0061 to report a claim, at which time PCT Brands, LLC technicians will attempt to solve any issues. If unable to resolve your issue, you will be issued an RMA to authorize the return of the item for repair/replacement. All charges incurred while returning product, including postage, duties, export taxes, and customs duties, are the responsibility of purchaser, and purchaser assumes all risk of loss during shipment. For more information wist www.poctbrands.com



PCT Brands is a division PC Treasures, LLC, 3720 Lapeer Rd., Auburn Hills, MI 48326, Made in China

PCT Brands, the PCT Brands logo, Lyrix, the Lyrix logo, Prysm, the Prysm logo are trademarks or registered trademarks of PCT Brands, LLC. Bluetooth is a registered trademark of Bluetooth SIG, Inc. © 2016 PCT Brands. LLC. All rights reserved.



USER GUIDE



BI-068/FCC ID:2AHLIBT-068




Package Contents

Lyrix Prysm Bluetooth Speaker Micro-USB to USB Charging Cable User Guide









Specifications:

Bluetooth: V2.1+EDR Wireless Range: 33' Speaker: 4Ω/3W Battery: 1200mAh Lithium Polymer

4 Hours of Battery-Powered Play Time

Size: 5.3" x 2.1" x 1.5" One-Year Warranty Play/Pause/Answer Phone
Increase Volume/Advance
to Next Song
Decrease Volume/Go to
Previous Song

. LED Light Display Control

Technical Support

Email: support+lyrixprysm@pctbrands.com

Phone: (248) 236-0061 9:30am - 5:30pm EST, M-F.

Usage Instructions

- Never disassemble the Lyrix Prysm in an attempt to make repairs.
- · Always supervise children when using Lyrix Prysm.
- Do not expose Lyrix Prysm to moisture or high temperatures.
- Metal rust, surface damage, and other forms of oxidation are not covered under the One-Year Warranty.

Pairing Instructions

- 1. Move the On/Off switch to ON.
- 2. Lyrix Prism will automatically enter Pairing Mode.
- 3. Search for and select "Lyrix Prysm" on the pairing device.
- 4. Enter PIN/and Password (if required).

Charging Instructions

Plug the micro-USB cable into the charging port of Lyrix Prysm, and connect the USB end to your computer or wall charger (not included). Input should not exceed DC 5V-1A. The indicator light by the micro-USB port will illuminate red while charging, and turn off when fully charged.

LED Light Display Mode

When the On/Off switch is turned to ON, an LED light cycle will begin. Press the LED light button once to activate the interactive LED light sequence. Press the light button twice to turn the LED light display off.

Bluetooth and Auxiliary Mode Controls

- Press and hold + to increase volume. Press once to hear the next song.
- Press and hold to decrease volume. Press once to replay the current song. Press multiple times to go back to the previous song desired.
- Press ▶I once for Play, Pause, Answer Call, and End Call.
- Press and hold ►I to end the Bluetooth connection.

How to Properly Dispose of Batteries

This product contains a lithium polymer battery. To properly dispose of expired batteries, view your city's website or newsletter to find what guidelines, if any, should be followed and to make note of their hazardous waste collection days.

Battery Warning

Lithium Polymer batteries can expand, burst, or catch fire if used incorrectly, causing both property damage and or personal injury. It is essential that you follow all the included instructions and safety warnings in full. The manufacturer, distributors, and retailers will assume no liability for the failure to comply with these safety instructions and warnings.