






NTNV-n41-PC2-30-10-M-CP-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-10-M-CP-256QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-10-H-DFT-BPSK-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-10-H-DFT-QPSK-Outer\_Full-Ant1-  
PASS






NTNV-n41-PC2-30-10-H-CP-16QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-10-H-CP-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-10-H-CP-256QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-15-L-DFT-BPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-15-L-DFT-QPSK-Outer\_Full-Ant1-1  
PASS



NTNV-n41-PC2-30-15-L-DFT-16QAM-Outer\_Full-Ant1-1  
PASS




NTNV-n41-PC2-30-15-L-DFT-64QAM-Outer\_Full-Ant1-1  
PASS



NTNV-n41-PC2-30-15-L-DFT-256QAM-Outer\_Full-Ant1-1  
PASS




NTNV-n41-PC2-30-15-L-CP-QPSK-Outet\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-L-CP-16QAM-Outet\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-L-CP-64QAM-Outet\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-L-CP-256QAM-Outet\_Full-Ant1-PASS





NTNV-n41-PC2-30-15-M-DFT-256QAM-Outer\_Full-Ant1-PASS



NTNV-n41-PC2-30-15-M-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-256QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-15-H-DFT-BPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-15-H-DFT-QPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-15-H-DFT-16QAM-Outer\_Full-Ant1-  
PASS








NTNV-n41-PC2-30-15-H-CP-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-15-H-CP-256QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-20-L-DFT-BPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-L-DFT-QPSK-Outer\_Full-Ant1-  
PASS






NTNV-n41-PC2-30-20-L-CP-16QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-L-CP-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-L-CP-256QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-20-M-DFT-BPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-M-DFT-QPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-M-DFT-16QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-M-DFT-64QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-20-M-DFT-256QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-M-CP-QPSK-Outer\_Full-Ant1-PASS



NTNV-n41-PC2-30-20-M-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-20-M-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-20-M-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-20-H-DFT-BPSK-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-20-H-DFT-QPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-H-DFT-16QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-20-H-DFT-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-20-H-DFT-256QAM-Outer\_Full-Ant1-PASS



NTNV-n41-PC2-30-20-H-CP-QPSK-Outer\_Full-Ant1-PASS



NTNV-n41-PC2-30-20-H-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n41-PC2-30-20-H-CP-64QAM-Outer\_Full-Ant1-PASS







NTNV-n41-PC2-30-20-H-CP-256QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-30-L-DFT-BPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-30-L-DFT-QPSK-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-30-L-DFT-16QAM-Outer\_Full-Ant1-  
PASS







NTNV-n41-PC2-30-30-L-CP-64QAM-Outer\_Full-Ant1-  
PASS




NTNV-n41-PC2-30-30-L-CP-256QAM-Outer\_Full-Ant1-  
PASS





NTNV-n41-PC2-30-30-M-DFT-BPSK-Outer\_Full-Ant1-  
PASS





NTNV-n41-PC2-30-30-M-DFT-QPSK-Outer\_Full-Ant1-  
PASS














NTNV-n41-PC2-30-40-L-DFT-BPSK-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-40-L-DFT-QPSK-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-40-L-DFT-16QAM-Outer\_Full-Ant1-  
PASS



NTNV-n41-PC2-30-40-L-DFT-64QAM-Outer\_Full-Ant1-  
PASS