



SUPREME TOYS (H.K.) LTD.

ITEM NO. 99/05

CAUTION:

1. Your Transceiver Set has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replacing the battery.
2. When the sound becomes weak, it is time to change the Battery.
3. After use, always return the "ON-OFF" Switch to the "OFF" position.
4. Keep your set in a dry and clean place.

HOW TO OPERATE YOUR TRANSCEIVER:

1. Open battery cover and snap in a 9-volt battery.
2. Turn the "ON-OFF" switch to "ON" position. Your transceiver is now ready to operate.
3. Press the "PUSH-TO-TALK" switch for transmitting.
4. Release the "PUSH-TO-TALK" switch for receiving.
5. When transmitting, speak clearly in a normal voice, holding the set about 3" from your mouth.
6. Best transmission and reception are obtained when the antenna is held in a vertical position.

HOW TO USE MORSE CODE FUNCTION:

1. For transmitting a signal, turn the "ON-OFF" switch to "ON" position.
2. While pushing the "PUSH-TO-TALK" button, press in the morse code button momentarily and release for desired signals.
3. For receiving a signal, adjust volume control for normal listening level.
4. When back to voice communications again, use normal "PUSH-TO-TALK" operation.

REMARK:

Modifications not authorized by the manufacturer may void users authority to operate this device.