


1. Select Settings with the remote control in the main interface below.



2. After entering Settings, select Information to see the FCC ID number and statement as shown below.

