	Product parameters	Product Schematic Description	Product operating instructions	LED guide light	Take responsibility for your listening ability	Precautions	Warranty Service	FCC Warnning:
M MONSTER [®]	Bluetooth version V5.4	_ ●	3. Volume control Turn up the volume: Press + for the volume.	Mode Operation method Sound prompt Indicator Power On Press the button of the switch machine for 3 seconds, "source_on" "mover_on" The cellule sights on for a pression of the switch machine for 3 seconds, "source_on"	To avoid hearing damage, make sure to turn down the volume of the music player before connecting the headphones. After putting on the headphones, slowly adjust the volume to the right level. The noise level is measured in decible (GM). Exposure to noise levels of 85dB or	 Regular cleaning, long life, if not used for a long time, it is recommended to charge once every 15 days to extend battery life, the charging part of the headset tail plug is often 	Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Pules. These limits are designed to provide reasonable
	Transmission distance 10m Driver diameter 40mm	Volume plus button	An promption is played at the maximum volume. Turn down the volume: short press the volume "-", An announcement trone is played at the minimum volume.	Power On Earphone on Yower_on Iong time and goes out for 5 Power Of Earphone of Yower_off The red gifts to for a long time and goes out for 5 Power Off The head off the switch huttom for 5 seconds, The head off the switch huttom for 5 seconds, The head off the switch huttom for 5 seconds, the sphone off Yower_off The red gift to for the switch and goes out for 15 Pairing The head off the suitch switch and goes out for 15 Lead black automatically enters the pairing state To be load off to fill	higher may cause progressive hearing loss. Monitor usage; Hearing loss is the result of both too much noise and time. The louder the sound, the less time you have to spend in it. The softer the sound, the longer you can listen. This noise level (dB) table compares and ranks	wiped with cotton swab alcohol, which can help smooth charging, avoid bad contact, affecting the use experience.	User info	protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there
	Driver impedance 16Ω±15% Sensitivity 97dB±3dB	Volume reduction button Multi-function Button (MFB)	4. On the phone Accurate (and a call Short parce MER	Paring after being turned on paring flicker alternately After the phone saarches for the Bluetooth pairing Connected name, click the pairing name to connect and the connection is successful "connected" ice blue light blinking slowly and the connection is successful	commonly-heard sounds with their potential to cause hearing loss. Make the best use of your equipment and enjoy the best sound from a safe range. Our headphones allow you to capture more sound detail at an unprecedented low volume. Learn how to establish a secure	 Ine battery (battery pack or battery combination) shall not be exposed to lighting, baking or similar overheating environment. 	Contact number Postal code	is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the
	Frequency response 20Hz-20KHz Battery capacity 600mAh 3.7V	Charging Type-C jack	Answerzenia a cail: Short press MFB Reject an incoming call: Long press MFB for about 2 seconds Last Call Redial: Double tap MFB to redial the last call number.	Low battery slarm Prompt tone "battery_low" The red light flashes tatus Charging status Connect random wing for charging / The red indicator light is	listening level and review other important safety guidelines on the Consumer Electronics Association vebsite (www.cc.org). Important information on how to prevent noise-induced Hearing loss (NIHL) and a complete list of the types of noise that can cause hearing loss can be found on the leader of measurement Research Environment ion watch at a tWMW.df or	3. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use. It may be normal to have a brief, slight sound delay during the playing of music.	Mailing address Product information	interference by one or more of thefollowing measures: Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver.
	Music playtime ≈60 hours Charging time ≈2 hours	The switch machine key	5. Music Play/pause: Short press MFB; Previous sone: Long press the volume "+" button for 2 seconds:	Charging completed / / Le blue light is always on	FCC statement	Warnings	Product name Product number Product number	Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Cuition: Any changes or modifications to this dealer on experience another with another one of the second sec

PDE