E D C B A

F&D WARRANTY CARD

DISTRIBUTOR'S COPY

WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____

Last Name: _____

Address: _____

Contact No.: _____

Product Name: _____

Model No.: _____

Serial No.: _____

Date Purchased: _____

Invoice No.: _____

Retail Outlet Where Purchased: _____

_____

(Please print the name & address)

SECTION 2

F&D WARRANTY CARD

END-USER'S COPY

WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____

Last Name: _____

Address: _____

Contact No.: _____

Product Name: _____

Model No.: _____

Serial No.: _____

Date Purchased: _____

Invoice No.: _____

Retail Outlet Where Purchased: _____

_____

(Please print the name & address)

SECTION 1

WARNING!

LISTENING TO AUDIO AT EXCESSIVE VOLUMES CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

never exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please usethe following guidelines established by the Occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

90 dB SPL at 8 hours	**95 dB SPL** at 4 hours
100 dB SPL at 2 hours	**105 dB SPL** at 1 hours
110 dB SPL at ½ hours	**115 dB SPL** at 15 minutes
120 dB SPL Avoid or damage may occur	

Safety Precautions

WARNING

- If water or other foreign objects enter theinside of the device, fire or electric shock may result.
- Do not attempt to modify this product.
- Doing so could result in personal injur and/or product failure.

CAUTION

- Never disassemble or modify the device,as failures may result.
- Do not subject to extreme force and do not pull on the cable or failures may result.
- Keep the product dry and avoidexposure to extreme temperatures and humidity.

Adjusting

Collapsible design for easy storage.



Adjust the earcups up and down to fit the headphone to your ears.

Specifications

Bluetooth version:	Bluetooth 4.1
Transmission distance:	10m
Frequency:	20Hz - 20KHz
Drive unit:	40mm NdfeB speaker driver
Sensitivity :	105±3dB @1KHz
Mic sensitivity:	-42dBt±3dB
THD:	<0.1%
Supported headset, Handsfree, A2DP, and AVRCP Profile	

Package Contents

Stereo *Bluetooth*® headphone	1 pc
Audio cable	1 pc
USB charging cable	1 pc
Manual and warranty card	1 pc

Paragon

Bluetooth Headphone

F&D SINCE 1993

Model No.: HW620

Manual & Warranty card

Wireless Audio Controls



Wireless Connection



Press and hold "MFB" without cables for 2 seconds to turn on the wireless mode.

Press and hold "MFB" without cables again for 2 seconds to turn off the wireless mode.



Pair with the headphone when the function indicator light is blinking blue.

"Paragon" will appear on your audio device to indicate the headphone is ready to be paired.

Wired mode and Charging

Plug in the provided audio cable to turn on the **WIRED MODE**.

WIRED MODE will automaticlly overwrite the **WIREDLESS MODE**.

Charge the headphone using the provide micro USB cable.



Function and Operation

Pair to your *Bluetooth*® Phone

- Pair the *Bluetooth*® headset for the first time, the distance between the *Bluetooth*® headset and your *Bluetooth*® phone would be better within 1 meter when pairing.
- With the headset power off, hold and press "MFB" until the headset is pairing status, the function indicator light flash alternately.
- Start mobile phone *Bluetooth*® function.
- Search *Bluetooth*® device, Choose "Paragon".
- Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code.
- Repeat above-mentioned steps if the pairing was unsuccessful.
- The blue light will flash one time per 8 senconds if paired successfully.

* MFB:Multi-Function Button

Power On: Long press "MFB" for 2 seconds until the function indicator light flashes 2 times per 1 second.

Power off: With the headset on, long press "MFB" for 4 seconds, the function indicator light flashes 3 times per 1 second and goes off.

Answering a call: Press the answer key on your phone or short press "MFB" on your headset.

Ending a call: Press the end key on your phone or short press "MFB" on your headset.

Rejecting a call: Press the end key on your phone or long press the "MFB" button for 2 seconds on your headset.

Redialing the last called number: Double press the "MFB" button when headset is in standby mode.

Play/Pause: When you are listening to the music from the headset, you can short press "MFB" to play and pause.

Previous/Next Track: Previous Track when press the "v+" about 2 seconds. Next Track when press the"v-" about 2 seconds.

Volume control: Volume will be up when short press "v+" and will be down when short press "v-".

Low power alarm: When the headset is power on, if the battery volatge is lower than 3.3V, there will be a prompt.

Charging status: The power indicator light constant red means charging, constant blue means charged fully.

Low power shutdown: When the headset is power on, if the battery voltage is lower than 3.0V, the headset will shutdown automatically.

Call switching: Call switching between mobile phone and headset: during a call, long press "MFB", the audio will be switched from the *Bluetooth*® headset to mobile phone; Long press "MFB", the audio will be switched from mobile phone back to the *Bluetooth*® headset.

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase.We guarantee the provision of free services of F&D product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

1. The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.
2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)
   A. Parts:..... 1 year
   B. Technical service free..... 1 year
3. Under the following circumstances, service and parts will be chargeable even within the warranty period:
   A. Failure to present the warranty card and receipt when servicing is required.
   Full particulars not clearly shown or alterations made against the actual information.
   For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.
   B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occuring in transit by or from the customer.
   C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China
P.C. : 518108 Http://www.fenda.com

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

a b c d e