

TRUE WIRELESS EARBUDS



Thank you for purchasing the billboard true wireless earbuds. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.



Package contains: 1. Wireless earbuds 2. Charging Case 3. USB charging cable







RECONNECT TO YOUR DEVICE

You only need to pair your Blastooth" device with these earhuids once.

*With your device's Bluestooth" Resulte turned on and in arrage, remove the left & right.

*With your device's Bluestooth "Resulte turned on and in arrage, remove the left & right.

*Ply will allumonately corrected to each form and to your Bluestoofh" enabled device.

*Ply with was previously paired device that does not allust-reconnect, anysight to the Bluestoofh" estimps men on your device and elect." Bluestoofh "Estimps here on your device and elect." Bluestoofh "estimps the "som the jack of paired Bluestoofh" estimps to pair the each sold is all bluestoofh enabled sold instruction on how to per the each sold is all bluestoofh enabled sold.



TO REDUCE THE RISK OF INJURY

Do not heat, open, or dispose of product in fire.

Do not allow metal objects to touch the battery contacts on the earbuds and inside

charging case.

Do not expose battery pack to excessive heat.


TROUBLESHOOTING

No power

Music is not playing over Bluetooth both devices are paired and connected over Bluetooth®. Restart the earbuds to reconnect your Bluetooth® device.

Recharge your earbuds using the included USB charging cable. Try using a different USB cable. Make sure your Bluetooth® device has A2DP profile. Check

Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap " BB-BT-EB " and select "Forget." Now follow the steps to pair your device again



AUTO PAIRING

Open the charging case and take earbuds out, the earbuds will automatically turn on. To
pair the earbuds with your Bluetooth® enabled device, open the Bluetooth® setting on your
device and select.* BB-BT-EB "After the Initial pairing, the earbuds should pair to
the device automatically every time they are taken out of the case."

OPERATION

POWER ON/OFF
- Remove the earbuds from the charging case. The earbuds will automatically turn on.
- Place earbuds into charging case to automatically turn off.

PLAY/PAUSE MUSIC
When listening to music:
- Tap the left or right earbud once to play or pause the music.

PREVIOUS/NEXT SONG

When listening to music:

Tap the left earbud two times to go to Previous Song.

Tap the right earbud two times to go to Next Song.

VOLUME -/+ - Tap the right earbud three times to increase Volume. - Tap the left earbud three times to decrease Volume.

REJECT INCOMING CALL

VOICE ASSISTANT

- Press and hold left or right earbud for 3 seconds to activate Siri voice assistant.

- Press and hold left or right earbud for 3 seconds to activate Siri voice assistant.

- PLEASE NOTE: The Voice Assistant Feature is only available when the earbuds are p with your IQS Smartphone or Tablet device. This feature will not work with any other Blactooth' enabled devices connected to your earbuds.

CHARGING FUNCTION

RECHARGING THE BATTERY IN THE CHARGING CASE

There is a USB-C cable included in the box. Connect it to the USB type-C charging port on the charging case and the other end into a USB power source to charge your case. While charging, the LED lights on the charging case will flash.

The number on the outside of the case indicates how much battery. life the case currently has on a scale of 0-100%. When the battery of the charging case is fully charged , the number displays "100" on the charging case.

EARBUDS CHARGING
- Extracts light will turn sold red, and LED display of case will flash white. After fully charged, the Condition light will be made to fight on the extracts will go out.

Life to play of case will said white for several seconds and then go out.

Chick the extracts back into the originary case to recharge.

While charging, the LED indicator lights on the earbuds will turn solid Red. When the
earbuds have been completed charged, the LED indicator light on the earbuds will go out.

FCC Information
This device complies with Part 15 of the FCC rules. (1) this device may not cause. Operation is subject to the following two conditions: (1) this device may not cause. Operation is subject to the following two conditions: (1) this device may not cause. Operation is subject to the following two conditions: (1) the following the friender consequent infertence near the friender consequent infertence near the friender consequent infertence near the friender for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This sequence generates, uses and can radiate radio frequency cause harmful interference harmful interference in a residential installation. If this consequence is cause harmful interference to paid on the testion reception, which try to correct the interference by one or more of the following measures using the following the following the following the following the following the following measures of the following mea

receiver is connected.

- Consult the dealer or an experienced radiorTV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for complence could void the user authority to operate the equipment. Tested to comply with FCC standard. FOR HOME OR OFFEE USE.

Warning:
This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.



WARNING: CHOMNS HAZAND - Small parts.
Not for children under 3 years.

BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle batter according to local, state and national regulations.

Battery information
Your device is powered by a rechargeable battery. The full performance of a new battery
is achieved only after two to three complete charge and discharge cycles. The battery
can be charged and discharged hundreds of times, but it will eventually wear out.

can be charged and ascranged numbers of times, but if will eventually wear out. Duri disease a little charged battery contracted to a charger, overchanging may shorten its Duri disease and proceeding of the charged by the contraction of the charge over time. Never use any charger that is disrugged. Leaving the device in his of codd places will electude the capacity and lettime of the tablety. Optimal temperature for the battery is between 15°C and 25°C 15°C and 77°F. In tablety, Optimal temperature for the battery is between 15°C and 25°C 15°C and 77°F. In tablety, Optimal temperature for which the proceding own when the battery is the original of the contraction of the charge of the c

tully charged.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser will be fee from defective overhamship and materials for one year and agrees that will, all its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

labor for the time periods described.

This warrandy obsen on apply to any appearance items of the product nor to the additional excluded item() set forth below nor at any product the exterior of which has been damaged or deduced with relation or construction. The limited warranty described here is in addition to an applicable law. ALL IMPLED WARRANTES INCLUDING THE WARRANTES OF MERICHARDARIUM AND HITMSS FOR USE ARE LIMITED TO THE PREDOS FORM THE DATE OF ORGENTAL PUBLICATION.

ARILY FIRESSFOR USE ARE LIMITED TO THE PERIOD FROM THE DURLED FORGERS. TO FURTHER SETTEMENT BELLED TO FIRE THE SETTEMENT BELLED TO FIRE THE SET OF THE SET

of any searmants is beyond the time period described herein on the behalf of ES Case is Accessionic, Inc.

Concessionic, Inc.

Send product with \$11.95 shipping & handling fee to: ESI Cases & Accessories One Gateway Center, Suite 2600 Newark, NJ 07102 TechSupport@ESICellular.com

EARBUDS PAIR AS BB-BT-EB VENDOR ADD FCC ID