








802.11ax (20MHz) / 6115MHz / Chain C / NSS-4




802.11ax (20MHz) / 6115MHz / Chain D / NSS-4



802.11ax (20MHz) / 6255MHz / Chain A / NSS-4





802.11ax (20MHz) / 6255MHz / Chain B / NSS-4




802.11ax (20MHz) / 6255MHz / Chain C / NSS-4


802.11ax (20MHz) / 6255MHz / Chain D / NSS-4




802.11ax (20MHz) / 6415MHz / Chain A / NSS-4




802.11ax (20MHz) / 6415MHz / Chain B / NSS-4



802.11ax (20MHz) / 6415MHz / Chain C / NSS-4





802.11ax (20MHz) / 6415MHz / Chain D / NSS-4




802.11ax (20MHz) / 6435MHz / Chain A / NSS-4


802.11ax (20MHz) / 6435MHz / Chain B / NSS-4




802.11ax (20MHz) / 6435MHz / Chain C / NSS-4




802.11ax (20MHz) / 6435MHz / Chain D / NSS-4



802.11ax (20MHz) / 6475MHz / Chain A / NSS-4





802.11ax (20MHz) / 6475MHz / Chain B / NSS-4




802.11ax (20MHz) / 6475MHz / Chain C / NSS-4

802.11ax (20MHz) / 6475MHz / Chain D / NSS-4







802.11ax (20MHz) / 6535MHz / Chain C / NSS-4




802.11ax (20MHz) / 6535MHz / Chain D / NSS-4



802.11ax (20MHz) / 6695MHz / Chain A / NSS-4



802.11ax (20MHz) / 6695MHz / Chain B / NSS-4



802.11ax (20MHz) / 6695MHz / Chain C / NSS-4

802.11ax (20MHz) / 6695MHz / Chain D / NSS-4