

# HP-3059 Wireless Headphones IM

March 14 2024



**ICONIC**  
WIRELESS HEADPHONES  
INSTRUCTION MANUAL

### Table of Contents

- 1 Introduction.....1
- 2 Packaging Contents.....2
- 3 Connection Diagram.....2
- 4 How To Use.....3
  - 4.1 General Function.....3
  - 4.2 Pairing To Mobile Phone.....4
  - 4.3 Charging Your Product.....5
- 5 Product Specification.....6
- 6 FAQ.....6
- 7 FCC Statement.....7
- Battery Statement.....8

### 1. Introduction

Congratulations, and thank you for choosing the Iconic Wireless Headphones. This manual will help you operate the Iconic Wireless Headphones, but firstly you should familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Iconic Wireless Headphones.

#### Safety Rules

- Please follow the rules mentioned in this manual closely to ensure your safety. Before using the Bluetooth headphones, we should strongly encourage you to read through this user manual.
- Be more wary of any edges, corners, surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- Do not modify, repair or disassemble the Bluetooth headphones. Doing so may result in fire, electric shock, personal injury or damage to the Bluetooth headphones, etc. All are not covered under warranty.
- Do not use an electric or magnetic field to attack the Bluetooth headphones.
- Do not use the Bluetooth headphones in a hazardous location.

### 2. Packaging Contents



### 3. Connection Diagram



### 4. How to use

#### 4.1 General Functions

| Desired Result                   | Required Action                                                                                                                                                        |
|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Turn on & Enter the pairing mode | Press and hold the On / Off button for 3 seconds. After turning on, the LED indicator turns off.                                                                       |
| Pairing                          | Use a mobile phone with Bluetooth function or other Bluetooth device to perform necessary pairing action. After pairing, the LED indicator turns off.                  |
| Turn off                         | Press and hold the On / Off button for 3 seconds.                                                                                                                      |
| Charging                         | Plug the USB Type-C plug to the USB Type-C charging port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.                |
| Answering a Call                 | Press the On / Off button to answer phone call, press the On / Off button again to end call. Press and hold 3 seconds to reject call. Double click to reject the call. |
| Play / Pause Music               | Press the On / Off button to play music or pause music to toggle music.                                                                                                |

#### 4.2. Pairing to Mobile phone or other device

To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

#### Pairing to a phone and Entertainment:

- Turn on your phone and ensure the Bluetooth function is activated.
- Turn on the headphones, enter the pairing mode.
- Search your Bluetooth device on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few seconds the phone will list the "HP-3059" as a discoverable device. Select it and follow your phone's instructions to select this pairing.
- Your phone will confirm the pairing, and then press Play/Pause.

#### 4.3. Charging your headphones

For your safety, please always use an appropriate 5V input charger/adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

Use the USB Type-C cable accessory provided with the headphones. Connect the USB Type-C plug to the USB Type-C charging port on the headphones positioned at ① in headphones diagram on page 2. Connect the USB plug to a USB port on wall adapter to activate charging.

Make sure to keep the headphones charging for a minimum of 2 hours before initial use.



**Warning:**

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones if it has not been used for more than 6 months.

### 5. Product Specification

Driver Diameter: 40 mm  
Impedance: 32 Ohms  
Frequency Response: 20 Hz - 20 kHz  
Sensitivity: 100 dB +/- 3 dB  
Power Supply: Li-ion Battery 3.7V/ 180 mAh  
Playing Time: 3 - 6 Hours  
Charging Time: 2 Hours  
Bluetooth Range: 32.8 Feet  
Bluetooth Version: 5.3  
USB Type-C Charging Cable Included  
USB Type-C Charging Cable Rating 5W/1A Max.

**CAUTION:** The USB Type-C charging cable included with this item is intended for use with this product. Using any other USB Type-C charging cable to charge this product.

### 6. FAQ

- Why is there no power when the headphones is turned on?  
**Ans:** Ensure the battery has been charged up to 1 hour for initial use.
- There is no sound when playback.  
**Ans:** Check the connection between headphones with phone or computer. If the connection is not established, please connect again. Make sure the headphones is paired and connected with your target phone or other media device.

### 7. FCC Statement

**FCC statement**

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
a) The device may not cause harmful interference.
- The device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can receive radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a power outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement**

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable operation without restriction.

**Battery instructions for the lithium battery and charging the product**

The input voltage to be provided is 5V/1A.

In order to charge the product in safe manner and avoid conditions posing any other safety hazards, please observe the following instructions:

- Only charge the product at ambient temperature between 10 °C to 35 °C and 85% to 95% RH.
- Do not charge above 70 °C (158 °F) or at 95% or above in any location where the fire risk is high.
- Do not use the product after use.
- Please note that we won't take any responsibility for any safety operation (e.g. voltage higher than 5V, or the use may result in electric fire or loss of property) and we cannot control the operating process during the time for using the product.
- All necessary safety, health or misuse or different safety point can be used to determine real protection for the development or process development.

The Bluetooth® brand name and logo are registered trademarks owned by Bluetooth SIG, Inc. and used by us under license. All other trademarks and trade names are those of their respective owners.

Form: HP-3059

Manufactured by: JACMAS HP-3059  
101 Howard Street, Suite 200  
Alhambra, CA 91801

**FCC** FCC ID: JACMAS-HP-3059

Keep all relevant information for future reference.