

Here is the manual to pair your tracker:

Setting up your Ekster Tracker

1. Download the Chipolo App

Go to the App Store, download and install the Chipolo mobile application.

2. Create an account/log in

When you open the app for the first time you will see the instruction screen. Create an account or if you already have an account please select 'Log in'

- a. You can sign in with your Google or Facebook account.
- b. Or login in with your e-mail address and password.
- c. If you created a new account, open your email and confirm your email address (essential for password reset).

3. Add (+) your tracker

- . Once signed in press (+) in the app to add your Ekster Tracker.
- a. Now tap on 'Partner Products' and select Ekster Wallets in the next step

4. Pairing your tracker

- . Place your tracker next to your device
- a. Firmly Push the button twice on your Tracker (you will hear a beep sound)
- b. Once connected you will see the checkmark icon and the text 'Success!'.

FCC warning :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.