



CUT LINE

FOLD LINE

1.97 in

5.9 in

Important Safety Instructions:

WARNING When using this product, basic precautions should always be followed, including the following:

- Read all of the instructions before using the product
- To reduce the risk of injury, close supervision is necessary when the product is used near children
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth
- Do not turn up your radio's volume too loud in case of increasing its background noise
- Although the transmitting power of the FM transmitter is strong, to ensure the best sound effect, please try to avoid adjusting to the frequency of local radio station with strong signal
- Do not break or throw the product to prevent surface or unit damage

FCC ID:2A023-BTMC01 Model: CAC-33KL-2A Input: 12-24V DC 4A
Output: USB-A: 5V 3A, 9V 2A, 12V 1.5A USB-A2: 5V 3A
Total: 33W max Music format: MP3/WMA/AM/FM/FLAC/WAV
USB: (Max capacity): 32GB Frequency range: 88.0-108.0MHz
FM transmission distance: less than 5M Made in Vietnam

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Target Corp. Mpls. MN, 55403 Phone: 612-304-6073
For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

Just what you need, priced just right.™
100% Satisfaction Guaranteed or your Money Back.

We welcome any questions you may have at
Target.com/comments or 1-800-910-6874.

deal worthy™

Bluetooth FM Transmitter

Instruction Manual

Package Contents


- Bluetooth FM Transmitter - 1

Compatibility

- Bluetooth 5.3 devices

DO NOT PRINT

how to fold




page 5


page 6

front

Transmitter Installation Instructions



Plug the transmitter into your vehicle's cigarette lighter port/auxiliary power outlet. The LED display will light on and indicate the voltage of the car battery, then the device will enter Bluetooth pairing mode.



Use the Bluetooth settings on your device to pair with **FM Transmitter**. When the transmitter has successfully paired, it will connect back to your device automatically next time.



TOP:
LED screen
Two USB-A outputs
(Left: A1 Right: A2)
Microphone

Press: answer / end calls / reject call / play / pause
Double Press: radial
Hold: 3 seconds to enable frequency modulation mode
Hold: 5 seconds to switch music playback between Bluetooth / flash drive

Press: Previous track / decrease frequency (In frequency modulation mode)
Hold: Decrease volume / quick decrease frequency (In frequency modulation mode)

Press: next track / increase frequency (In frequency modulation mode)
Hold: Increase volume / quick Increase frequency (In frequency modulation mode)

Note: The transmitter will recall the last setting when turned back on. When the flash drive is playing, if there is an audio action on the mobile, it will be executed first. After the response is completed, it will return to its original state and continue playing. Bluetooth priority is higher than flash drive playback. Flash drive can only use the A2 port of USB-A. The transmitter only supports flash drives with FAT32 format

4 Please follow the FM frequency tuning instructions to set the transmitting frequency of the player and try to avoid local radio frequencies with strong FM signals. You can answer phone calls and play music through the transmitter.

Troubleshooting:

- If the transmitter will not charge your device, make sure that your device's cable is fully plugged into the transmitter and not damaged.
- If the device still won't charge make sure the transmitter is fully plugged into your vehicle's cigarette lighter port/auxiliary power outlet.

page 2

page 3

page 4