

FCC ID: WAF-TEST0316

IC: 6127B-TEST0316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Powerline test setup



Powerline test setup




FCC ID: WAF-TEST0316

IC: 6127B-TEST0316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Radiated Emission below 1000 MHz



Radiated Emission above 1000 MHz




FCC ID: WAF-TEST0316


IC: 6127B-TEST0316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Radiated Emission below 1000 MHz



Radiated Emission above 1000 MHz




FCC ID: WAF-TEST0316


IC: 6127B-TEST0316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Setup 30 to 200 MHz



Setup 200 to 1000 MHz




FCC ID: WAF-TEST0316


IC: 6127B-TEST0316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Setup EUT view below 1GHz



Setup 1 to 13 GHz




FCC ID: WAF-TESTO316

IC: 6127B-TESTO316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Setup EUT view above 1 GHz



Setup 30 to 1000 MHz horizontal, charging mode (TESTO)




FCC ID: WAF-TESTO316


IC: 6127B-TESTO316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Setup 30 to 1000 MHz vertical, charging mode (TESTO)



Setup 1000 to 13000 MHz horizontal, accumulator mode




FCC ID: WAF-TESTO316

IC: 6127B-TESTO316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Setup 1000 to 13000 MHz vertical, accumulator mode



Test setup charging, 1000-13000 MHz (TESTO)



FCC ID: WAF-TESTO316

IC: 6127B-TESTO316

HVINS: testo 316i, testo 316-1-EX, testo 316-2-EX

Test setup accumulator and Bluetooth, 1000-13000 MHz



Setup EUT with AC/DC adapter (TESTO)

