

S28, S10

1. Instructions for use

The transmitter

- 1, plug in the power DC5V, the screen has a digital display, the boot.
- 2, gear adjustment, press the "+-" key, gear 100-990 feet.
- 3, the dog out of the transmitter signal transmission range, the receiver will issue a warning. Warning mode: vibrate for 3-5 seconds and then electrostatically shock for 3-5 seconds. After two cycles, the receiver vibrates and reminds the dog to return to the active area with a buzzing sound.
- 4, when not in use, directly shut down.

receiver

1. Press on/key, and the indicator blinks three times, that is, the machine is turned on.
2. When charging, plug in the DC5V power supply, and the indicator light flashes quickly. When fully charged, the indicator light is steady on.
3. When the power is short, the indicator blinks slowly.
4. When not in use, press the on key to turn off the light.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction