

<h1>WIRELESS GEAR®</h1> <h2>TRUE WIRELESS STEREO EARBUDS</h2>  <p>USER MANUAL</p> <p>BC</p>	<p>Bluetooth Pairing: Using a pair of earbuds: Step 1: Open the upper cover of the charging box and take out the earbuds, then the earbuds are automatic pairing. Step 2: Either one earbud will flash blue/red once the two earbuds paired with each other successfully. Step 3: The earbuds are now ready to get paired with your Bluetooth device via the Bluetooth menu in your smartphone or another Bluetooth device. Simply open up the Bluetooth function on your phone device, select the pairing name "WIRELESS GEAR" from the list of Bluetooth device found, pair your earbuds with your phone. Step 4: Listen to music and enjoy it. Single click the left/right earbud to play/pause music, double click the left earbud to play the previous song, double click the right earbud to play the next song. Step 5: Single click any one earbud to answer an incoming call, then single click any one earbud again to end the call. Long press either one earbud for 2 seconds to reject an incoming call. Triple click either one earbud to redial last dialed number. Note: When in a call you can listen from both earbuds but only the master earbud can talk.</p> 	<p>Device Safety</p> <ul style="list-style-type: none"> Your True Wireless Earbuds have internal rechargeable batteries. Improper usage may result in the Earbuds becoming hot, ignite or burst and cause injury if exposed to conditions of abuse. Do not disassemble, throw away or damage the True Wireless Earbuds. Store the True Wireless Earbuds in a dry place, keeping environments such as salt air. Keep the True Wireless Earbuds away from direct sunlight, fire and high voltage equipment. Do not store the True Wireless Earbuds inside a car during hot weather. Remember a closed car acts as a green house allowing the inside to reach high temperatures. The True Wireless Earbuds are not a toy. Please keep them out of the reach of young children. Please do not discard the True Wireless Earbuds. Consult your local waste collection agency for proper disposal or recycling methods. You may also contact "Call2Recycle" at 877-272-2528 or at www.call2recycle.org for a battery recycling drop off location near you. <p>Additional Information. Make sure the earbuds are paired before use and the Bluetooth function is activated on your phone. Make sure the earbuds are charged before use. Safety use of the lithium battery The lithium batteries inside these products are not removable, do not attempt to remove these batteries.</p> 	<p>FCC Information FCC ID: 2AHLNR212 This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Federal Communications Commission (FCC) Statement This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide a reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Failure to comply with FCC standard, FOR HOME OR OFFICE USE. Warning: This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.</p>
<p>INTRODUCTION Thank you for purchasing the WIRELESS GEAR® True Wireless Earbuds. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.</p> <p>Package contains: a. Wireless Two Earbuds b. Charging case c. USB charging cable d. User manual e. Ear gel f.</p> 	<p>Automatic pairing: After the earbuds are paired once with your device, next time the pairing will be done automatically. In other words, you do not need to look for your Bluetooth device the next time you want to pair them with your device. The earbuds are paired with your phone or Bluetooth device automatically when turned on again. Note: When the earbuds on, if not paired to your device, the earbuds will automatically power off in a few minutes.</p> <p>Charging the earbuds. Place the earbuds into the charging case, the LED indicator of earbuds will be solid red during charging, the LED indicator of charging case will be solid red while. When the earbuds is fully charged, the indicator will turn off.</p> <p>Charging the charging case Please plug the charging cable into the charging port of the case, connect the charger to a USB power source, the charging case will flash white during charging. If charging does not start, disconnect the charger plug it in again and try. Charging the battery may take hours. When the battery of the charging case is fully charged, the four indicator light on the charging case will be solid white. Disconnect charger from the USB power source and the charging case.</p> 	<p>Battery Information Your earbuds are powered by a rechargeable batteries. The full performance of new batteries is achieved only after two to three complete charge and discharge cycles. The batteries can be charged and discharged hundreds of times, but will eventually wear out. • Do not leave a fully charged earbuds connected to a charger, overcharging may shorten their lifetime. If left unused, fully charged earbud batteries will lose their charge over time. • Never use any charger that is damaged. • Leaving the device in hot or cold places will reduce the capacity and lifetime of the batteries. Optimal temperature for the batteries is between 59°F and 77°F. A device with a hot or cold batteries may not work temporarily, even when the batteries are fully charged. • Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.</p> <p>Technical Support techsupport@esicellular.com or call (212) 883-8838 ESI Cases and Accessories 44 East 32nd Street, 8th Floor, New York, New York 10016</p> <p>Wireless Gear® is a registered trademark of ESI Cases & Accessories.</p> <p><small>All trademarks are the property of their respective companies. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.</small></p> <p>It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for listening by music.</p> 	<p>Limited Warranty ESI Cases and Accessories warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser, will be free from defects in materials and workmanship for one year and agrees that it will, at its option, either repair or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described. This warranty does not apply to any accessories, items of the product not in the additional exclusive period set forth below nor to any product the exterior of which has been damaged or defaced which has been exposed to misuse, abnormal use or handling of which has been altered or modified in design or construction. The limited warranty described herein is in addition to any applicable law. ALL WARRANTIES REGARDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE. SEE NOTES BELOW. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the salesperson of the dealer, nor any other person is authorized to make any warranties or to alter these expressed warranties or to extend the duration of any warranty beyond the time and period described herein or the warranty of ESI Cases and Accessories. The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases and Accessories and shall be the full and exclusive remedy available to the purchaser in connection with defects in the material and/or the workmanship of the product, in the manner and for the period of time described herein. All other warranties, including all implied warranties and responsibilities of ESI Cases and Accessories in the purchase and/or resale of the product and/or its parts shall constitute full satisfaction of all claims, whether known or not known, and shall be the sole and exclusive remedy of the purchaser. ESI Cases and Accessories is not responsible for any consequential or incidental damages, including but not limited to, lost profits, lost data, lost time, or any other damages, which may result from the use of the product. This warranty does not cover cables that have become frayed, cracked, or broken from use. The user should immediately replace this, or any, charge cable that has become frayed, cracked, or broken, as it may constitute a serious safety risk, including electrocution, if it is continued to be used. Send device with the product to: ESI Cases and Accessories 44 East 32nd Street, 8th Floor, New York, New York 10016 To be used as proof of purchase and to receive shipping and tracking.</p>

VENDOR: PLEASE ADD FCC ID