# The user manual of TV's WIFI module

### 1. The product description

The user can achieve TV connection WIFI net, through this module and the voltage supplied by the system to the module needs to be transmitted by a voltage regulator or circuit

The module installation method is as follows: pass the large round hole of the module through the limit column of the bracket of the TV, and fix the module by the snap-fit on the bracket. Connect the external IPEX antenna to the antenna pedestal of the module

#### 2. Basic parameters

Feature Description	Feature Description
Model	MWH414S
Product Name	WiFi Module
Interface	USB2.0
Supply Voltage	3.3V±0.3V
Dimension	15 (mm) *13 (mm) *2.4(mm)
Operating Temperature	-10° C to 70° C
Storage Temperature	-40° C to 85° C

#### 3. RF output power

	Band	Limited power
WlAN	2400MHZ-2483.5MHZ	<20dBm
BT	N/A	

## 4. The display method of Model approved code

In the factory, the model approve code is pasted on the back shell in a label.

### 5. Radiation Exposure Statement

This equipment complies with radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of RF Rules. This equipment should be installed and operated with minimum distance of 20 in (50cm) between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter

### CAUTION:

To comply with the limits of the Class B digital device pursuant to Part 15 of the Rules, this device is compliant with Class B limits. All peripherals must be shielded and grounded. Operation with non-certified peripherals or non-shielded cables may results in interference to radio or reception

## **MODIFICATION**

To assure continued compliance, Any changes or modifications not expressly approved by the grantee of this device could void the users authority to operate the device.

### 6. Radiation Exposure Statement


This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 50 cm(8 in )between the radiator and your body NOTE To satisfy exterior labeling requirements, the following text must be placed on the exterior of the end product Contains Transmitter module To satisfy IESD exterior labeling requirements, the following text must be placed on the exterior of the end product "Contains Transmitter module





This symbol on the product or on its packaging indicates that this product must not be disposed of with your household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

The device is restricted to indoor use only when operating in the 2400 to 2483.5 MHz frequency range.



#### 7. RSS-GEN 8.4 User Manual Notice

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

"Operation is subject to the following two conditions: (1) this device may not cause interference,and (2) this device must accept any interference,including interference that may cause undesired operation of the device."

Le présent appareil est conforme, aux CNR d'Industrie Canada applicables auxappareils radio exempts de licence. Lexploitation est autorisee aux deux conditions suixantes

- 1) Lappareil ne doitpas produire de brouillaaer
- 2) Kappareil doit accepter tout brouillaae radioelectrigue subi,meme si le brouillaaeest susceptible d'en compromettre le fonctionnement.

## 8. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Manufacturer: Qingdao Intelligent & Precise Electronics Co., Ltd.

Address: 218 Qianwangang Road, Qingdao Economic & Technological Development Zone,

Qingdao, China

Importers:

**Hisense France SAS** 

Address: 9 Rue des 3 Soeurs, 93420 Villepinte, France

Hisense Iberia, S.L.U

Address: Ronda Auguste y Louis Lumiere. 23 Nave 12. Edificio Lumiere - Parque

Tecnológico 46980

Paterna (Valencia) - Spain

Hisense Italia S.r.l

Address: Via Montefeltro, 6/A, 20156 MILANO

Hisense South Africa

Address: The Estuaries, Building 17 Oxbow Crescent, Century City, Cape Town, SouthAfrica