IR/RF Internet Wireless Keyboard

Overview

System Requirement

Installation Multimedia Button Functions

Setting Program

Overview

Congratulations on your purchase of the IR/RF Internet Wireless Keyboard. The IR/RF Internet Wireless Keyboard combines a standard keyboard layout with 17 convenient Multimedia Buttons which control the following:

- CD control buttons: Play/Pause, Previous, Next, and Stop.
- Volume control buttons: Volume Up, Volume Down, and Mute
- · World Wide Web site buttons: Internet browser, and E-mail.
- · Re-defineable control buttons: The function of button can be re-difined

System Requirement

Before installing the IR/RF Internet Wireless Keyboard software, please make sure that the hardware connections of your keyboard are correctly set up. The following system specifications are required:

- IBM PC compatible system .
- Microsoft® Windows® 95, 98, 2000 or NT4.0
- CD-ROM drive (for CD and Video operation)
- Standard sound card (for CD and Video operation)

When using the 3 power management buttons, particular requirements are needed:

- Microsoft® Windows® 98 or 2000 Operating System .
- The system supporting ACPI or APM II .
- ATX mother board and ATX power supply

Top

Installation

Installation for Windows operation system

Please follow the instructions below on how to install the IR/RF Internet Wireless Keyboard software to your PC system.

- Please insert the CD included in your package, labeled "Multimedia Keyboard Driver" into your CD-ROM drive.
- 2. Simply double-click on the setup.exe to continue the installation procedure.
- 3. Follow all the on-screen instructions.

Uninstallation

1 14

 From the Windows Start Menu, locate uninstall under Programs Files\Multimedia Keyboard V1.0\

, and double-click on Uninstall Multimedia Keyboard to uninstall the driver.

Top

Multimedia Button Functions

Multimedia hot keys Internet hot keys Customize hot keys

	CD Player / VCD Playe
a de la colo	Windows CD Player / Winamp
	Previous Track
	Stop/Eject
	Play
	Next Track
	Volumn -/+
	Mute on/off
	Menu
	Close
	WWW
	Email
	Address Book
	WWW Search
	Help
	Dos Shell
	User Define
Power hot keys	
	Sleep
Ē	Wake up
	Power off
Pointing Devices	

Mouse left key Mouse right key Pointing control Scrolling Wheel

Setting Program

Pop-up Menu

A in

Once the software installation for the Multimedia Keyboard is complete, the icon is shown on the Windows® taskbar. The setting program provides 17 graphic Multimedia Buttons on the screen. You can Re-defineable control buttons.

Graphic Multimedia Buttons

Left-click the icon on the taskbar of Windows® to activate the graphic Multimedia Buttons.Once you place the pointer on a button, a tooltip dialog box will appear displaying the function of the particular button.

Top

Top

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment