DO NOT PRINT COMMENTS

MERKURY

MERKURY INNOVATIONS CONFIDENTIAL

FILE INFORMATION

DATE: 03/05/18

FACTORY: SWETZ SOUND

MODEL NUMBER:

MI-BTE11-Series (MANUAL)

PRINTER SPECIFICATIONS

FILE NAME: MI-BTE11_Manual_030518.ai

SCALE: 100%

SIZE: Trim: W 372mm x H 144mm

PAPER STOCK: 80g Art Paper INNER STRUCTURE: (none)

FINISH: PP Matte Varnish Coating

INKS: 1/0 Greyscale

PRESS WORK / NOTES: Trim to size, score, fold,

& glue in specified areas.

----- Score

DO NOT print Comments or Dielines.

Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT

MERKURY CHINA:

perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)

File created by Dmitry Shmakov

- Please include this manual in all packaging

for MI-BTE11

- Greyscale

Double sided printing

- FIT INSIDE STORAGE COMPARTMENT IN INNER TRAY

HOW TO FOLD IT (Internal reference only) PLACE IN STORAGE COMPARTMENT ONCE FOLDED









Troubleshooting

No power

Music is not playing

Recharge your earbuds using the included micro USB cable. Try using a different micro USB cable. Make sure your Bluetooth device has A2DP profile Check if both devices are paired and connected over Bluetooth. Restart the earbuds to reconnect your Navigate to your Bluetooth settings menu on your Bluetooth device, tap "MERKURY BTE11", and select "Forget". Now follow the steps to pair your

Bluetooth device will not reconnect with the earbuds

Specifications: Frequency Response: 20Hz to 50KHz Driver Size: 10mm Impedence: 32 oHm Battery Information:

Music playing time: Up to 3 Hours*

Bluetooth Information: Bluetooth Specification: V4.2 Additional Connection Sources: Power Source: Built-in rechargeable battery or via USB cable

Approximate Playback time depends on individual use and may be more or less than the time specified.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditi

cause undestrea operation.
Technical Support:
Please do not attempt to fix the product by yourself. If you are experiencing any problems with
the product, please do not return it to the store you bought it from. You can contact our
technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

45 Broadway, 3rd Floor New York, New York 10006

E-mail: support@merkuryinnovations.com

©2018 Merkury Innovations, LLC.

To explore our full selection of products, visit us at: www.merkuryinnovations.com The Bluetooth wordmark and logo are registered trademarks owned by Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks

and trade names are those of their respective ow Made in China

Plug the micro USB cable into the micro USB port on the side of the in-line remote, and connect the other end of the cable to either a computer USB port or to a USB-compatible.

when charging, the LED indicator will glow red.

 When charging, the LED indicator will urn off. Charging time is approximately 1.5 hours.

NOTE: When connected to an Apple device, the battery level will show on your screen next to the Bluetooth icon.

Pair & Connect with a New Device

• With the **Bounce** Earbuds powered off, press & hold the power button

on the earbuds for 3-5 seconds to turn on the earbuds. The LED light will flash blue and the earbuds will emit a tone.

NOTE: If your earbuds are already turned on, you must first power off the

After a few seconds the LED light above step.

After a few seconds the LED light above the "power" button will quickly flash blue. Your earbuds are now ready to be paired.

On your Bluetooth-enabled smartphone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.

 After a few seconds you will see "MERKURY BTE11" listed. Tap this model to select it. The LED will begin to slowly blink blue, and the earbuds will emit a tone to indicate that it has been successfully paired with your device.

NOTE: If your device asks for a password to connect to the earbuds, enter "0000"

Power On & Off/Reconnect to Bluetooth

 You only need to pair your Bluetooth device with the **Bounce** Earbuds once. · With your previously paired device's Bluetooth turned on and in range, press & hold

the power button on the Bounce Earbuds for 3-5 seconds.

The earbuds will power on, a blue LED light will flash, and will automatically reconnect to the last Bluetooth device they were connected to.
To turn the **Bounce** Earbuds off, press & hold the "power" button again for about 4 seconds. The LED light will flash red, and the earbuds will emit a descending

tone to indicate that the earbuds are now powering off.

• If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select "MERKURY BTE11" from your list of paired Bluetooth devices.

Play

• Connect your device to the Bounce Earbuds via Bluetooth (see "Pair &

Connect with a New Device").

Open your favorite music app and press play.


· Control the music, track & volume from your device, or control them from the in-line controls on the Bounce Earbuds. Press the "Power" button once to

play/pause music & answer calls, or press it twice to re-dial the last call you made.
 Press the "+" or "-" button once raise/lower the volume on the earbuds. Press and hold to skip to the next/previous track. Note: Volume on your device and on the earbuds are

controlled separately. • All audio, including music, games, videos, and notifications will be routed through the **Bounce** Earbuds.

Multi-Function Button Uses **Power Function** last connected Bluetooth device, or power off the earbuds. Power's Other Funct Play/pause music, answer/end phone calls Hang Up after a phone call Reject a phone call Press & Hold "Power" Press "Power" Twice Redial the last call you made Increase volume, decrease volume Press & Hold "+" or "-" Skip to next audio track, skip to previous audio track **Product Diagram** 1 In-line Mic & Controls 2 LED Charging Indicator Ligh Audio Drivers **Controls Diagram** Press: Press & Hold (2-3 sec.): Previous Track

OUTSIDE



COVER