

# LED Floor Light User Manual

## Features

16 million colors, RGB+HC digital color lighting.	Multiple control ways available, can be controlled by controller's switch button, IR remote and APP.
Support music sync function and various music modes available.	Voice controllable by third-party intelligent speaker like Alexa and Google Assistant etc.
Three wide-angle illuminated surfaces, no video flashing.	Dual infrared heads for sensitive remote control operation.


## Product Parameters

Dimension	22*1950mm
Material	Aluminum+ABS+Silicone
Working voltage	DC 5V / DC 12V
Rated power	MAX.10W / MAX.10W
Communication protocol	WIFI/IEEE 802.11b/g/n+BLE
Product function	Digital color/Music sync
Switch button function	ON/OFF switch/Mode adjustment.
APP control	Smart Life(Support various functions like brightness adjustment, music sync, mode switch and set timer etc.)
IR remote control	Control distance: 0-5-meters
Voice control	Support third-party intelligent speaker like Alexa and Google Assistant etc.
Installation ways	Four-segment connection
Working environment	-10~40°C

## Voice control


Turn on the third-party intelligent speaker you want to connect like Alexa, Google Assistant etc. Make sure they connect to same WiFi, and go to the APP to search for the devices and get authorized, then you can voice control the lights with the standard command words.

## Installation




## Operation

Short press: Turn on the light, or modes adjustment  
Double click: Shutdown  
Long press: Into quick flash internet pairing mode



## APP Operation

- Download and install the APP of Smart Life, open your mobile phone's WiFi and BLE, long press the switch button for over 3 seconds to make the light into quick flash internet pairing mode. Search or add the device on the APP, and log in with the WiFi password to start internet pairing.
- After pairing success, you can start to operate the APP to control the light to change colors, adjust brightness, change the modes, set timer and share your accounts etc.



## Remote controller operation

Power supply: 2V button cell  
Control distance: 5-8 meters in open area

Remove the PVC film on the back of the remote controller before use, and press the power button before operation.



Features	Action	Remote control buttons
On/Off	On/Off	①
Modes	Mode/Mode	②
Music control	Music/Play	③④
Power mode	Power/Power	⑤⑥⑦⑧
Custom mode	Custom/Play	⑨
Stepless dim	Stepless/Stepless	⑩
Color setting	Color/Color	⑪⑫⑬
IR code	IR code/IR code	⑭⑮⑯

## FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation.

3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.