

08JUL22

W:55mm x H:86.5mm




FRONT





Package Contents Remote Control Mist Spraying Dragon x 1 Remote Control x 1 Instruction Manual x 1 **Specifications** Remote Control Mist Spraying Dragon Power Supply: 3 x "AA" 1.5V Alkaline Batteries (Not Included) Remote Control Power Supply: 2 x "AAA" 1.5V Alkaline Batteries (Not Included) Black Dragon - 40 MHz White Dragon - 49 MHz **Remote Control**



Standard Control

Control the Mist Spraying Dragon to roar, move forward and flap the wings



Control the Mist Spraying Dragon to roar & spray mist.


Fill Water For Mist Spray



Open the top water cap to reach for the water container Inject water into the water container and put the top water cap back in place

⚠WARNING: Take care when pouring water into water container, water leakage may cause product damage.


Power On/Off



Slide the ON/OFF Switch to ON to turn on the Remote Control Mist Spraying Dragon. Slide the ON/OFF Switch to OFF to turn off the Remote Control Mist Spraving Dragon

BACK

Batteries Installation








To install batteries into the Remote Control Mist Spraying Dragon, unscrew the screw on the battery box cover to open the battery compartment. Insert 3 x "AA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram.


Put back in place the battery box cover and tighten the screw.

When inserting the batteries, you must insert according to the correct polarity, the Remote Control Mist Spraying Dragon won't function if batteries

Batteries Installation







To install batteries into the Remote Control, unscrew the screw on the battery hox cover to onen the battery compartment. Insert 2 x "ΔΔΔ" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on

Put back in place the battery box cover and tighten the screw

When inserting the batteries, you must insert according to the correct polarity, the Remote Control won't function if batteries are reversed.

Performance Tips

- . Do not drive the RC Mist Spraying Dragon on grass, sand or go through water
- 2. Do not drive the RC Mist Spraying Dragon in windy or rainy weather
- 3. Do not drive the RC Mist Spraying Dragon into any sharp object.
- 4. Keep fingers, hair and loose clothing away from RC Mist Spraying Dragon.

Care and Maintenance

Always use dry and soft cloth to clean this product

Avoid this product from being exposed to sunlight or heat.

Avoid immersing these toys in water, otherwise, the electronic parts may be damaged.

Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired and in good working condition.

IMPORTANT: BATTERY INFORMATION

\triangle CAUTION:

TO AVOID BATTERY LEAKAGE

 The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222)

- 2. Always purchase the correct size and grade of battery most suitable for
- 2. Always purchase the correct size and grade or battery most suitable for intended use.

 3. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings. 4. Do not mix old batteries and new batteries or standard (carbon-zinc) with
- alkaline batteries. 5. Remove exhausted or dead batteries from the product
- 6. Remove exhausted or dead uteries from the product.

 6. Remove batteries if product is not to be played with for a long time.

 7. Do not short-circuit the supply terminals.

 Should this product cause, or be affected by local electrical interference,
- move it away from other electrical equipment. Reset (switching ON & OFF again or removing and re-inserting batteries) if necessary.

This product is suitable to be used by people who has operating experience in

Please do not put the product in your mouth to prevent choking hazard of small parts.

Except the screw on the battery cover. Never try to open the product by unscrew the other screws of product. Nothing inside for service.

Please do not put the finger into available interspaces

Please do not play the product in a brutal way such as throwing, crashing or twisting it.

Please store the smaller-sized product accessories in places that are out of reach of

Avoid placing the batteries in places in high temperatures and avoid exposure to heat.

When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient.

When the product is not in use, please switch off the power supplies of the toy, and

Please note that we won't take any responsibility for any wrong operation as this ma

Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.

"Caution": Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the
- receiver is connected. Consult the dealer or experienced radio/ TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

BLACK: ECC ID: 2ADM5-FT-0358C-40 WHITE: FCC ID: 2ADM5-ET-0358C-49



Class 1 LED product

istributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in Shantou, China

ITEM# ET-03580

Keep All Relevant Information For Future Reference

