


1. Photographs of Conducted Emissions Test Configuration

Test Mode: Mode 1, Mode 3, Mode 4 and Mode 5

FRONT VIEW




REAR VIEW



Test Mode: Mode 2 and Mode 6

FRONT VIEW




REAR VIEW




2. Photographs of Radiated Emissions Test Configuration

Test Mode: Mode 1 and Mode 4

FRONT VIEW




REAR VIEW




Test Mode: Mode 2 and Mode 3

FRONT VIEW




REAR VIEW




Test Mode: Mode 5

FRONT VIEW



REAR VIEW



Test Mode: Mode 6

FRONT VIEW



REAR VIEW



————THE END————