


front side  
正面



## User manual \*1

USB-C Charging Cable \*1



1. MFB button(Touch panel)
2. Earbuds RGB indicator
3. Microphones
4. Earbuds charging pins
5. Case RGB indicator
6. Reset button
7. Case charging port(USB-C)
8. Wireless Dongle(USB-C)
9. Dongle LED indicator

Choose a pair of ear cup that fits your ears best firstly, then gently insert the earbuds into the ear and adjust the appropriate comfort.



instructions. The earbuds RGB indicator will change from flashing to steady effects if the earbuds successfully paired. Pairing mode would just last 3 minutes. If you miss the pairing time, you need to restart the device and operate follow the procedural steps mentioned above.

a). HAVIT TW970 remembers previously connected devices. When turned on, earbuds attempts to reconnect to previously connected devices.

b). HAVIT TW970 will disconnect when deviate the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range in 3 minutes.

The earbuds connect to the dongle automatically and the earbuds RGB indicator will change to red&yellow when connect successfully.

With a USB-C to USB-A converter (not supplied), you can connect the wireless dongle to a USB-A port on your device, such as PC or game controller.

Put the earbuds into the charging case and close the lid of case, they will automatically shut off.

**04 Answer incoming call (Bluetooth mode & Wireless Dongle mode)**  
Double press the left or right MFB button to answer incoming call.

\*Note: TW970 doesn't support decline a call at Wireless Dongle mode.

Both earbuds work: Long press 2s the left or right MFB button to activate voice assistant.  
Single earbud work: Long press 2s the MFB button of working earbud to activate voice assistant.

During playing in wireless dongle connection, hold the MFB button on either earbud for

3 seconds to mute or unmute the microphone. The earbuds will exit the mute mode after reboot.

\*Note: If only one earbud works, triple press left or right MFB button to switch to next song.

Charge the case using the USB-C cable connected to a computer or wall charger. When the case is charging, the case RGB indicator turn steady blue, and it turns off when the charging case is fully charged or when the power is cut off.

The earbuds make a warning tone to warn of low power. Please put the earbuds in the case to charge.

www.havitsmart.com

1. Take out one earbud from charging case, the earbuds automatically turn on and reconnect to previous connected devices;
2. Switch from one earbud to the other earbud when playing music, taking out the other earbud from the charging case and these two earbuds will connected automatically. Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes;  
(note: Call mode is applicable)
3. Please refer to the TWS mode for more functions.

Get the earbuds out of the case first, and then get the dongle from the inner front lid of the case.

Open the lid of the case and short press the reset button to change the RGB effects. There are 9 styles of RGB indicator.

This function allows you to answer a call when playing game quickly and easily. Ensure that your earbuds are connected to your mobile phone through Bluetooth and to your PC/P55 console/Nintendo Switch controller through wireless dongle at the same time. When you are playing games on your PC/P55 console/Nintendo Switch controller with the earbuds. If there is an incoming call to your mobile phone, the game audio will be interrupted by the ring tone. You can double press the MFB button on either earbud to answer / hang up the call. When the call end, the game audio will recover.

If the earbuds can't pair frequently, please reset your earbuds. Put both of the earbuds into charging case and close the cover. Open the case again, press the reset button for 3 seconds within 3 minutes, the earbuds

RGB indicator will flash alternately for 3 seconds. Then the earbuds will enter the pairing mode again, search the "HAVIT TW970" bluetooth pairing name with the mobile phone and connect again.

- Bluetooth Version: V5.3
- Working Range via Bluetooth mode: 10m (without obstacles)
- Working Range via Wireless Dongle mode: 6m (without obstacles)
- Earbuds Battery: 45mAh
- Charging Case Battery: 400mAh
- Play Time: 5h (Bluetooth mode, 60% Vol., RGB off)
- Play Time: 3h (Wireless Dongle mode, 60% Vol., RGB on)
- Talk time: 4h (Bluetooth mode, 60% Vol., RGB off)
- Case Charging Time: 2.0h
- Speaker size:  $\Phi 13\text{mm} \times 2$
- Speaker Frequency: 20Hz~20kHz
- Input Voltage / Current: DC 5V/1A
- USB Port: USB-C

1. Please follow the instruction to operate.

7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time.
8. Whatever reasons damage the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service.
9. Technical specifications are subject to change without prior notice.
10. Compatibility with all USB-C or USB-A ports is not guaranteed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2A16I-TW970

尺寸(Size): 55 X 77 mm

